

# Safety Key Selector Switch

# A22TK

# **Key-type Selector Switch with Direct Opening Mechanism**

- Selector Switch for secure equipment activation during maintenance
- 30 types of exclusive keys make it more difficult to disable.
- The trapped key of the D4JL Guard Lock Safety-door Switch has the same shape as the lockout key of the D4GL-SK10-LK□, D4SL-NSK10-LK□ Slide Key Unit. Units can be combined to improve safety.
  - (Specify the same key type.)
- Common to the switch part of Emergency Stop Switch A22E.
   (Non-lighted model only)




For the most recent information on models that have been certified for safety standards, refer to your OMRON website.




For safety precautions for all pushbutton switches, refer to the website at: www.ia.omron.com, and "Safety Precautions" on page 13 in this catalog.

# **Features**

Because the A22TK Safety Key Selector Switch uses the same key as the Guard Lock Safety-door Switch, the operator is prevented from forgetting to remove the key. The result is a safer working environment when performing maintenance.









From

# Safety can be ensured, but there is a risk of human error occurring during operation.






(To)

By using a common key, the risk of human error is reduced in operations from when the door is open/shut until the equipment is started.

# Guard Lock Safety-door Switch + Safety Key Selector Switch (A22TK)

The two locks on the door and equipment use the same key, reducing the likelihood that the user will forget to remove it. In addition, the key cannot be removed when maintenance is being performed. This prevents the key from being lost and greatly reduces the risk of an operator becoming trapped inside. Same Key



the presence of operators, equipment malfunctions can be prevented when operators are inside, enabling a higher safety level.

# **Model Number Structure**

# Model Number Legend (Ordering as a set)

The Operation Unit and Switch are delivered as a set. For information on combinations, refer to Ordering Information on page 5.

The models numbers of only Operation Units are they same as the set model numbers without (2) Contact Configuration.

 $\label{thm:example:e$ 

Ask your OMRON representative about parts without model numbers when ordering.

		A22	TK-2LL-1	2 - K	0 1	
(1) Oper	ation Uni	t		(3) Key Av	ailability	(4) Key Type
Symbol	No. of notches	Key release position	Key position of NC contact closing	Symbol	Туре	01 to 30: 30 types
	Holdies			None	No key	
2LL		$\bigcirc$	$\bigcirc$	K	With key	
2RL	2	<b>Ø</b>	$\bigcirc$	(2) Contac	t Configura	ation
2LR				Symbol	T	уре
				01	SPS	ST-NC
2RR				11	SPST-NC	)/SPST-NC
				02	DPS	ST-NC
				12	DPST-NC	+ SPST-NO
				21	DPST-NO	+ SPST-NC
				03	TPS	T-NC

Key can be created up to 30 types. Specify keys in order starting from 01.

#### Key drop preventive type

A 2 2 T K - 
$$\square$$
 -  $\square$  -  $\square$  0 1 - S J

#### (1) Operation Unit

Symbol	No. of notches	Key release position	Key position of NC contact closing
2LL			$\bigcirc$
2RL	2	$\bigcirc$	$\bigcirc$
2LR	2	$\bigcirc$	$\bigcirc$
2RR		$\bigcirc$	$\bigcirc$

#### (2) Contact Configuration

Symbol	Туре
01	SPST-NC
11	SPST-NO/SPST-NC
02	DPST-NC
12	DPST-NC+SPST-NO
21	DPST-NO+SPST-NC
03	TPST-NC

## (3) Key Availability


Symbol	Туре
None	No key
K	With key

# **Key drop preventive (on the A22TK-2RL-□)**

#### Standard type



#### Key drop preventive type



# **Contact Configuration**


# A22TK-2□L

Key position	SPST-NC	SPST-NO/SPST-NC	DPST-NC	DPST-NC + SPST-NO	DPST-NO + SPST-NO	TPST-NC
$\bigcirc$	• • •	0 0	• • • • •	0 0	0 0 0 0	• • • • • • • •
	• , •	0 0 0 0	• • • • •	• • • • • • •	0 0 0 0 0 0	• • • • • • •

# A22TK-2□R

Key position	SPST-NC	SPST-NO/SPST-NC	DPST-NC	DPST-NC + SPST-NO	DPST-NO + SPST-NO	TPST-NC
$\bigcirc$	• , •	0 0 0 0	• • • •	<u>• • • • • • • • • • • • • • • • • • • </u>	0 0 0 0 0 0	• • • • • • •
$\bigcirc$	<u>• 1 •</u>	0 0	• • • • •	0 0	0 0 0 0	• • • • • • • • • • • • • • • • • • • •

# **Operation Angle**



FP: Free position
TTP: Total travel position

HP : Key hold position (drop prevention) \*2

- \*1. If the key is stopped at a position between FP and TTP, the contacts will not be in the states indicated above.

  Always be careful to turn the key completely to the FP (HP) or TTP position to ensure that the contacts are properly switched and the direct open circuit operation characteristics are obtained.
- \*2. Key drop preventive type (A22TK-□-SJ or A22TK-□-SJ only)

# **Ordering Information**

## **Switch**

**List of Models (Completely Assembled)**... Shipped as a set which includes the Operation Unit and Switch. The models numbers of only Operation Units are they same as the set model numbers without (2) Contact Configuration. Example: The model number of the Operation Unit from the A22TK-2LL-12-K01 Set is A22TK-2LL-K01. Ask your OMRON representative about parts without model numbers when ordering.

Appearance	Key release position	Key position of NC contact closing	Contact Configuration	Key availability	Model
			SPST-NC		A22TK-2LL-01-K01
			SPST-NO/SPST-NC		A22TK-2LL-11-K01
			DPST-NC		A22TK-2LL-02-K01
			DPST-NC + SPST-NO		A22TK-2LL-12-K01
			DPST-NO + SPST-NC		A22TK-2LL-21-K01
			TPST-NC		A22TK-2LL-03-K01
			SPST-NC		A22TK-2RL-01-K01
_	_		SPST-NO/SPST-NC		A22TK-2RL-11-K01
			DPST-NC		A22TK-2RL-02-K01
			DPST-NC + SPST-NO		A22TK-2RL-12-K01
			DPST-NO + SPST-NC		A22TK-2RL-21-K01
			TPST-NC	V	A22TK-2RL-03-K01
			SPST-NC	Yes	A22TK-2LR-01-K01
			SPST-NO/SPST-NC	Ė	A22TK-2LR-11-K01
out)			DPST-NC	-	A22TK-2LR-02-K01
			DPST-NC + SPST-NO		A22TK-2LR-12-K01
	)		DPST-NO + SPST-NC	-	A22TK-2LR-21-K01
			TPST-NC	-	A22TK-2LR-03-K01
			SPST-NC	-	A22TK-2RR-01-K01
	$\bigcirc$	$\bigcirc$	SPST-NO/SPST-NC		A22TK-2RR-11-K01
			DPST-NC		A22TK-2RR-02-K01
			DPST-NC + SPST-NO		A22TK-2RR-12-K01
			DPST-NO + SPST-NC		A22TK-2RR-21-K01
			TPST-NC		A22TK-2RR-03-K01
			SPST-NC		A22TK-2LL-01-01
			SPST-NO/SPST-NC		A22TK-2LL-01-01
			DPST-NC		A22TK-2LL-02-01
			DPST-NC + SPST-NO		A22TK-2LL-02-01
			DPST-NO + SPST-NC		A22TK-2LL-12-01
:			TPST-NC	-	A22TK-2LL-03-01
		$\bigcirc$	SPST-NC		A22TK-2RL-01-01
			SPST-NO/SPST-NC		A22TK-2RL-11-01
			DPST-NC		A22TK-2RL-02-01
			DPST-NC + SPST-NO		A22TK-2RL-12-01
			DPST-NO + SPST-NC		A22TK-2RL-21-01
			TPST-NC	No	A22TK-2RL-03-01
			SPST-NC	-	A22TK-2LR-01-01
O'A			SPST-NO/SPST-NC		A22TK-2LR-11-01
	( \ \ )	( / )	DPST-NC		A22TK-2LR-02-01
			DPST-NC + SPST-NO		A22TK-2LR-12-01
			DPST-NO + SPST-NC		A22TK-2LR-21-01
			TPST-NC		A22TK-2LR-03-01
			SPST-NC		A22TK-2RR-01-01
			SPST-NO/SPST-NC		A22TK-2RR-11-01
			DPST-NC		A22TK-2RR-02-01
			DPST-NC + SPST-NO		A22TK-2RR-12-01
			DPST-NO + SPST-NC		A22TK-2RR-21-01
			TPST-NC	H	A22TK-2RR-03-01

Annogrange	Key release	Key position of NC	Contact Configuration	Key	Model
Appearance	position	contact closing	Contact Configuration	availability	Model
			SPST-NC		A22TK-2LL-01-K01-SJ
			SPST-NO/SPST-NC		A22TK-2LL-11-K01-SJ
			DPST-NC		A22TK-2LL-02-K01-SJ
			DPST-NC + SPST-NO		A22TK-2LL-12-K01-SJ
			DPST-NO + SPST-NC		A22TK-2LL-21-K01-SJ
			TPST-NC		A22TK-2LL-03-K01-SJ
			SPST-NC		A22TK-2RL-01-K01-SJ
			SPST-NO/SPST-NC		A22TK-2RL-11-K01-SJ
	( / )	( \ \ )	DPST-NC		A22TK-2RL-02-K01-SJ
	$\langle \cdot \rangle$		DPST-NC + SPST-NO		A22TK-2RL-12-K01-SJ
			DPST-NO + SPST-NC		A22TK-2RL-21-K01-SJ
			TPST-NC	Yes	A22TK-2RL-03-K01-SJ
			SPST-NC		A22TK-2LR-01-K01-SJ
			SPST-NO/SPST-NC		A22TK-2LR-11-K01-SJ
(C) Line	( \ \ )	(1)	DPST-NC		A22TK-2LR-02-K01-SJ
			DPST-NC + SPST-NO		A22TK-2LR-12-K01-SJ
			DPST-NO + SPST-NC		A22TK-2LR-21-K01-SJ
			TPST-NC		A22TK-2LR-03-K01-SJ
	$\bigcirc$		SPST-NC		A22TK-2RR-01-K01-SJ
			SPST-NO/SPST-NC		A22TK-2RR-11-K01-SJ
			DPST-NC		A22TK-2RR-02-K01-SJ
			DPST-NC + SPST-NO		A22TK-2RR-12-K01-SJ
			DPST-NO + SPST-NC		A22TK-2RR-21-K01-SJ
			TPST-NC		A22TK-2RR-03-K01-SJ
			SPST-NC		A22TK-2LL-01-01-SJ
			SPST-NO/SPST-NC		A22TK-2LL-11-01-SJ
			DPST-NC		A22TK-2LL-02-01-SJ
			DPST-NC + SPST-NO		A22TK-2LL-12-01-SJ
			DPST-NO + SPST-NC		A22TK-2LL-21-01-SJ
			TPST-NC		A22TK-2LL-03-01-SJ
		_	SPST-NC		A22TK-2RL-01-01-SJ
			SPST-NO/SPST-NC		A22TK-2RL-11-01-SJ
			DPST-NC		A22TK-2RL-02-01-SJ
	$\langle \rangle$		DPST-NC + SPST-NO		A22TK-2RL-12-01-SJ
			DPST-NO + SPST-NC		A22TK-2RL-21-01-SJ
			TPST-NC	No	A22TK-2RL-03-01-SJ
			SPST-NC	140	A22TK-2LR-01-01-SJ
			SPST-NO/SPST-NC		A22TK-2LR-11-01-SJ
			DPST-NC		A22TK-2LR-02-01-SJ
			DPST-NC + SPST-NO		A22TK-2LR-12-01-SJ
			DPST-NO + SPST-NC		A22TK-2LR-21-01-SJ
			TPST-NC		A22TK-2LR-03-01-SJ
			SPST-NC		A22TK-2RR-01-01-SJ
			SPST-NO/SPST-NC		A22TK-2RR-11-01-SJ
			DPST-NC		A22TK-2RR-02-01-SJ
			DPST-NC + SPST-NO		A22TK-2RR-12-01-SJ
			DPST-NO + SPST-NC		A22TK-2RR-21-01-SJ
			TPST-NC		A22TK-2RR-03-01-SJ

# **Accessories**

Name	Appearance	Classification	Model	Remarks	
Control Box		One hale wallow have	A22Z-B101Y	Material: Polycarbonate resin The A22Z-B101Y do not support 2NO, 2NC or 1NO + 1NC One-piece Switch Blocks. The	
		One hole, yellow box	A22Z-B201Y	A22Z-B201Y do not support A22-series Alternate-action Switches. They also do not support 2NO, 2NC, or 1NO + 1NC One-piece Switch Blocks.	

Note: For information on two-hole and three-hole control boxes, contact your OMRON representative.

The Switch Block, Mounting Latch, Connector, and Lock Plate of A22E can be used.

# **Specifications**

# **Approved Standard Ratings**

- UL, cUL (File No. E41515): 6 A at 220 VAC, 10 A at 110 VAC
- TÜV (EN60947-5-1) (Low Voltage Directive): 3 A at 220 VAC
- CCC (GB14048.5): 3 A at 240 VAC, 1.5 A at 24 VDC

#### **Certified Standards**

Certification body	Standards	File No.
UL *1	UL508, C22.2 No.14	E41515
TÜV SÜD	EN60947-5-1 (certified direct opening mechanism)	Consult your OMRON representative for details.
CQC(CCC)	GB14048.5	2003010303070635
KOSHA	EN60947-5-1	2009-156

Note: Only models with NC contacts have a direct opening mechanism.

# Ratings

Contacts (Standard load)

Pated carry current	Rated voltage (V)	Rated current (A)				
(A)		AC15 (inductive load)	AC12 (resistive load)	DC13 (inductive load)	DC12 (resistive load)	
	24 VAC	10	10		_	
	110	5	10			
	220	3	6	-	-	
	380	2	3			
10	440	1	2			
10	24 VDC			1.5	10	
	110			0.5	2	
	220	-	-	0.2	0.6	
	380			0.1	0.2	

Note: 1. Rated current values are determined according to the testing conditions. The above ratings were obtained by conducting tests under the following conditions.

- (1) Ambient temperature: 20±2C°
- (2) Ambient humidity: 65±5% RH
- (3)Operating frequency: 20 operations/minute
- 2. Minimum applicable load: 10 mA at 5 VDC

# **Characteristics**

Item	Model	A22TK	
Allowable operating	Mechanical	30 operations/minute max.	
frequency	Electrical	30 operations/minute max.	
Insulation resistance	1	100 MΩ min. (at 500 VDC)	
Dielectric strength	Between terminals of same polarity	2,500 VAC, 50/60 Hz for 1 min.	
Dielectric Strength	Between each terminal and ground	2,500 VAC, 50/60 Hz for 1 min.	
Vibration resistance *1		10 to 55 Hz, 1.5-mm double amplitude (within 1 ms)	
Shock resistance	Destruction	1000 m/s <sup>2</sup>	
SHOCK TESISTATICE	Malfunction *1	250 m/s <sup>2</sup> max.	
Durability	Mechanical	100,000 operations min.	
Durability	Electrical	100,000 operations min.	
Ambient operating temperating	erature *2	-20 to +70°C	
Ambient operating humid	dity	35% to 85%RH	
Ambient storage tempera	ature	-40 to +70°C	
Degree of protection		IP65 *3	
Electric shock protection	class	Class II	
PTI (tracking characteris	tic)	175	
Degree of contamination		3 (EN60947-5-1)	
*4 Malfatia.a		•	

<sup>\*1.</sup> Malfunction within 1 ms.

Note: 1. Do not allow the load current to exceed the rated value.


- 2. The contact ON/OFF timing is not synchronized. Confirm performance before application.
- 3. Once the contacts have been used to switch a load, however, they cannot be used to switch smaller loads. The contact surfaces will become rough once they have been used and contact reliability for smaller loads may be reduced.

<sup>\*1.</sup> UL-certification for CSA C22.2 No. 14 has been obtained. (Certification has been obtained for the Switch Unit only)

<sup>\*2.</sup> With no icing or condensation.

<sup>\*3.</sup> The degree of protection from the front of the panel.

# **Structure and Nomenclature**





#### Switch Contact Ratings

10 A at 110 VAC (resistive load) 10 A at 24 VDC (resistive load)

#### **Contact Configuration**

SPST-NC, SPST-NO/SPST-NC, DPST-NC, DPST-NC + SPST-NO, DPST-NO + SPST-NC, and TPST-NC



#### Lock Plate (attached with the Switch)


(Refer to "Mounting the Lock Plate" on page 14 for use.)

(The above figures are examples of the model with key.)

**Mounting Hole** 

Dimensions (Unit: mm)


## **●**Switch




## Accessories

#### **Control Box**

# A22Z-B101Y (1 hole)






Mounting Hole
2-R3


16±1 dia.
(Side lead draw-out hole)

Two, mounting holes


### **Control Box**

## A22Z-B201Y (1 hole)






41



# **Cable Draw-out Hole (Top View)**

**Cable Draw-out Hole (Top View)** 

## **Terminal Arrangement (Bottom View)**



## **Terminal Connection**

Туре	Terminal connection (Bottom View)								
	SPST-NO	/SPST-NC	DPS	T-NC	DPST-NC + SPST-NO	DPST-NO + SPST-NC	TPST-NC		
Non-lighted	1	3	1	1	0 0 0	1 3 3			
	2	4	2	2	2 2 4	2 4 4	2 2 2		

# **Application Examples**

# Application Overview


- Switching between normal operation mode and maintenance mode is performed manually.
  In normal operation mode, the power supply to the motor M2 is turned OFF when the guard is opened.
  In maintenance mode, the power supply to the motor M2 is turned OFF when the enabling switch is released or strongly gripped.
- In normal operation mode and maintenance mode, the power supply to the motor M1 and M2 is turned OFF when the emergency stop switch is pressed.

#### Evaluation example


PL/safety category	Model	Stop category	Reset
PLe/4 equivalent	Safety Key Selector Switch A22TK-2□□-11 (SPST-NO/SPST-NC type) Guard lock Safety-door Switch D4NL-□A□A-□, -□A□B-□, -□A□C-□ (Mechanical Lock Type) Enabling Grip Switch A4EG Safety Guard Switching Unit G9SX-GS226-T15 Flexible Safety Unit G9SX-BC202 (24 VDC)	-	-

Note: The above PL is only the evaluation result of the example concerning solely the mode selection. The PL must be evaluated in an actual application by the customer after confirming the usage conditions.

#### Circuit Diagram



# **Timing Chart**



- (1) The G9SX-GS starts in operation mode.
- (2) The mode switches to maintenance
- The operator opens the guard and
- performs maintenance work.
  The Enabling Switch is gripped to the middle position.
- (5) The G9SX-GS starts in maintenance
- The G9SX-GS will stop when the
- Enabling Switch is released or gripped. The G9SX-GS will start again after the guard is closed and the mode is switched to operation mode.
- The G9SX-GS will stop and the guard can be opened when the stop signal is input while in operation mode
- The guard is closed and the G9SX-GS starts again.
- (10)All the units will stop if the emergency stop is pressed.

## Application Overview

- (1) In normal operation mode, the power supply to the motor M is turned ON when the reset switch S7 is pressed while the rotator is stopped and the guard is locked after closed.
- (2) The PLC sends high speed rotation command to the motor controller.
- (3) The stop signal is applied with the S8.
- (4) The PLC sends deceleration command to the motor controller.
- (5) The guard can be unlocked when the rotator slows down to the safe speed.
- (6) The power supply to the motor M is turned OFF when the guard is unlocked with the S5. (7) The mode switches to maintenance mode with the mode selection switch.


- (8) The PLC sends low speed rotation command to the motor controller.
  (9) The power supply to the motor M is automatically turned ON again by gripping the enabling switch to the middle position.
- (10)The operator opens the guard and performs maintenance work.

#### Evaluation example


PL/safety category	Model	Stop category	Reset
PLd/3 equivalent	Safety Key Selector Switch A22TK-2□□-11 (SPST-NO/SPST-NC type) Guard lock Safety-door Switch D4NL-□A□A-□, -□A□B-□, -□A□C-□ (Mechanical Lock Type) Enabling Grip Switch A4EG Low-speed Monitoring Unit G9SX-LM224-F10-R□ Flexible Safety Unit G9SX-BC202 (24 VDC)	-	-

Note: The above PL is only the evaluation result of the example concerning solely the mode selection. The PL must be evaluated in an actual application by the customer after confirming the usage conditions.

#### Circuit Diagram



# **Timing Chart**




# Installation

#### Mounting to the Panel

#### (1) Preparing the Panel


- The panel dimensions are shown below.
- Recommended panel thickness: 1 to 5 mm.



- A Lock Ring is provided as a standard feature.
- When painting or coating the panel, make sure that the specified panel dimensions apply to the panel after painting or coating.


#### (3) Mounting the Switch on the Operation Unit

• Insert the Operation Unit into the Switch Unit, aligning the arrow mark inscribed on the Case with the lever on the Switch Blocks, then move the lever in the direction indicated by the arrow in the following figure.




#### (2) Mounting the Operation Unit on the Panel

- Insert the Operation Unit from the front surface of the panel, insert the Lock Ring and the mounting ring from the terminal side, then tighten the ring.
   Before tightening, check that the rubber washer is present between the Operation Unit and the panel.
- $\bullet$  Tighten the mounting ring at a torque of 0.98 to 1.96 N·m.
- When using a Lock Ring, insert the projecting part into the lock slot, and then tighten the mounting ring.



#### (4) Removing the Switch


 Move the lever in the direction indicated by the arrow in the following figure, then pull the Operation Unit or the Switch Blocks. Since the lever has a hole with an inside diameter of 6.5 mm, the lever can be moved in the specified direction by inserting a screwdriver into the hole and then moving the screwdriver.



#### Installing/Removing the Switch Blocks


#### (1) Installing the Switch Blocks

 Hook the small protrusion on the Mounting Latch into the groove on the other side of the lever, then push up the Switch Block in the direction indicated by the arrow in the figure below.




#### (2) Removing the Switch Blocks

 Insert a screwdriver between the Mounting Latch and the Switch Block, then push down the screwdriver in the direction indicated by the arrow in the following figure.



#### Wiring

 Loosen the terminal screw from the Switch Unit until it completely comes off the groove, insert a screwdriver as shown in the following figure, then push up the washer in the direction indicated by the arrow to temporarily secure it. Now, a round crimp terminal can be connected. After inserting the terminal, tighten the screws to complete wiring.



# **Safety Precautions**

Be sure to read the precautions for All Pushbutton Switches in the website at:http://www.ia.omron.com/.

#### Indication and Meaning for Safe Use

<u></u> ∆ DANGER	Indicates an imminently hazardous situation which, if not avoided, is likely to result in serious injury or may result in death. Additionally there may be severe property damage.
<b>⚠</b> CAUTION	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury or in property damage.
Precautions for Safe Use	Supplementary comments on what to do or avoid doing, to use the product safely.
Precautions for Correct Use	Supplementary comments on what to do or avoid doing, to prevent failure to operate, or undesirable effect on product performance.

## **⚠ DANGER**

Always confirm that safety functions are operational before stating operation. Wiring mistakes, setting mistakes, switch failure or other factors may prevent safety functions from operating. This may result in the machine continuing to operate, possibly resulting in human accidents.



## **↑** CAUTION

If the Operation Unit is separated from the Socket Unit, the equipment will not stop, creating a hazardous condition.



Secure the lever on the Socket Unit by using the A22Z-3380 Lock Plate so that the Operation Unit cannot be easily separated from the Socket Unit.

(Refer to "Mounting the Lock Plate" at the right.)

#### [Used in combination with a Slide Key]

The machine may operate, possibly causing injury. Do not disable safety function by using a spare door switch operation key or spare key with the door open.



#### [Used outside/inside hazardous area]

The machine may operate, possibly causing injury. Do not disable safety function by using a spare key outside or inside the hazardous area.



#### **Precautions for Safe Use**

#### **Installation Environment**

- Do not use the switch in locations where explosive or flammable gasses may be present.
- Do not use the switch submerged in oil or water or in locations continuously subject to splashes of oil or water. Doing so may result in oil or water entering the switch.

#### Wiring

- Connect a fuse in series with the A22TK to protect it from shortcircuit damage. The value of the breaking current of the fuse must be calculated by multiplying the rated current by 150% to 200%.
  - When using the A22TK for an EN rating, use a 10-A fuse of type gl or gG that complies with IEC 60269.
- Always make sure that the power is turned OFF before wiring the Switch.
- Also, do not touch the terminals or other current-carrying ports while power is being supplied.
- Check the contact specifications before mounting the Switch Block. Use an NC contact for a safety circuit. It may not operate properly. Check the Switch Block for safe operation before use.
- Check the operating specification before mounting the Operation Unit. It may not operate properly. Check the Operation Unit for safe operation before use.

#### Installation

- Do not drop the Switch. Doing so may prevent the Switch from functioning to its full capability.
- Make sure the Switch is mounted securely to prevent it from falling off. Otherwise injury may result.
- Mount the Operation Key so that it will not come into contact with persons in the area when the door is opened and closed. Injury may result.
- Do not use a Switch as a stopper. Otherwise, the switch may be damaged and may not operate properly.
- Be sure to use the supplied Lock Ring. Otherwise, the switch may rotate and may not operate properly.

#### **Others**

- Do not attempt to disassemble or modify the Switch. Doing so may cause the Switch to malfunction.
- The durability of the Switch is greatly influenced by the switching conditions. Always test the switch under actual working conditions before application and use it in a switching circuit for which there are no problems with performance.
- The user must not maintain or repair equipment incorporating the Switch. Contact the manufacturer of the equipment for any maintenance or repairs required.

#### **Precautions for Correct Use**

#### **Operating Environment**

- This Switch is designed for use indoors.
  Using the Switch outdoors may damage it.
- Do not use the Switch where corrosive gases (e.g., H<sub>2</sub>S, SO<sub>2</sub>, NH<sub>3</sub>, HNO<sub>3</sub>, or Cl<sub>2</sub>) are present or in locations subject to high temperature and humidity. Doing so may result in damage to the Switch as a result of contact failure or corrosion.
- Do not use the Switch in any of the following locations.
  - Locations subject to extreme temperature changes
  - Locations subject to high humidity or condensation
  - · Locations subject to excessive vibration
  - Locations where metal dust, processing waste, oil, or chemicals may enter through the protective door
  - Locations subject to detergents, thinners, or other solvents

#### Storage

 Do not store the Switch where corrosive gases (e.g., H<sub>2</sub>S, SO<sub>2</sub>, NH<sub>3</sub>, HNO<sub>3</sub>, or Cl<sub>2</sub>) or dust is present, or in locations subject to high temperature or high humidity.


#### Mounting

- Do not tighten the mounting ring more than necessary using tools such as pointed-nose pliers. Doing so will damage the mounting ring. The tightening torque is 0.98 to 1.96 N·m.
- Recommended panel thickness: 1 to 5 mm.

#### Mounting the Lock Plate

- Confirm that the lever on the Mounting Latch is on the side where the Operation Unit is secured and then insert the protrusion on the Lock Plate into the hole in the lever on the Mounting Latch.
- Press the hole on the Lock Plate onto the protrusion on the Mounting Latch until it clicks into place.

After mounting the Lock Plate, check that the lever does not move.



## Operating the Key

 When rotating the key to the total travel position or free position, the operating force must be 1.47 N·m max.


#### Wiring

- Terminal screws must be Phillips or slotted M3.5 screws with a square washer.
- The tightening torque is 1.08 to 1.27 N·m.
- Single wires, stranded wires, and crimp terminals can be connected to the Switch
- · Applicable Wiring Materials:

Twisted strands: 2 mm<sup>2</sup> max.

Solid wire: 1.6 mm dia. max.

# Naked Crimp Terminals Crimp Terminals with Insulating Sheaths



- After wiring the Switch, maintain an appropriate clearance and creepage distance.
- Do not pull the lead wires with excessive force. Doing so may disconnect them.
- The cable cannot be bended repeatedly.
- When bending the cable, provide a bending radius of 45 mm min. so as not to damage the cable insulation or sheath. Excessive bending may cause fire or leakage current.

#### **Operating Environment**


- The IP65 model is designed with a protective structure so that it will
  not sustain damage if it is subjected to water from any direction to
  the front of the panel.
- The Switch is intended for indoor use only. Using the Switch outdoor may cause it to fail.

#### **Using the Microload**

Contact failure may occur if a Switch designed for a standard load is used to switch a microload. Use Switches within the application ranges shown in the following graph. Even within the application range, insert a contact protection circuit, if necessary, to prevent the reduction of life expectancy due to extreme wear on the contacts caused by loads where inrush current occurs when the contact is opened and closed.

The minimum applicable load is the N-level reference value. This value indicates the malfunction reference level for the reliability level of 60% ( $\lambda$  60) (conforming to JIS C5003).

The equation,  $\lambda$  60 = 0.5 x 10<sup>-6</sup>/time indicates that the estimated malfunction rate is less than 1/2,000,000 with a reliability level of 60%.




#### **Others**

- If the panel is to be coated, make sure that the panel meets the specified dimensions after coating.
- Due to the structure of the Switch, severe shock or vibration may cause malfunctions or damage to the Switch.

Also, most Switches are made from resin and will be damaged if they come into contact with sharp objects. Particularly scratches on the Operation Unit may create visual and operational obtrusions.

Handle the Switches with care, and do not throw or drop them.



- · Perform maintenance inspections periodically.
- Do not use the key switch to stop/start the machine.
- Mode switching by key must be performed by the operator specified in the operating manual.
- · Apply load current not to exceed the rated value.
- The contact ON/OFF timing is not synchronized. Confirm performance before application.

#### READ AND UNDERSTAND THIS CATALOG

Please read and understand this catalog before purchasing the products. Please consult your OMRON representative if you have any questions or comments.

# Warranty and Limitations of Liability

#### WARRANTY

OMRON's exclusive warranty is that the products are free from defects in materials and workmanship for a period of one year (or other period if specified) from date of sale by OMRON.

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, REGARDING NON-INFRINGEMENT, MERCHANTABILITY, OR FITNESS FOR PARTICULAR PURPOSE OF THE PRODUCTS. ANY BUYER OR USER ACKNOWLEDGES THAT THE BUYER OR USER ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE. OMRON DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED.

#### LIMITATIONS OF LIABILITY

OMRON SHALL NOT BE RESPONSIBLE FOR SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED ON CONTRACT, WARRANTY, NEGLIGENCE, OR STRICT LIABILITY.

In no event shall responsibility of OMRON for any act exceed the individual price of the product on which liability is asserted.

IN NO EVENT SHALL OMRON BE RESPONSIBLE FOR WARRANTY, REPAIR, OR OTHER CLAIMS REGARDING THE PRODUCTS UNLESS OMRON'S ANALYSIS CONFIRMS THAT THE PRODUCTS WERE PROPERLY HANDLED, STORED, INSTALLED, AND MAINTAINED AND NOT SUBJECT TO CONTAMINATION, ABUSE, MISUSE, OR INAPPROPRIATE MODIFICATION OR REPAIR.

# **Application Considerations**

#### **SUITABILITY FOR USE**

OMRON shall not be responsible for conformity with any standards, codes, or regulations that apply to the combination of products in the customer's application or use of the product.

At the customer's request, OMRON will provide applicable third party certification documents identifying ratings and limitations of use that apply to the products. This information by itself is not sufficient for a complete determination of the suitability of the products in combination with the end product, machine, system, or other application or use.

The following are some examples of applications for which particular attention must be given. This is not intended to be an exhaustive list of all possible uses of the products, nor is it intended to imply that the uses listed may be suitable for the products:

- · Outdoor use, uses involving potential chemical contamination or electrical interference, or conditions or uses not described in this document.
- Nuclear energy control systems, combustion systems, railroad systems, aviation systems, medical equipment, amusement machines, vehicles, safety equipment, and installations subject to separate industry or government regulations.
- Systems, machines, and equipment that could present a risk to life or property.

Please know and observe all prohibitions of use applicable to the products.

NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

#### **Disclaimers**

#### **CHANGE IN SPECIFICATIONS**

Product specifications and accessories may be changed at any time based on improvements and other reasons.

It is our practice to change model numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the product may be changed without any notice. When in doubt, special model numbers may be assigned to fix or establish key specifications for your application on your request. Please consult with your OMRON representative at any time to confirm actual specifications of purchased products.

#### **DIMENSIONS AND WEIGHTS**

Dimensions and weights are nominal and are not to be used for manufacturing purposes, even when tolerances are shown.

#### **ERRORS AND OMISSIONS**

The information in this document has been carefully checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical, or proofreading errors, or omissions.

#### PERFORMANCE DATA

Performance data given in this catalog is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of OMRON's test conditions, and the users must correlate it to actual application requirements. Actual performance is subject to the OMRON Warranty and Limitations of Liability.

#### **PROGRAMMABLE PRODUCTS**

OMRON shall not be responsible for the user's programming of a programmable product, or any consequence thereof.

# **Copyright and Copy Permission**

## **COPYRIGHT AND COPY PERMISSION**

This document shall not be copied for sales or promotions without permission.

This document is protected by copyright and is intended solely for use in conjunction with the product. Please notify us before copying or reproducing this document in any manner, for any other purpose. If copying or transmitting this document to another, please copy or transmit it in its entirety.

**OMRON Corporation Industrial Automation Company** 

Tokyo, JAPAN

Contact: www.ia.omron.com

Regional Headquarters

OMRON EUROPE B.V. Wegalaan 67-69-2132 JD Hoofddorp The Netherlands Tel: (31)2356-81-300/Fax: (31)2356-81-388

OMRON ASIA PACIFIC PTE. LTD.

No. 438A Alexandra Road # 05-05/08 (Lobby 2), Alexandra Technopark, Singapore 119967 Tel: (65) 6835-3011/Fax: (65) 6835-2711

OMRON SCIENTIFIC TECHNOLOGIES INC.

6550 Dumbarton Circle, Fremont CA 94555-3605 U.S.A. Tel: (1) 510-608-3400/Fax: (1) 510-744-1442

OMRON (CHINA) CO., LTD.

Room 2211, Bank of China Tower, 200 Yin Cheng Zhong Road, PuDong New Area, Shanghai, 200120, China Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200 **Authorized Distributor:** 

© OMRON Corporation 2009 All Rights Reserved. In the interest of product improvement, specifications are subject to change without notice.

CSM\_8\_1\_1016 Cat. No. A189-E1-01

Printed in Japan 0409