



MotionWorks IEC61131-3 Toolboxes



MotionWorks IEC Toolboxes Rev: 2013-09-013



Table Of Contents

Yaskawa's IEC61131-3 Toolboxes: 2013-09-13..... 1

Toolbox Introduction..... 1

Cam Toolbox 3

Getting Started: Cam 6

Cam Revision History..... 7

Cam Curve Characteristics..... 13

Cam Curve Types 16

Parabolic..... 18

ParabolicVelocityBlend 19

Simple Harmonic..... 20

Cycloidal 21

Modified Trapezoid 22

Modified Sine..... 23

Modified Constant Velocity..... 24

Arc..... 25

Asymmetrical Cycloidal 26

Asymmetrical Modified Trapezoid 27

Trapezoid 28

One Dwell Cycloidal_1 29

One Dwell Cycloidal_2_3 30

One Dwell Trapezoid_1 31

One Dwell Trapezoid..... 32

One Dwell Trapezoid_2_3..... 33

One Dwell Modified Sine..... 34



One Dwell Trapezoid 35

No Dwell Simple Harmonic 36

No Dwell Modified Trapezoid 37

No Dwell Modified Constant Velocity 38

NC2 Curve..... 39

Tangent Matching 40

Reverse Trapezoid 42

Double Harmonic..... 43

Reverse Double Harmonic 44

Tangent Blending 45

Cubic Spline 46

Data Types for Cam Toolbox..... 51

Data Type: AXIS_REF 52

Data Type: AxisParameterStruct 54

Data Type: BlendStruct..... 56

Data Type: CamPairs 57

Data Type: CamParameters..... 58

Data Type: CamSegmentArray..... 59

Data Type: CamSegmentStruct..... 60

Data Type: CamStruct 62

Data Type: CamSyncStruct 63

Data Type: Matrix 64

Data Type: SubMatrix 65

Data Type: TableIDStruct..... 66

Data Type: UINTArray 67

Data Type: Y_MS_CAM_STRUCT 68



Table Of Contents



Enumerated Type: TB_CurveType	70
Enumerated Type: TB_Mode	72
CalcSpline	73
Cam_Analyzer	74
CamBlend	78
CamControl	84
CamGenerator	90
CamMaster_Lookup	94
CamShift_Control	96
CamSlave_FeedToLength	103
CamSlave_FeedToLength2	114
CamSlave_Lookup	120
CamSlave_PullToLength	123
CamSlave_Recover	127
CamSlave_WindowCheck	133
CamTableManager	135
CamTableUpdate	138
SlaveIndex_Lookup	142
SlaveRegistrationCheck	145
Communications Toolbox	149
Getting Started: Communications	151
Communications Revision History	152
Data Type: SMTP_Data	153
Data Type: FTP_Data	155
Data Type: CircularBufferStruct	156
Data Type: CommStruct	157



Table Of Contents



Data Type: DelimiterArray	158
Data Type: EthernetConfig	159
Data Type: RecipientArray	160
Data Type: RecipientStruct	161
Data Type: SerialConfig	162
Enumerated Type: COM_Type	163
Enumerated Type: Method	164
CommunicationChannel	165
DNS_LookUp	168
FTP_SendFile	175
GetCommand	186
GetParameter	188
InputBufferManager	191
ReName_CommandProcessor	193
ReName_CommunicationsMgr	198
SendEmail	199
UpdatePointer	204
File_RW Toolbox	205
Getting Started: File_RW	206
File_RW Revision History	207
Data Type: ByteBufferStruct	208
Data Type: MyDataStruct	209
Data Type: SeparatorList	210
Read_CSV_File	211
Write_CSV_File	220
Gantry Toolbox	228



Table Of Contents



Getting Started: Gantry	230
Gantry Revision History.....	231
Data Types for Gantry Toolbox.....	233
Data Type: AXIS_REF	234
Data Type: GantryPositions	236
Data Type: GantryStruct	237
Data Type: PathDetails	239
Data Type: PathIDStruct	240
Data Type: PathPairs	241
Data Type: PathPointArray	242
Data Type: PathStruct	243
Data Type: SegmentArray	245
Data Type: SegmentDetails	246
Data Type: SegmentStruct	247
Data Type: WPos	248
Data Type: XPos	249
Data Type: YPos	250
Data Type: ZPos	251
Enumerated Type: TB_PatternType	252
Enumerated Type: TB_PatternType	253
Calculate_Angles.....	254
Gantry_Home	259
Gantry_Power.....	262
Gantry_Return_Home	264
Gantry_Stop.....	266
GotoXY	268



GoToXYZ.....270

GripperControl.....272

Interpolator.....274

Interpolator3D.....276

Move_Path.....278

PathGenerator.....288

PathIDManager.....296

Pick_Part.....299

Place_Part.....301

SegmentLookup.....303

XY_MoveAbsolute.....306

XY_MoveRelative.....309

Math Toolbox.....312

ATAN2.....313

REM.....315

Getting Started: PackML.....317

PackML Revision History.....318

Enumerated Type: PackMLState.....319

Enumerated Type: PackMLState.....321

Data Type: PackML_Commands_STRUCT.....323

Data Type: EquipmentModule_STRUCT.....324

Data Type: PackML_States_STRUCT.....326

Data Type: EquipmentModule_Array.....327

Data Type: UNitMachine_STRUCT.....328

Data Type: PackTags_Admin_STRUCT.....329

Data Type: PackTags_Status_STRUCT.....330



Table Of Contents



Data Type: PackTags_Commands_STRUCT.....	332
Data Type: ControlModule_Array.....	334
Data Type: PackML_Module_Commands_STRUCT.....	335
Data Type: Parameter_STRUCT.....	337
Data Type: Parameter_ARRAY	338
Data Type: ProcessVariable_STRUCT	339
Data Type: ProcessVariable_ARRAY	340
Data Type: Node_STRUCT.....	341
Data Type: Node_ARRAY.....	342
Data Type: Ingredient_STRUCT.....	343
Data Type: Ingredient_ARRAY	344
Data Type: Product_STRUCT	345
Data Type: Product_ARRAY	346
Data Type: Limit_STRUCT	347
Data Type: Limit_ARRAY	348
Supporting Arrays	349
CM_Control_Inputs.....	350
CM_Control_Outputs.....	352
EM_ModuleSummation.....	355
PackMLCommands_Init	357
PackMLModeStateTimes	358
PackML_State_Diagram	361
UN_ModuleSummation.....	368
PLCopen Toolbox.....	370
Getting Started: PLCopen.....	373
PLCopen Revision History	374



Table Of Contents



Data Types for PLCopen Toolbox	383
Data Type: AXIS_REF	384
Data Type: AxisParamData	385
Data Type: AxisParameterStruct	386
Data Type: AxisPrmArray	388
Data Type: AxisStruct	389
Data Type: CAMSWITCH_ARRAY	391
Data Type: CAMSWITCH_REF	392
Data Type: CAMSWITCH_STRUCT	393
Data Type: HomeStruct	395
Data Type: IndividualParamDetails	396
Data Type: LatchBufferArray	397
Data Type: MoveStruct	398
Data Type: ProductBufferStruct	399
Data Type: SWERROR_STRUCT	401
Data Type: TRACK_ARRAY	403
Data Type: TRACK_REF	404
Data Type: TRACK_STRUCT	405
Enumerated Type: MC_Direction	406
Enumerated Type: TB_AxisType	407
AbsolutePositionManager	409
AccDecLimits	412
Axes_Interlock	416
AxisControl	418
AxisStatus	421
ControllerAlarm	423



Table Of Contents



Feed_To_Length	425
HighSpeedOutput	432
Home_Init	435
Home_LS	437
Home_LS_Pulse	440
Home_Pulse	443
Jog	446
Jog_To_Position	449
MoveRelative_ByTime	455
PositionLimits	458
ProductBuffer	462
ReadAxisParameters	468
Reverse_MC_Direction	474
VelocityLimits	476
Y_DigitalCamSwitch	479
Yaskawa Toolbox	488
Getting Started: Yaskawa	490
Yaskawa Revision History	491
ExplicitSendDataStruct	496
ExplicitReceiveDataStruct	498
RegSessionRequestStruct	500
UnRegSessionRequestStruct	502
SenderContext	503
Service	504
ExplicitData	505
Data Types for Yaskawa Toolbox	506



Table Of Contents



Data Type: MovingAverageArray	507
Data Type: PIDStruct.....	508
Data Type: RTCStruct	509
Data Type: XYArray	510
Data Type: XYData.....	511
Data Type: XYDataStruct	512
Action	513
Blink.....	515
ByteSwap.....	517
CommWatchDog	518
DataRecord	519
DataSort	521
DateCompare	523
Enable_FB_Template	524
Enable_ST_Template	525
Execute_FB_Template	526
Execute_ST_Template	528
Explicit_Message.....	530
MovingAverage	535
PackByte.....	538
PackWord.....	540
PIDControl	543
RangeCheck	552
RateCalculator	554
RealTimeClock	556
Scaler	558



Table Of Contents



Sweep	560
UnpackByte	562
UnpackWord	564
WindowCheck	567
XYLookup	569
Function Block ErrorID List	571

Yaskawa's IEC61131-3 Toolboxes: 2013-09-13

Toolbox Introduction



Yaskawa has created several IEC-61131 projects for MotionWorks IEC which can be imported for use by another project as a User Library, or "Toolbox." These toolboxes were designed to save time by providing application code for a wide variety of situations.

- **Cam** toolbox contains functions that increase the power of the PLCopen cam function in the firmware library by providing extras such as functions for calculating motion profiles, making adjustments based on latch inputs, and estop recovery.
- **Communications** toolbox provides advanced communication protocol function blocks (DNS, SMTP, FTP).
- **File Read / Write** toolbox builds upon the basic file manipulation functions available in the ProConOS firmware library to more quickly read and write application data files.
- **Gantry** toolbox provides functions useful for operating an XY table with or without a Z (vertical) axis.
- **Kinematics** toolbox contains forward and inverse kinematics for selected mechanisms.
- **Math** Toolbox provides compatibility with the built in function that include EN and ENO outputs, and also provides other tools such as ATAN2, and Floating Point Remainder (REM).
- **PackML** is both a Template and Toolbox for designing applications to take advantage of the PackML specification. It emphasizes machine state and transition logic and provides predefined PackML data structures.
- **PLCopen** toolbox contains functions that build upon the PLCopen standard functions. It can serve as a starting point for every project.



Cam Toolbox



- **Yaskawa** toolbox contains functions that add basic functionality, such as PID Control, or a Moving Average Filter.

Others coming soon!

A toolbox or user library is just another project. What makes it a user library is the import method. When a project is imported as a user library, only the functions, function blocks and datatypes are available to the main project. None of the hardware specific information of the user library applies.

Please refer to the document [TN.MCD.08.130](http://www.yaskawa.com/TN.MCD.08.130) on www.yaskawa.com for a comprehensive look at how user libraries can increase programming efficiency by reducing development time.

See our [Youtube channel](#) for video tutorials and examples for MotionWorksIEC and many of our toolboxes.



Cam Toolbox

Cam Toolbox

Cam Toolbox contains functions which provide enhanced support of the PLCopen function blocks:

Y_CamStructSelect

Y_CamIn

Y_CamOut

Y_CamShift

Y_SlaveOffset

Y_CamScale

Y_ReleaseCamTable

See the [Cam Toolbox eLearning Modules](#) on Yaskawa's YouTube Channel for video tutorials and examples.

Requirements:

PLCopen Toolbox, Math Toolbox. Some functions such as CamSlaveFeedToLength require the YMotion firmware library.

The Cam Toolbox consists of the following:

Data Types:

Data Type	Description
AXIS_REF	Identifies an axis
AxisParameterStruct	For use with the CamSlave_FeedToLength and CamSlave_WindowCheck function blocks.
BlendStruct	For use with the CamBlend function block
CamPairs	Used by the CamGenerator function block
CamParameters	Supporting structure for CamSegmentStruct. For use with the CamGenerator function block
CamSegmentArray	Supporting structure for CamSegmentStruct. For use with the CamGenerator function block
CamSegmentStruct	For use with the CamGenerator function block



CamStruct	For use with Y_CamIn and Y_CamOut function blocks
CamSyncStruct	For use with the CamControl and CamShift_Control function blocks
Matrix	For use by the CamGenerator for Cubic Spline calculations
SubMatrix	For use by the CamGenerator for Cubic Spline calculations
TablesIDStruct	For use with the CamTableUpdate function block
UINTArray	For use with the CamTableManager Function Block
Y_MS_CAM_STRUCT	For use with the CamGenerator, CamTableUpdate, CamMaster_Lookup, and SlaveIndex_Lookup function blocks.

Enumerated Types:

Enumerated Type	Description
TB_CurveType	For use with the CamSegmentStruct when using the CamGenerator function block
TB_Mode	ENUM Type for CamShift_Control to select rotary or linear slave motion

Function Blocks:

Function Block	Description
CamAnalyzer	Designed to calculate peak velocity, accel/decel and jerk for a given cam profile and master velocity
CamBlend	Designed for applications that require a one way cam profile, and the slave must be able to engage or disengage smoothly from a moving master
CamControl	Used to make a decision on when to engage and disengage a cam for applications where product length or frequency can be variable
CamGenerator	Designed to replicate the functionality of Yaskawa's CamTool software
CamMaster_Lookup	Provides the master position given a slave position by searching the referenced CamTable
CamShift_Control	Calculates shift parameters and performs shifting on the master position
CamSlave_FeedToLength	For use with camming applications that index a slave axis forward in one direction, and require on the fly adjustments of the actual index length based on a sensor input
CamSlave_FeedToLength2	CamSlave_FeedToLength2 is an enhancement of CamSlave_FeedtoLength and uses Y_ProbeContinuous making use of the continuous latch feature of the Sigma-5
CamSlave_Lookup	Returns the array index value corresponding to the given slave position
CamSlave_PullToLength	Designed for applications where the slave mechanism pulls material forward but the mechanism has a reciprocating stroke
CamSlave_Recover	Used to bring the slave axis back in sync with the master axis after



	camming was interrupted unexpectedly
CamSlave_WindowCheck	Used inside CamSlave_FeedToLength to determine when the MC_TouchProbe output is valid and should be used for correction
CamTableManager	Serves as a FIFO buffer for CamTableID's
CamTableUpdate	Aids with cam file management when on the fly changes to the table data are required
SlaveIndex_Lookup	Returns the array index value corresponding to the given slave position
SlaveRegistrationCheck	Uses variables related to a cam slave index and fires the output "MakeCorrection?" which can be connected to Y_SlaveOffset along with the AbsoluteCorrection output. The function also provides the interpolated value of the cam table output when the latch was detected



Getting Started: Cam

Requirements for v204

To use the Cam Toolbox, your project must also contain the following:

Firmware libraries:

- YMotion (only if using [CamSlave FeedToLength2](#))

User libraries:

- Math_Toolbox (v202 or higher)
- DataTypes_Toolbox (v200 or higher)
- PLCopen_Toolbox (v205 or higher)

Using the Cam Toolbox

See Yaskawa's Youtube video - [Camming Demonstration with Yaskawa MP2300Siec](#) for more info.



Cam Revision History

Current Version:

New for Cam v204 – All firmware library DataType definitions were moved to a new toolbox called the DataTypes Toolbox. Formerly, the PLCOpen Toolbox contained the MotionInfoTypes and the PLCTaskInfoTypes datatype files. These were removed and are now included in the DataTypes Toolbox. If upgrading from an older version of Cam Toolbox, you must do the following:

- 1) Include the DataTypes Toolbox in your project.
- 2) Remove any other Yaskawa supplied datatype files with firmware library definitions such as
 - a. ControllInfoTypes
 - b. YDeviceCommTypes

```
(*****                2013-09-01 v204 released. Developed using 2.4.0 firmware
*****)
```

- 1) CamBlend - Added ErrorID 10084. One of the Cam Tables has an invalid TableID. *)
- 2) CamBlend - Fixed ExecuteStandStill contact in RETURN rung to be normally closed. *)
- 3) CamGenerator - Corrected mistake with Tangent Match & Tangent Blend formulas introduced in v202 when CamGenerator was improved to allow blending segments.
- 4) CamBlend - Added check: If BlendData.Window = 0, then the code defaults the value to 1% of the CamMasterCycle.
- 5) CamGenerator - Added curve type 32 for Arc profile. Also added radius and direction to CamSegmentStruct
- 6) Removed references to Math Toolbox functions where possible. Now only the CamShiftControl function block requires the Math Toolbox.
- 7) Because of the reintroduction of functions with EN/ENO, the MP2600 requires firmware 2.1.
- 8) SlaveRegistrationCheck - Added ErrorID 10086 to report if the MaxPosCorrection or MaxNegCorrection are not set correctly.
- 9) CamSlaveFeedToLength - Added RecordedPosition as output. Also included interlock to prevent adjustments from occurring if the slave is not engaged.
- 10) CamGenerator - Added Parabolic with blended velocity as formula code 33. (for multi segment)
- 11) CamShift_Control - Consolidated Rotary Knife and Linear Flying shear math.

Previous Versions:



Cam Toolbox: Revision History



(***** 2013-01-16 v203 released. Created using 2.4.0 firmware
 *****)

- 1) CamGenerator - Improved to support wrap around cubic spline segments at the beginning and the end of the cam. (YEU) 7 spline categories tested.
- 2) CamGenerator - Added TableShift support into the CamSegmentStruct. Initial shifts can be applied to the cam data without using the Y_CamShift function block.

(***** 2012-11-19 v203 created using 2.3.0 firmware
 *****)

- 1) Improved CamGenerator to support wrap around cubic spline segments at the beginning and the end of the cam.
 (YEU) 7 spline categories tested.
- 2) Added TableShift support into the CamSegmentStruct for CamGenerator. Initial shifts can be applied to the data
 without using the Y_CamShift function block.

(***** 2012-10-18 v202 released. Created using 2.2.0 firmware
 *****)

- 1) CamGenerator - Improved to allow blending segments such as straight line, parabolic, modified sine without forcing a zero speed transition.
- 2) CamGenerator - Improved for blending of Cubic Spline segments to other segment types.
- 3) SlaveRegistrationCheck - Changed 'Missed Latch Error' to occur when the missed latch counter is \geq the MissedLatchLimit. Previously it was not causing error until the MissedLatchLimit was exceeded.
- 4) CamBlend - Added DisengageData to CamBlend's Y_CamOut for compatibility on MP2600iec and MP3200iec

(***** 2011-03-09 v201 released. Created using 2.1.0 firmware
 *****)

- 1) CamGenerator - Added Cubic Spline CurveType as Type #31
- 2) CamAnalyzer - Added new function block



Cam Toolbox: Revision History



- 3) CamFileMgmt - CamTableMgmt renamed CamTableManager
- 4) CamSlave_Lookup - Fixed false 10113 ErrorID from occurring
- 5) CamSlave_Recover - Fixed unconnected line in the first rung
- 6) DataTypes - Increased CamPair and CamSegmentArray from 200 to 400

(***** 2011-07-29 v200 released. Created using 2.0.0 firmware
 *****)

- 1) Built from v009beta for MotionWorks IEC 2.0

(***** 2011-04-02 v009 released. Created using 1.2.4 firmware
 *****)

- 1) Added CamSlave_Lookup and CamSlave_Recover function blocks for e-stop recovery capability.
- 2) Added input 'ExecuteStandstill' to CamBlend. This input causes the running cam to engage immediately, which enhances the E-Stop recovery capability of CamBlend.
- 3) Removed SETCOIL from CamBlend CommandAborted.

(***** 2011-04-01 v008 released. Created using 1.2.4 firmware
 *****)

- 1) Fixed Y_CamStructSelect in PathGenerator to comply with PLCopen rule to read TableID only on the scan.
 when done is high. (Also to comply with firmware change made for 1.2.3.)
- 2) Reworked PathGenerator to support any variety of arcs beyond just simple 0,90,180,270 quadrants.
- 3) Removed spaces from project file name for improved usage with MotionWorks IEC 2.0.
- 4) Removed PathGenerator and MovePath, ported over to Gantry Toolbox
- 5) Included YMotion firmware library in ZWT, required for CamSlaveFeedToLength2 function block.

NOTE: This toolbox will work with 1.2.3 firmware unless CamSlaveFeedToLength2 is used, which requires firmware 1.2.4.

- 6) Improved CamBlend's CommandAborted output behavior to ignore Commandaborted caused by itself.



(***** 2011-02-02 v007 released
*****)

1) Fixed incorrect parameter in CamBlend for checking the half way point of the cam cycle.

Step 5 had 1520, it is changed to 1512. Also streamlined the code to only include one check for Halfway instead of two.

2) Added CamSlaveFeedToLength2, which incorporates Y_ProbeContinuous from the Y_Motion firmware library and

requires firmware 1.2.4 or higher. NOTE: After the 2.0 product release, Y_ProbeContinuous will be available in

PLCopenPlus firmware library v2_3.

(***** 2010-11-15 v006 released
*****)

Moved on to v006, beta005 never released.

1) Increased flexibility of CamSlave_FeedToLength / SlaveRegistrationCheck by making Max Positive and Negative Correction

inputs and outputs.

2) Added CamShift_Control FB for 'Rotary' and 'Out and Back' cam motions.

3) Added TB_CurveType#Polynomial345 to CamGenerator, Polynomial345.

4) Added Cam_Control FB which works with the Product Buffer for slaves that must stop when no product is coming.

(***** 2010-08-01 v005beta created
*****)

Moved on to v005, beta004 never released.

1) Merged code changes with Doug Meyer, for CamSlavePullToLength and CamSlaveFeedToLength for MaxCorrection

and Time based correction. NOTE: Function block interface changed for these functions.

2) Removed LatchError from occurring in CamSlavePullToLength and CamSlaveFeedToLength.



3) Moved window logic into the main Enable section of SlaveRegistrationCheck to allow on the fly updates.

(***** 2010-07-02 v004beta created
*****)

Moved on to v004, beta003 never released.

1) Added logic to SlaveRegistrationCheck to add one CamCycle if the LatchTableReference is negative.

(***** 2010-03-15 v003beta created
*****)

1) Fixed mistake in case statement to allow Simple Harmonic as one of the Valid Curve Types. Was 4, should be 3.

2) Changed Max CamSegmentArray size to 200 from 20.

3) Changed CamSlave_FeedToLength to use Stair Step method of latch lookup in cam table. Original method used an

interpolated latch algorithm.

4) Removed Y_EngageMethod#Linked as a StartMode inside CamBlend.

5) Changed the second and third Y_CamIn functions inside CamBlend to use StartMode = Absolute to eliminate drifting

caused by switching tables while master in motion.

6) Added NOT(Error) contact to prevent the CamSlave_FeedToLength function from running if there was an error.

7) Added PathGenerator and MovePath for creating XY paths with straight line and circular interpolation.

8) Added CamSlavePullToLength and supporting function CS_PTL_ScaleCalc.

(***** 2010-03-12 v002 released
*****)

1) Changed CamGenerator straight line segment to include option for calculating points at spec'ed resolution.

2) Initial version would ignore resolution and just use beginning and end points for straight line.

3) Improved CamGenerator. It was recalculating the entire profile over and over each scan while execute was held high.



Cam Toolbox: Revision History



Changed to F_TRIG to let initialize section run on the first scan, and the cam calcs on the second.

- 4) Improved CamBlend Output behavior. (Some bits remained on when both execute inputs were off.

```
(***** 2010-02-01 v001beta created  
*****)
```

Created Cam Toolbox by moving the following Function blocks from PLCopen Toolbox v019beta:

- 1) CamBlend
- 2) CamMaster_Lookup
- 3) CamSlave_FeedToLength
- 4) CamSlave_WindowCheck
- 5) CamGenerator
- 6) CamTableUpdate
- 7) SlaveRegistrationCheck
- 8) SlaveIndex_Lookup



Creating Cam Tables

Cam Curve Characteristics

Cam Curve does not mean a shape curve which expresses a cam profile, but rather a “motion curve” of the follower moved by the cam. A motion curve is generally shown with time on the horizontal axis and displacement on the vertical axis. The purpose of a cam is to move an object smoothly in a minimum time, without vibration and with minimum power. For this purpose, various motion curves have been developed.

These curves are not only used for cam mechanisms but can also be applied to various other motions. The maximum non dimensional values such as V_m , A_m , and J_m are called the characteristic values of the cam curve. From these characteristic values and from the shapes of the acceleration curves, the general properties of the cam curves can be known.

Curve Selection

The procedure for selecting a curve is as follows:

1. Velocity V and Acceleration A are to be continuous
2. Low values of V_m and Q_m are needed in low speed and heavy load applications.
3. Low values of A_m and J_m are needed in high speed and light load applications.
4. Asymmetrical curve having the longer period of deceleration than acceleration should be used for situations when positioning accuracy is critical and residual vibration must be avoided.
5. A one-dwell curve should be used when the motion has no stop at the endpoint and must return immediately.
6. Select a curve from the modified constant velocity group when constant velocity is required in the middle part of the stroke.
7. Select a curve from the modified trapezoid group when acceleration is to be minimized.
8. The modified sine curve is recommended if there are no limitations.



Cam Curve Characteristics

Sorted by velocity

Curve	Velocity Max	Accel Max	Accel Min	Jerk Max	Jerk Min	Inertia Torque Max	Comment
No Dwell Modified Constant Velocity	1.22	7.68	7.68	48.20	-48.20	4.69	Lowest Velocity
Modified Constant Velocity	1.28	8.01	8.01	201.40	-67.10	5.73	Highest Accel
Simple Harmonic	1.57	4.93	4.93	∞	-15.50	3.88	Lowest Inertial Torque
One Dwell Modified Sine	1.66	5.21	5.21	65.50	-21.80	4.86	
One Dwell Cycloidal (m=2/3)	1.72	6.75	-4.50	53.00	-53.00	7.53	
No Dwell Modified Trapezoid	1.72	4.20	4.20	26.40	-26.40	5.07	Lowest Jerk
One Dwell Trapezoid	1.74	4.91	4.91	61.70	-61.70	6.86	
Modified Sine	1.76	5.53	-5.53	69.50	-23.20	5.46	
One Dwell Cycloidal (m=1)	1.76	5.53	5.53	34.70	-34.70	6.32	
NC2 Curve	1.79	5.89	-4.21	∞	-111.10	8.87	
One Dwell Modified Trapezoid (m=1)	1.92	4.44	-4.44	55.80	-55.80	7.11	
One Dwell Modified Trapezoid (Ferguson)	1.92	4.68	-4.22	58.90	-58.90	7.43	
One Dwell Modified Trapezoid (m=2/3)	1.94	5.53	-3.68	69.40	-69.40	8.63	
Parabolic	2.00	4.00	-4.00	∞	∞	8.00	Lowest Accel, Highest Jerk
Cycloidal	2.00	6.28	6.28	39.50	-39.50	8.16	
Modified Trapezoid	2.00	4.89	4.89	61.40	-61.40	8.09	
Asymmetrical Cycloidal	2.00	7.85	-5.24	61.70	-61.70	10.20	
Asymmetrical Modified Trapezoid	2.00	6.11	-4.07	96.00	-96.00	10.11	
Trapezoid	2.18	6.17	6.17	77.50	-77.50	10.84	Highest Velocity, Highest Inertial Torque

Cam Curve Characteristics

Sorted by Positive Acceleration

Curve	Velocity Max	Accel Max	Accel Min	Jerk Max	Jerk Min	Inertia Torque Max	Comment
No Dwell Modified Trapezoid	1.72	4.20	4.20	26.40	-26.40	5.07	Lowest Jerk
One Dwell Cycloidal (m=1)	1.76	5.53	5.53	34.70	-34.70	6.32	
Cycloidal	2.00	6.28	6.28	39.50	-39.50	8.16	
No Dwell Modified Constant Velocity	1.22	7.68	7.68	48.20	-48.20	4.69	Lowest Velocity
One Dwell Cycloidal (m=2/3)	1.72	6.75	-4.50	53.00	-53.00	7.53	
One Dwell Modified Trapezoid (m=1)	1.92	4.44	-4.44	55.80	-55.80	7.11	
One Dwell Modified Trapezoid (Ferguson)	1.92	4.68	-4.22	58.90	-58.90	7.43	
Modified Trapezoid	2.00	4.89	4.89	61.40	-61.40	8.09	
One Dwell Trapezoid	1.74	4.91	4.91	61.70	-61.70	6.86	
Asymmetrical Cycloidal	2.00	7.85	-5.24	61.70	-61.70	10.20	
One Dwell Modified Sine	1.66	5.21	5.21	65.50	-21.80	4.86	
One Dwell Modified Trapezoid (m=2/3)	1.94	5.53	-3.68	69.40	-69.40	8.63	
Modified Sine	1.76	5.53	-5.53	69.50	-23.20	5.46	
Trapezoid	2.18	6.17	6.17	77.50	-77.50	10.84	Highest Velocity, Highest Inertial Torque
Asymmetrical Modified Trapezoid	2.00	6.11	-4.07	96.00	-96.00	10.11	
Modified Constant Velocity	1.28	8.01	8.01	201.40	-67.10	5.73	Highest Accel
Parabolic	2.00	4.00	-4.00	∞	∞	8.00	Lowest Accel, Highest Jerk
Simple Harmonic	1.57	4.93	4.93	∞	-15.50	3.88	Lowest Inertial Torque
NC2 Curve	1.79	5.89	-4.21	∞	-111.10	8.87	



Cam Curve Characteristics							
Sorted by Positive Jerk							
Curve	Velocity Max	Accel Max	Accel Min	Jerk Max	Jerk Min	Inertia Torque Max	Comment
No Dwell Modified Trapezoid	1.72	4.20	4.20	26.40	-26.40	5.07	Lowest Jerk
One Dwell Cycloidal (m=1)	1.76	5.53	5.53	34.70	-34.70	6.32	
Cycloidal	2.00	6.28	6.28	39.50	-39.50	8.16	
No Dwell Modified Constant Velocity	1.22	7.68	7.68	48.20	-48.20	4.69	Lowest Velocity
One Dwell Cycloidal (m=2/3)	1.72	6.75	-4.50	53.00	-53.00	7.53	
One Dwell Modified Trapezoid (m=1)	1.92	4.44	-4.44	55.80	-55.80	7.11	
One Dwell Modified Trapezoid (Ferguson)	1.92	4.68	-4.22	58.90	-58.90	7.43	
Modified Trapezoid	2.00	4.89	4.89	61.40	-61.40	8.09	
One Dwell Trapezoid	1.74	4.91	4.91	61.70	-61.70	6.86	
Asymmetrical Cycloidal	2.00	7.85	-5.24	61.70	-61.70	10.20	
One Dwell Modified Sine	1.66	5.21	5.21	65.50	-21.80	4.86	
One Dwell Modified Trapezoid (m=2/3)	1.94	5.53	-3.68	69.40	-69.40	8.63	
Modified Sine	1.76	5.53	-5.53	69.50	-23.20	5.46	
Trapezoid	2.18	6.17	6.17	77.50	-77.50	10.84	Highest Velocity, Highest Inertial Torque
Asymmetrical Modified Trapezoid	2.00	6.11	-4.07	96.00	-96.00	10.11	
Modified Constant Velocity	1.28	8.01	8.01	201.40	-67.10	5.73	Highest Accel
Parabolic	2.00	4.00	-4.00	∞	∞	8.00	Lowest Accel, Highest Jerk
Simple Harmonic	1.57	4.93	4.93	∞	-15.50	3.88	Lowest Inertial Torque
NC2 Curve	1.79	5.89	-4.21	∞	-111.10	8.87	

Cam Curve Characteristics							
Sorted by Combined Score Rank							
Curve	Velocity Max	Accel Max	Accel Min	Jerk Max	Jerk Min	Inertia Torque Max	Comment
No Dwell Modified Trapezoid	1.72	4.20	4.20	26.40	-26.40	5.07	Lowest Jerk
One Dwell Modified Trapezoid (m=1)	1.92	4.44	-4.44	55.80	-55.80	7.11	
One Dwell Cycloidal (m=1)	1.76	5.53	5.53	34.70	-34.70	6.32	
No Dwell Modified Constant Velocity	1.22	7.68	7.68	48.20	-48.20	4.69	Lowest Velocity
One Dwell Trapezoid	1.74	4.91	4.91	61.70	-61.70	6.86	
One Dwell Modified Trapezoid (Ferguson)	1.92	4.68	-4.22	58.90	-58.90	7.43	
One Dwell Modified Sine	1.66	5.21	5.21	65.50	-21.80	4.86	
One Dwell Cycloidal (m=2/3)	1.72	6.75	-4.50	53.00	-53.00	7.53	
Modified Trapezoid	2.00	4.89	4.89	61.40	-61.40	8.09	
Simple Harmonic	1.57	4.93	4.93	∞	-15.50	3.88	Lowest Inertial Torque
Modified Sine	1.76	5.53	-5.53	69.50	-23.20	5.46	
Parabolic	2.00	4.00	-4.00	∞	∞	8.00	Lowest Accel, Highest Jerk
Cycloidal	2.00	6.28	6.28	39.50	-39.50	8.16	
One Dwell Modified Trapezoid (m=2/3)	1.94	5.53	-3.68	69.40	-69.40	8.63	
Modified Constant Velocity	1.28	8.01	8.01	201.40	-67.10	5.73	Highest Accel
NC2 Curve	1.79	5.89	-4.21	∞	-111.10	8.87	
Asymmetrical Modified Trapezoid	2.00	6.11	-4.07	96.00	-96.00	10.11	
Asymmetrical Cycloidal	2.00	7.85	-5.24	61.70	-61.70	10.20	
Trapezoid	2.18	6.17	6.17	77.50	-77.50	10.84	Highest Velocity, Highest Inertial Torque



Cam Curve Types

Cam Curve Types

- [Parabolic](#)
- [Simple Harmonic](#)
- [Cycloidal](#)
- [Modified Trapezoid](#)
- [Modified Sine](#)
- [Modified Constant Velocity](#)
- [Asymmetrical Cycloidal](#)
- [Asymmetrical Modified Trapezoid](#)
- [Trapezoid](#)
- [One Dwell Cycloidal 1](#)
- [One Dwell Cycloidal 2 3](#)
- [One Dwell Trapezoid 1](#)
- [One Dwell Trapezoid](#)
- [One Dwell Trapezoid 2 3](#)
- [One Dwell Modified Sine](#)
- [One Dwell Trapezoid](#)
- [No Dwell Simple Harmonic](#)
- [No Dwell Modified Trapezoid](#)
- [No Dwell Modified Constant Velocity](#)
- [NC2 Curve](#)
- [Tangent Matching](#)
- [Reverse Trapezoid](#)
- [Double Harmonic](#)
- [Reverse Double Harmonic](#)
- [Tangent Blending](#)
- [Arc](#)
- [Cubic Spline](#)



Cam Toolbox: Cam Tables and Curves

- [ParabolicVelocityBlend](#)






Parabolic


Designed for use as the only segment in the motion profile when a axis must be indexed. This curve has the feature that the non dimensional maximum acceleration A_m is the minimum ($A_m=4$) among all curves.

Downside – Can cause vibration. Modified Trapezoid is better.






ParabolicVelocityBlend






Simple Harmonic

This curve is also one of the discontinuous curves that easily causes vibration, but since it has smooth and good (low) properties, it can be used for low speed applications. When this curve is used for no-dwell applications, (out & back) the discontinuity of acceleration at the starting and end points is not a factor and then this curve is regarded as the best curve for no-dwell use. The modified sine curve is considered an improvement over the simple harmonic.






Cycloidal






Modified Trapezoid






Modified Sine





Modified Constant Velocity






Arc

The CamSegmentStruct elements ArcRadius and ArcDirection must be declared for proper usage of this curve type.






Asymmetrical Cycloidal






Asymmetrical Modified Trapezoid






Trapezoid






One Dwell Cycloidal_1






One Dwell Cycloidal_2_3






One Dwell Trapezoid_1






One Dwell Trapezoid






One Dwell Trapezoid_2_3






One Dwell Modified Sine






One Dwell Trapezoid






No Dwell Simple Harmonic






No Dwell Modified Trapezoid






No Dwell Modified Constant Velocity





NC2 Curve

Notes: Deceleration is twice as long as acceleration, which provides the effect of restricting vibration.





Tangent Matching


Provides a speed matched profile to minimize jerk between segments. Matches to the previous and next segment. In the case of the Tangent match segment coming first or last, a wraparound match is calculated. A straight line segment is required before and after the tangent match segment.

```

0.000   CamTool.SlaveStart:=LREAL#0.0;
      2   CamTool.LastSegment:=INT#2;
      1   CamTool.CamParameters[1].CurveType:=INT#1;
180.000 CamTool.CamParameters[1].MasterEnd:=LREAL#180.0;
      0.250 CamTool.CamParameters[1].SlaveEnd:=LREAL#0.25;
      0.500 CamTool.CamParameters[1].Resolution:=REAL#0.5;

      22   CamTool.CamParameters[2].CurveType:=INT#22;
360.000 CamTool.CamParameters[2].MasterEnd:=LREAL#360.0;
      1.000 CamTool.CamParameters[2].SlaveEnd:=LREAL#1.0;
      0.500 CamTool.CamParameters[2].Resolution:=REAL#0.5;

```





Cam Toolbox: Cam Tables and Curves



```


0.000 CamTool.SlaveStart:=LREAL#0.0;
4 CamTool.LastSegment:=INT#4;
1 CamTool.CamParameters[1].CurveType:=INT#1;
45.000 CamTool.CamParameters[1].MasterEnd:=LREAL#45.0;
0.250 CamTool.CamParameters[1].SlaveEnd:=LREAL#0.25;
0.500 CamTool.CamParameters[1].Resolution:=REAL#0.5;

22 CamTool.CamParameters[2].CurveType:=INT#22;
90.000 CamTool.CamParameters[2].MasterEnd:=LREAL#90.0;
1.000 CamTool.CamParameters[2].SlaveEnd:=LREAL#1.0;
0.500 CamTool.CamParameters[2].Resolution:=REAL#0.5;

1 CamTool.CamParameters[3].CurveType:=INT#1;
270.000 CamTool.CamParameters[3].MasterEnd:=LREAL#270.0;
4.500 CamTool.CamParameters[3].SlaveEnd:=LREAL#4.5;
0.500 CamTool.CamParameters[3].Resolution:=REAL#0.5;

22 CamTool.CamParameters[4].CurveType:=INT#22;
360.000 CamTool.CamParameters[4].MasterEnd:=LREAL#360.0;
3.000 CamTool.CamParameters[4].SlaveEnd:=LREAL#3.0;
0.500 CamTool.CamParameters[4].Resolution:=REAL#0.5;

```





Reverse Trapezoid

This cam curve type is not currently supported.



Double Harmonic

This cam curve type is not currently supported.



Reverse Double Harmonic

This cam curve type is not currently supported.




Tangent Blending

Provides the same profile as [Tangent Matching](#), but designed for use with the [CamBlend](#) function block. The difference between this and Tangent Matching is how the matching velocity is determined. For this formula type, two segments are required: a straight line and a tangent blend. Which segment comes first dictates whether a “blend in” or “blend out” or blend out profile is created.

See [CamBlend](#) function block for application examples



Cubic Spline



In this example, the left or beginning portion of a motion profile was created using the cubic spline formula. The right or end portion of the cycle includes two modified sine motions.

The CamData values are shown below:

(* test cubic spline *)

Profile4.SlaveStart:=LREAL#44.0; (* The slaves initial and final position is not zero, it is 44.0 *)

seg:=INT#1;

Profile4.CamParameters[Seg].CurveType:=TB_CurveType#StraightLine;

Profile4.CamParameters[Seg].MasterEnd:=LREAL#15.0;

Profile4.CamParameters[Seg].SlaveEnd:=LREAL#44.0;

Profile4.CamParameters[Seg].Resolution:=REAL#0.0;



```
seg:=Seg + INT#1;
```

```
Profile4.CamParameters[Seg].CurveType:=TB_CurveType#CubicSpline;
```

```
Profile4.CamParameters[Seg].MasterEnd:=LREAL#17.0;
```

```
Profile4.CamParameters[Seg].SlaveEnd:=LREAL#43.9614;
```

```
Profile4.CamParameters[Seg].Resolution:=REAL#1.0;
```

```
seg:=Seg + INT#1;
```

```
Profile4.CamParameters[Seg].CurveType:=TB_CurveType#CubicSpline;
```

```
Profile4.CamParameters[Seg].MasterEnd:=LREAL#25.5;
```

```
Profile4.CamParameters[Seg].SlaveEnd:=LREAL#40.3036;
```

```
Profile4.CamParameters[Seg].Resolution:=REAL#1.0;
```

```
seg:=Seg + INT#1;
```

```
Profile4.CamParameters[Seg].CurveType:=TB_CurveType#CubicSpline;
```

```
Profile4.CamParameters[Seg].MasterEnd:=LREAL#34.0;
```

```
Profile4.CamParameters[Seg].SlaveEnd:=LREAL#30.4425;
```

```
Profile4.CamParameters[Seg].Resolution:=REAL#1.0;
```

```
seg:=Seg + INT#1;
```

```
Profile4.CamParameters[Seg].CurveType:=TB_CurveType#CubicSpline;
```

```
Profile4.CamParameters[Seg].MasterEnd:=LREAL#42.5;
```

```
Profile4.CamParameters[Seg].SlaveEnd:=LREAL#19.6003;
```

```
Profile4.CamParameters[Seg].Resolution:=REAL#1.0;
```

```
seg:=Seg + INT#1;
```



Cam Toolbox: Cam Tables and Curves



```
Profile4.CamParameters[Seg].CurveType:=TB_CurveType#CubicSpline;
```

```
Profile4.CamParameters[Seg].MasterEnd:=LREAL#43.0;
```

```
Profile4.CamParameters[Seg].SlaveEnd:=LREAL#19.0;
```

```
Profile4.CamParameters[Seg].Resolution:=REAL#1.0;
```

```
seg:=Seg + INT#1;
```

```
Profile4.CamParameters[Seg].CurveType:=TB_CurveType#CubicSpline;
```

```
Profile4.CamParameters[Seg].MasterEnd:=LREAL#51.0;
```

```
Profile4.CamParameters[Seg].SlaveEnd:=LREAL#10.0305;
```

```
Profile4.CamParameters[Seg].Resolution:=REAL#1.0;
```

```
seg:=Seg + INT#1;
```

```
Profile4.CamParameters[Seg].CurveType:=TB_CurveType#CubicSpline;
```

```
Profile4.CamParameters[Seg].MasterEnd:=LREAL#59.5;
```

```
Profile4.CamParameters[Seg].SlaveEnd:=LREAL#3.5477;
```

```
Profile4.CamParameters[Seg].Resolution:=REAL#1.0;
```

```
seg:=Seg + INT#1;
```

```
Profile4.CamParameters[Seg].CurveType:=TB_CurveType#CubicSpline;
```

```
Profile4.CamParameters[Seg].MasterEnd:=LREAL#68.0;
```

```
Profile4.CamParameters[Seg].SlaveEnd:=LREAL#0.6464;
```

```
Profile4.CamParameters[Seg].Resolution:=REAL#1.0;
```

```
seg:=Seg + INT#1;
```

```
Profile4.CamParameters[Seg].CurveType:=TB_CurveType#CubicSpline;
```

```
Profile4.CamParameters[Seg].MasterEnd:=LREAL#76.5;
```



Cam Toolbox: Cam Tables and Curves



```
Profile4.CamParameters[Seg].SlaveEnd:=LREAL#0.005;
```

```
Profile4.CamParameters[Seg].Resolution:=REAL#1.0;
```

```
seg:=Seg + INT#1;
```

```
Profile4.CamParameters[Seg].CurveType:=TB_CurveType#CubicSpline;
```

```
Profile4.CamParameters[Seg].MasterEnd:=LREAL#85.0;
```

```
Profile4.CamParameters[Seg].SlaveEnd:=LREAL#0.0;
```

```
Profile4.CamParameters[Seg].Resolution:=REAL#1.0;
```

```
seg:=Seg + INT#1;
```

```
Profile4.CamParameters[Seg].CurveType:=TB_CurveType#StraightLine;
```

```
Profile4.CamParameters[Seg].MasterEnd:=LREAL#220.0;
```

```
Profile4.CamParameters[Seg].SlaveEnd:=LREAL#0.0;
```

```
Profile4.CamParameters[Seg].Resolution:=REAL#0.0;
```

```
seg:=Seg + INT#1;
```

```
Profile4.CamParameters[Seg].CurveType:=TB_CurveType#ModifiedSine;
```

```
Profile4.CamParameters[Seg].MasterEnd:=LREAL#250.0;
```

```
Profile4.CamParameters[Seg].SlaveEnd:=LREAL#14.7;
```

```
Profile4.CamParameters[Seg].Resolution:=REAL#1.0;
```

```
seg:=Seg + INT#1;
```

```
Profile4.CamParameters[Seg].CurveType:=TB_CurveType#StraightLine;
```

```
Profile4.CamParameters[Seg].MasterEnd:=LREAL#310.0;
```

```
Profile4.CamParameters[Seg].SlaveEnd:=LREAL#14.7;
```

```
Profile4.CamParameters[Seg].Resolution:=REAL#1.0;
```



```
seg:=Seg + INT#1;
```

```
Profile4.CamParameters[Seg].CurveType:=TB_CurveType#ModifiedSine;
```

```
Profile4.CamParameters[Seg].MasterEnd:=LREAL#348.0;
```

```
Profile4.CamParameters[Seg].SlaveEnd:=LREAL#44.0;
```

```
Profile4.CamParameters[Seg].Resolution:=REAL#1.0;
```

```
seg:=Seg + INT#1;
```

```
Profile4.CamParameters[Seg].CurveType:=TB_CurveType#ModifiedSine;
```

```
Profile4.CamParameters[Seg].MasterEnd:=LREAL#360.0;
```

```
Profile4.CamParameters[Seg].SlaveEnd:=LREAL#44.0;
```

```
Profile4.CamParameters[Seg].Resolution:=REAL#1.0;
```

```
Profile4.LastSegment:=Seg;
```



Data Types

Data Types for Cam Toolbox

The following is a complete list of all DataTypes included in the Cam Toolbox. The list is arranged to separate those that are used internally, and not useful outside of their particular function, and those that an application program must incorporate when the programmer wishes to use the associated Function Block.

Data Type	Usage
DataTypes for use with function blocks in the PLCopen Plus firmware library	
CamStruct	For use with Y_CamIn and Y_CamOut function blocks
DataTypes for external use with Cam Toolbox function blocks	
AXIS_REF	Identifies an axis
AxisParamStruct	For use with the CamSlave_FeedToLength and CamSlave_WindowCheck function blocks.
BlendStruct	For use with the CamBlend function block
CamSegmentStruct	For use with the CamGenerator function block
CamSyncStruct	For use with CamControl and CamShift_Control function blocks
TableIDStruct	For use with the CamTableUpdate function block
TB_CurveType	ENUM type for describing the cam formula to be used.
UINTArray	For use with the CamTableManager Function Block
Y_MS_CAM_STRUCT	For use with the CamGenerator, CamTableUpdate, CamMaster_Lookup, and SlaveIndex_Lookup function blocks.
DataTypes that support other DataTypes (no need for direct use by the application programmer)	
CamParameters	Supporting structure for CamSegmentStruct. For use with the CamGenerator function block
CamSegmentArray	Supporting structure for CamSegmentStruct. For use with the CamGenerator function block
DataTypes used internally by Cam Toolbox function blocks	
CamPairs	Used by the CamGenerator function block
Matrix	For use by the CamGenerator for Cubic Spline calculations
SubMatrix	For use by the CamGenerator for Cubic Spline calculations



Data Type: AXIS_REF

The AXIS_REF data type identifies an axis and thus provides the interface to the hardware or virtual axes. AXIS_REF is used as VAR_IN_OUT in all Motion Control Function Blocks described in this Online help. It is represented as an input and an output connected by a horizontal line in the graphical representation of a function block.

The value of AxisNum is determined by the logical axis number assigned in the Hardware Configuration. See the Configuration tab under each axis.

Data Type Declaration

```

TYPE
  AXIS_REF:STRUCT
    AxisNum:UINT;    (* Logical axis number *)
  END_STRUCT;
END_TYPE

```

Variable Declaration Example

Name	Type	Usage
Default		
MC_ReadActualPosition_1	MC_ReadActual...	VAR
FeedAxis	AXIS_REF	VAR_EXTER...
AlwaysTrue	AXIS_REF	ER...
ReadActualPosValid1	BOOL	ER...
ReadActualPosBusy1	BYTE	ER...
ReadActualPosError1	CTD	ER...
ReadActualPosErrorID1	CTU	ER...
ReadActualPosPosition1	CTUD	ER...
ActualPosition1	REAL	VAR_EXTER...
MC_ReadActualVelocity_1	MC_ReadActual...	VAR
ReadActualVelValid1	BOOL	VAR_EXTER...

Code Example

```

AxisX.Number:=UINT#0;
MCMoveAbsoluteX(Axis:=AxisX, Execute:=FALSE);
AxisX:=MCMoveAbsolutX.Axis;
AxisY.Number:=UINT#0;

```



Cam Toolbox: DataTypes

```
MCMoveAbsoluteY(Axis:=AxisY, Execute:=FALSE);  
AxisX:=MCMoveAbsoluteY.Axis;
```





Data Type: AxisParameterStruct

For use with the [CamSlave FeedToLength](#) and [CamSlave WindowCheck](#) function blocks.

Data Type Declaration

TYPE

AxisParameterStruct:STRUCT

ActualPosition:LREAL; (* 1000 *)
ActualPositionCyclic:LREAL; (* 1005 *)
ActualPositionNonCyclic:LREAL; (* 1006 *)
ActualTorque:LREAL; (* 1004 *)
ActualVelocity:LREAL; (* 1001 *)
AtVelocity:BOOL; (* 1141 *)
BufferedMotionBlocks:LREAL; (* 1600 *)
CamMasterCycle:LREAL; (* 1512 *)
CamMasterPosition:LREAL; (* 1500 *)
CamMasterShiftedCyclic:LREAL; (* 1502 *)
CamMasterShiftedPosition:LREAL; (* 1501 *)
CamMasterScale:LREAL; (* 1510 *)
CamMasterShift:LREAL; (* 1511 *)
CamOffset:LREAL; (* 1531 *)
CamScale:LREAL; (* 1530 *)
CamShiftRemaining:LREAL; (* 1513 *)
CamState:LREAL; (* 1540 *)
CamTableIDEngaged:LREAL; (* 1541 *)
CamTableOutput:LREAL; (* 1520 *)
CommandedAcceleration:LREAL; (* 1012 *)



Cam Toolbox: DataTypes



```
CommandedPosition:LREAL;      (* 1010 *)  
  
CommandedPositionCyclic:LREAL;  (* 1015 *)  
  
CommandedPositionNonCyclic:LREAL; (* 1016 *)  
  
CommandedTorque:LREAL;        (* 1014 *)  
  
CommandedVelocity:LREAL;      (* 1011 *)  
  
InPosition:BOOL;             (* 1140 *)  
  
LatchPositionNonCyclic:LREAL;  (* 1031 *)  
  
PositionError:LREAL;         (* 1130 *)  
  
PositionWindow:LREAL;        (* 1120 *)  
  
END_STRUCT;  
  
END_TYPE
```



Data Type: BlendStruct

Used by the [CamBlend](#) function block

Data Type Declaration

TYPE

RampInTableID:UINT; (* TableID of the Cam profile that is used to ramp up (accelerate) to the master speed *)

RampInSwitchOverPos:LREAL; (* Specify a position where the slave would be at the same position in both the RampIn and Running table, typically near the last 90 to 100% of the profile *)

RunningTableID:UINT; (* TableID of the Cam profile that is used in normal operation *)

StandStillEngagePos:LREAL; (* This input can be used if the slave is being engaged to the master at standstill. (E-Stop recovery where the slave engages to a stationary master).

(* This input will engage the slave to the running table *)

RampOutTableID:UINT; (* TableID of the Cam profile that is used to ramp out (decelerate) to zero speed *)

RampOutSwitchOverPos:LREAL; (* Specify a position where the slave would be at the same position in both the RampIn and Running table, typically near the last 90 to 100% of the profile *)

Window:LREAL; (* Switchover / Engage window *)

END_TYPE



Data Type: CamPairs

Used by the [CamGenerator](#) function block

Data Type Declaration

```
TYPE
```

```
CamPairs: ARRAY[0..20] OF UDINT;
```

```
END_TYPE
```



Data Type: CamParameters

Supporting structure for [CamSegmentStruct](#). For use with the [CamGenerator](#) function block.

Data Type Declaration

```
TYPE
```

```
CamParameters:STRUCT
```

```
MasterEnd:LREAL; (* Location of the master at the end of the current segment *)
```

```
SlaveEnd:LREAL; (* Location of the slave at the end of the current segment *)
```

```
CurveType:INT; (* Formula code to indicate the motion profile for this segment *)
```

```
Resolution:REAL; (* Determines how many data points are calculated along this segment. *)
```

```
    (* If the master delta from the previous segment is 10.0, and the resolution *)
```

```
    (* is set to 0.5, then 20 datapoints will be generated for this segment. *)
```

```
END_STRUCT;
```

```
END_TYPE
```



Data Type: CamSegmentArray

Supporting structure for [CamSegmentStruct](#). For use with the [CamGenerator](#) function block.

Data Type Declaration

TYPE

CamSegmentArray: ARRAY[0..200] OF [CamParameters](#);

END_TYPE



Data Type: CamSegmentStruct

For use with the [CamGenerator](#) function block.

Data Type Declaration

TYPE

CamSegmentStruct: STRUCT

CamParameters: [CamSegmentArray](#);

SlaveStart: LREAL;

LastSegment: INT;

ArcRadius: LREAL; (* Only used with 'Arc' CurveType *)

ArcDirection: INT; (* 1: ccw, -1: cw *) (* Only used with 'Arc' CurveType *)

END_STRUCT;

END_TYPE

Example

```
RampInCam.SlaveStart:=LREAL#0.5;      (*Slave home position at 12 O'Clock *)
```

```
RampInCam.LastSegment:=INT#2;
```

```
RampInCam.CamParameters[1].CurveType:=TB_CurveType#TangentBlending;
```

```
RampInCam.CamParameters[1].MasterEnd:=LREAL#0.9;
```

```
RampInCam.CamParameters[1].SlaveEnd:=LREAL#0.9; (* Slave moves SlaveEnd - SlaveStart during RampIn *)
```

```
RampInCam.CamParameters[1].Resolution:=REAL#0.01;
```

```
RampInCam.CamParameters[2].CurveType:=TB_CurveType#StraightLine;
```

```
RampInCam.CamParameters[2].MasterEnd:=LREAL#1.0;
```



Cam Toolbox: DataTypes

RampInCam.CamParameters[2].SlaveEnd:=LREAL#1.0;

RampInCam.CamParameters[2].Resolution:=REAL#0.01;





Data Type: CamStruct

For use with Y_CamIn and Y_CamOut function blocks

Data Type Declaration

TYPE

CamStruct: STRUCT

FileName:STRING; (* Filename that will be used by Y_CamFileSelect *)

TableType:INT; (* 0=Undefined, 1=M/S pair, 2=reserved, 3=reserved *)

TableSize:UDINT; (* The size of the cam table in bytes (Don't forget, 16 bytes per M/S pair) *)

TableID:UINT; (* Number returned from Y_CamFileSelect *)

EngagePosition:LREAL; (* Master location where slave must start synchronization

(Reference prm 1502 - CamMasterShiftedCyclic *)

EngageData:Y_ENGAGE_DATA;

DisengagePosition:LREAL; (* Master location where slave must stop synchronization

(Reference prm 1502 - CamMasterShiftedCyclic *)

DisengageData:Y_DISENGAGE_DATA;

Window:LREAL; (* Size of the window in master units where the engage or disengage
will take place *)

MasterCycle:LREAL;

SlaveCycle:LREAL;

END_STRUCT;

END_TYPE



Data Type: CamSyncStruct

For use with the [CamControl](#) and [CamShift_Control](#) function blocks

Data Type Declaration

CamSyncStruct: STRUCT

Mode:INT; (* User Input. 1 = Rotary Knife; 2 = Linear Flying Shear, 3 = Rotary Placer or Reciprocating Drill *)

StartSyncPosition:LREAL; (* User Input. The first master position where the slave must be synchronized with the master *)

EndSyncPosition:LREAL; (* User Input. The final master position where the slave must be synchronized with the master, adjustments can start after. *)

DecisionPosition:LREAL; (* User Input. Key location in the process where the machine must decide to start the disengage process, or continue camming and CamShift to the next product. *)

MaxShift:LREAL; (* User Input. If Mode = 3, this value is used to determine if the slave should advance or retard to synchronize with the next product. *)

SafeEngageDistance:LREAL; (* Distance traveled from the sensor until the product is less than one machine cycle away from the synchronization point. *)

Shifting:BOOL; (* System Output flag set by the CamShift_Control function block *)

Pause:BOOL; (* System Output flag set by the CamControl function block if the system was temporarily disengaged *)

END_STRUCT;



Data Type: Matrix

For use by the [CamGenerator](#) for [Cubic Spline calculations](#)

Data Type Declaration

Matrix : ARRAY [0..20] OF SubMatrix;



Data Type: SubMatrix

For use by the [CamGenerator](#) for [Cubic Spline calculations](#)

Data Type Declaration

```
SubMatrix : ARRAY [0..20] OF LREAL;
```



Data Type: TableIDStruct

For use with the [CamTableUpdate](#) function block

Data Type Declaration

```
TYPE
```

```
TableIDStruct:STRUCT
```

```
Inactive:UINT; (* The CamTableID that is NOT currently being accessed to control motion *)
```

```
Active:UINT; (* The CamTableID that IS currently being accessed to control motion *)
```

```
END_STRUCT;
```

```
END_TYPE
```



Data Type: UINTArray

For use with the [CamTableManager](#) Function Block

Data Type Declaration

UINTArray: ARRAY[0..4] OF UINT; (* An array for CamTableIDs that are released from memory in a FIFO method. *)



Data Type: Y_MS_CAM_STRUCT

This data type is for use with the [CamGenerator](#), [CamMaster Lookup](#), [CamTableUpdate](#), and [SlaveIndex Lookup](#) function blocks.

Data Type Declaration

TYPE

Y_CAM_HEADER:STRUCT

TableType:INT; (* INT#1 = Master/Slave pair *)

Reserved1:UINT;

DataSize:UDINT; (* Size of cam table in bytes, 16 bytes per Y_MS_PAIR *)

END_STRUCT;

Y_MS_PAIR: STRUCT

Master:LREAL; (* Master position *)

Slave:LREAL; (* Slave position *)

END_STRUCT;

Y_MS_HEADER:STRUCT

SlaveIncremental:BOOL; (* If TRUE, then the slave data from pair to pair is relative. *)

MasterIncremental:BOOL; (* If TRUE, then the master data from pair to pair is relative. *)

Reserved1:UINT;

Reserved2:UINT;

Reserved3:UINT;

END_STRUCT;

MS_Array_Type:ARRAY[0..2880] OF Y_MS_PAIR;



```
Y_MS_CAM_STRUCT:STRUCT
```

```
Header:Y_CAM_HEADER;
```

```
MS_Header:Y_MS_HEADER;
```

```
MS_Data:MS_Array_Type;
```

```
END_STRUCT;
```

```
END_TYPE
```




Enumerated Types

Enumerated Type: TB_CurveType

ENUM type for describing the cam formula to be used.

Data Type Declaration

(* ENUM Type for CurveType *)

TB_CurveType:

(

na, (* INT#0 - Not a valid CurveType *)

StraightLine, (* INT#1 - Straight Line *)

Parabolic, (* INT#2 - Parabolic *)

SimpleHarmonic, (* INT#3 - Simple Harmonic *)

Cycloidal, (* INT#4 - Cycloidal *)

ModifiedTrapezoid, (* INT#5 - Modified Trapezoid *)

ModifiedSine, (* INT#6 - Modified Sine *)

ModifiedConstVelocity, (* INT#7 - Modified Constant Velocity *)

AsymmetricalCycloidal, (* INT#8 - Asymmetrical Cycloidal *)

AsymmetricalModifiedTrapezoid, (* INT#9 - Asymmetrical Modified Trapezoid *)

Trapezoid, (* INT#10 - Trapezoid *)

OneDwellCycloidal_1, (* INT#11 - One Dwell Cycloidal m=1 *)

OneDwellCycloidal_2_3, (* INT#12 - One Dwell Cycloidal m=2/3 *)

OneDwellTrapezoid_1, (* INT#13 - One Dwell Trapezoid m=1 *)

OneDwellTrapezoid, (* INT#14 - One Dwell Trapezoid *)

OneDwellTrapezoid_2_3, (* INT#15 - One Dwell Trapezoid m=2/3 *)

OneDwellModifiedSine, (* INT#16 - One Dwell Modified Sine *)



Cam Toolbox: DataTypes



OneDwellTrapecloid, (* INT#17 - One Dwell Trapecloid *)

NoDwellSimpleHarmonic, (* INT#18 - No Dwell Simple harmonic *)

NoDwellModifiedTrapezoid, (* INT#19 - No Dwell Constant Velocity *)

NoDwellModifiedConstVelocity, (* INT#20 - No Dwell Modified Constant Velocity *)

NC2Curve, (* INT#21 - NC2 Curve *)

TangentMatching, (* INT#22 - Tangent Matching *)

ReverseTrapecloid, (* INT#23 - Reverse Trapecloid *)

DoubleHarmonic, (* INT#24 - Double Harmonic *)

ReverseDoubleHarmonic, (* INT#25 - Reverse Double Harmonic *)

TangentBlending, (* INT#26 - Tangent Blending *)

Unsupported27 (* INT#27 - Unsupported *)

Unsupported28 (* INT#28 - Unsupported *)

UserModifiedConstVelocity, (* INT#29 - User Modified Constant Velocity - To specify the accel / decel distances *)

Polynomial345 (* INT#30 - 5th order polynomial with C3 = 10, C4 = -15, C5 = 6 *)

CubicSpline (* INT#31 - Cubic spline interpolation *)

Arc (* INT#32 - Arc *)

ParabolicVelocityBlend (* INT#33 - Parabolic curve with velocity blending *)

);



Enumerated Type: TB_Mode

ENUM Type for [CamShift_Control](#) to select rotary or linear slave motion

Data Type Declaration

TB_Mode:

(

na, (* INT#0 - Not a valid Mode *)

Reciprocating, (* INT#1 - Reciprocating, like Rotary Placer, Rotary Knife, etc. *)


OutAndBack (* INT#2 - Out and Back, like linear flying shear, walking beam, bottle filler *)

);



Function Blocks

CalcSpline




This function block is for internally calculating the [Cubic Spline](#) cam curve type.

Attention: This function block is not intended for end user implementation. Its functionality is a requirement for the [Cam Toolbox](#) user library. To use this functionality, please refer to the function block [CamGenerator](#).



Cam_Analyzer



The CamAnalyzer function block provides the slaves maximum velocity, acceleration, deceleration and jerk values for a specific cam profile based on a maximum expected master velocity.

Parameters

*	Parameter	Data Type	Description
VAR_IN_OUT			
B	CamTable	Y_MS_CAM_STRUCT	This structure contains the resulting master/slave information for each datapoint and can be downloaded to the motion engine using Y_CamStructSelect
VAR_INPUT			
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.
B	MasterVelocity	LREAL	Master axis maximum velocity (in master user units/sec.)
VAR_OUTPUT			
B	Done	BOOL	Set high when the commanded action has




			been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.
B	MaximumVelocity	LREAL	Peak slave velocity for the given cam profile at the maximum master velocity.
B	MaximumAcceleration	LREAL	Peak slave acceleration for the given cam profile at the maximum master velocity.
B	MaximumJerk	LREAL	Peak slave jerk for the given cam profile at the maximum master velocity.

Error Description



ErrorID	Meaning
0	No error
10113	Incorrect cam table size (check the CamTable.Header.Datasize)


Example

Consider a linear flying shear application. The maximum slave velocity of the profile is in the speed matching region. The master maximum velocity was given as 24 units/sec and the maximum velocity output of the CamAnalyzer is 24.




Maximum velocity at speed matching region of cam profile







CamBlend



This function block was designed for applications that require a one way cam profile, and the slave must be able to engage or disengage smoothly from a moving master. It requires three separate cam tables with a portion of equivalent slave data, so an on-the-fly changeover from one table to the next can occur. This function block uses three Y_CamIn functions blocks and one Y_CamOut function block.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
B	Master	AXIS_REF	A logical reference to the master axis	
B	Slave	AXIS_REF	A logical reference to the slave axis	
V	BlendData	BlendStruct	Structure containing the information required for engaging, disengaging, ramping in, and ramping out.	
VAR_INPUT				Default
V	ExecuteRampIn	BOOL	Upon the rising edge, this function block will prepare to engage the RampIn cam profile at the master position specified in the BlendData structure.	FALSE
V	ExecuteRampOut	BOOL	Upon the rising edge, this function block will	FALSE



			prepare to switch to the RampOut cam profile at the SwitchOver position specified in the BlendData structure.	
V	ExecuteStandStill	BOOL	Upon the rising edge, this function block will prepare to engage the slave to the Running cam profile at the StandstillEngage position (calculated after an E-Stop recovery routine) in the BlendData structure	FALSE
VAR_OUTPUT				
E	InSync	BOOL	Set high when the slave first synchronizes with the master (Running cam profile is synchronized). This output is reset when execute goes low.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.	
B	Active	BOOL	For buffered modes, this output is set high at the moment the block takes control of the axis. For non buffered modes, the outputs Busy and Active have the same value.	
B	CommandAborted	BOOL	Set high if motion is aborted by another motion command or MC_Stop. This output is cleared with the same behavior as the Done output.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	
V	BlendStatus	UINT	Outputs a value of 1 to indicate the RampIn Cam is operating, 2 indicates the Running cam is operating, and 3 indicates the RampOut cam is operating.	
E	EndOfProfile	BOOL	Pulsed output signaling the cyclic end of a CAM Profile	

Notes

- Typically the RampInSwitchOverPos and the RampOutSwitchOverPos will be fixed at some predetermined position that is suitable for the application. Typically the RampInSwitchOverPos will occur very late in the cycle, and the RampOutSwitchOverPos will occur very early in the cycle. This will provide for the optimum motion performance by allowing as much time as possible for the slave to accelerate up to the master speed.
- If using the ExecuteStandStill mode, use the [CamMaster Lookup](#) and [CamSlave Recover](#) function blocks to determine the master position that corresponds to the current slave position, and set BlendData.StandStillEngagePos accordingly to preserve synchronization. The ExecuteStandStill mode was added to provide the capability of re-synchronizing after an E-Stop.


See the [CamBlend eLearning Module](#) on Yaskawa's YouTube Channel.



Error Description


ErrorID	Meaning
0	No error
4370	The move could not be started because motion is prohibited. The drive may not be enabled. MC_Power.Enable_Positive or MC_Power.Enable_Negative might be low. Check MC_Power.Status output. MC_Stop.Execute might be held high, preventing motion.
4375	CamOut called while not camming.
4378	The function block is not applicable for the external axis specified
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4394	More than 10 Y_CamIn, Y_CamOut, or MC_GearInPos function blocks for a given axis are active at the same time. Most likely the application program is not coded correctly, and the Execute input is being fired too frequently.
4395	Window parameters are outside of the cams Machine Cycle. (0 to Prm1502, the last master position in the active cam table.)
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4633	Table size results in misaligned data. Refer to the help section "Internally Created Cam Data." A cam table will have a multiple of 16 bytes if created correctly.
4643	Start mode does not correspond to a valid enumeration value.
4669	Engage position is outside the cam table domain.
4670	Engage window is less than zero.
467/1	Disengage position is outside the cam table domain.
4672	Negative Disengage Window.
4887	CamTableID does not refer to a valid cam table.
4891	The slave axis can not be the same as the master axis.
10084	One of the Cam Tables has an invalid TableID
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type. This error may occur because data passed to an 'Axis' input on a PLCopen function block is not an AXIS_REF. If you have included a data element into a user structure which includes an AXIS_REF, be sure that the input to the function block is entered correctly.

Example 1






Flying Shear (Running)




Timing Diagram

The speed matching, or normal running cam is designated as Profile #2. Profile #1 and Profile #3 will only run once, but Profile #2 will run indefinitely. A simple straight line profile for Profile #2 is not required, and reasonable motion can be used if the application requires it, keeping in mind that CamBlend was designed for one way slave motion that never stops while in normal operation, thus making it difficult to synchronize with the master smoothly without blending from one profile to another.





CamControl



The CamControl block makes decisions regarding engage and disengage timing for applications where products are buffered and processed at random intervals. This function block requires the [ProductBuffer](#) function block from the PLCopen Toolbox and the [CamShift_Control](#) block from the Cam Toolbox. The main inputs that feed the CamControl block are RegistrationData and ControlData. This function block was designed for applications like Linear Flying Shear, Random Rotary Placer, Knife, Drill, etc.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
B	Axis	AXIS_REF	Logical axis reference. This value can be located on the Configuration tab in the Hardware Configuration (logical axis number).	
V	RegistrationData	ProductBufferStruct	Structure containing all information for the circular buffer to operate.	
V	ControlData	CamSyncStruct	Structure containing all information to allow both the CamControl and CamShiftControl to make decisions to run the cam function effectively.	
VAR_INPUT			Default	
B	Enable	BOOL	The function will continue to execute	FALSE



			while enable is held high.
VAR_OUTPUT			
B	Valid	BOOL	Indicates that the outputs of the function are valid.
V	Engage	BOOL	Set high when the externally located Y_Cam_In function block(s) must be executed.
V	Disengage	BOOL	Set high when the externally located Y_Cam_Out function block(s) must be executed.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
E	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Notes

- The Engage output is to be used with a Y_CamIn function block placed external to this function block. This design allows for one or more cam slaves to be operated via the logic provided.
- The Disengage output is to be used with a Y_CamOut function block placed external to this function block. This design allows for one or more cam slaves to be operated via the logic provided.
- This function block is designed to work with the [CamShift Control](#) function block. It waits for an initial Camshift will occur before the first Engage event should take place. If the application requires the slave to become synchronized with the master without a Camshift, simply use an R_TRIG of the CamControl.Valid to cause the CamData.Shifting bit to go high and low.

Error Description

ErrorID	Meaning
0	No error
10081	ControlData.DecisionPosition

Code Example

The operation of CamControl in deciding when to engage and disengage a cam is shown in the logic analyzer illustration below. The rising edge of the CamControl.Shifting variable denotes the "first" product to be processed. First product in this implementation means the cam is disengaged, the ProductBuffer was empty, and a product arrived. Shifting starts immediately if it is the first product in the ProductBuffer. CamControl waits for the falling edge of the Shifting bit to set the CamControl.Engage output. While the cam is engaged, the CamControl block continues to monitor the product buffer for new products. When the ProductBuffer indicates that no products have arrived and the cam cycle has past the 'Decision Position,' the CamControl.Disengage output is turned on.



```


(*Initializing the ProductBufferStruct for Registration Data *)
(*-----*)
20 Products.BufferSize:=INT#20; (* Maximum size of buffer*)
10.0000000 Products.LockoutDistance:=LREAL#10.0; (* Looks for a new part only after conveyor has travelled LockOutDistance after previous part *)
0.0000000 Products.ManualOffset:=LREAL#0.0;
16.5000000 Products.ProductAwayDistance:=LREAL#16.5; (* Distance from sensor that corresponds to last sync point on the cam profile*)
1 Products.Sensor.Bit:=UINT#1; (* Equates to EXT1 on a Sigma-5 amplifier, see MC_TouchProbe help for details *)
14.0000000 Products.SensorDistance:=LREAL#14.0; (* Distance from sensor to centre of sync area in cam profile *)
14.0000000 Products.SensorOffset:=REM(Products.SensorDistance,LREAL#18.0); (* 18 is the cam master cycle *)
  
```

Variable Properties

Name: **Products**

Data Type: ProductBufferStruct

Usage: VAR_GLOBAL RETAIN



```

13.0000000 CamControlData.DecisionPosition := LREAL#13.0; (*Position in the cam profile where decision to cam out can be made, *)
9.0000000 CamControlData.EndSyncPosition := LREAL#9.0;
2 CamControlData.Mode := 2;
4.0000000 CamControlData.StartSyncPosition:= LREAL#4.0;
  
```


Variable Properties

Name: **CamControlData**

Data Type: CamSyncStruct

Usage: VAR_GLOBAL RETAIN

ControlData.Shifting is updated in CamShift_Control
ControlData.Pause is updated in CamControl







Application Example

This example illustrates how the CamControl block can be applied in a linear flying shear application. In this application, the items to be cut are defective areas (knots) in a piece of wood. The code shown here performs the following actions:


1. The [ProductBuffer](#) stores the position of each defect where a cut must be made.
2. The [CamShift_Control](#) synchronizes the master (conveyor moving the wood) and slave (saw).
3. The CamControl.Engage output must be connected to Y_CamIn.Execute. (Other logic requirements may be included if necessary.)
4. Key Point: When defects are close together, the goal is to remain engaged, and use the CamShift function during the slave (saw) retraction stroke while not in contact with the wood to re-synchronize with the next defect (or knot) to be cut.
5. The CamControl.Disengage output must be connected to Y_CamOut.Execute. In this application, it will cause the slave (saw) to disengage when the ProductBuffer indicates that there are no more defects to be cut.








Cam Toolbox: Function Blocks





CamGenerator



This function can calculate the information required for various master / slave motion profiles. It was designed to replicate the formulas available in Yaskawa's CamTool windows software and includes additional curve types.

The "CamData" input is a structure of key datapoints required by the application, including a formula code which is used to generate a pair of master / slave datapoints at the resolution specified. The output "CamTable" is a [Y_MS_CAM_STRUCT](#) which can be downloaded to the Motion Engine using the Y_CamStructSelect function block.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
V	CamData	CamSegmentStruct	This structure must be populated with the key datapoints required for the cam profile.	
V	CamTable	Y_MS_CAM_STRUCT	Cam data structure. Can be downloaded to the motion engine using Y_CamStructSelect.	
VAR_INPUT			Default	
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
V	TableSize	UDINT	This value must be the same as the definition of the ARRAY size of the MS_Array_Type in the MotionInfo DataTypes folder of either the PLCopen or DataTypes Toolbox.	UDINT#2880



VAR_OUTPUT			
B	Done	BOOL	ERROR: Variable (Parameter bDescription_Done) is undefined.
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Notes

- In MotionWorks IEC, certain information must be hard coded at design time, such as the size of an array. Because of this, we selected a default size of 200 for the CamSegmentArray DataType. If more segments are required, edit the Cam Toolbox's DataType definition by changing this value. There is no practical limit on the number of segments, however the IEC code uses INT datatype for array definitions associated with this function. There is also a hard coded check for the number of segments inside the CamGenerator function block. If you change the array size, also change the line that reads:

SegmentSizeError:=(CamData.LastSegment = INT#0) OR (CamData.LastSegment > INT#200).

- The default size of a Y_MS_CAM_STRUCT is defined in the PLCopen Toolbox as:

MS_Array_Type:ARRAY[0..2880] OF Y_MS_PAIR.

If your cam profile requires more than 2880 master / slave pairs, this value can be increased by editing the PLCopen Toolbox DataType definition. If you change the value, don't forget to change the TableSize input to CamGenerator.

- The resolution specified for each point in the CamData STRUCT is resolution of the master. For example, if MasterEnd = 100.0, and the previous segment's MasterEnd = 80.0, and the Resolution = 1.0, then 20 data points will be calculated along the CurveType specified.
- See the [Cam Curve Types](#) for further details about creating cam profiles.
- See the [CamGenerator eLearning Module](#) on Yaskawa's YouTube Channel.

Error Description

ErrorID	Meaning
0	No error
10038	CamData.LastSegment must be greater than 0 and less than 400, or whatever value has been declared as the ARRAY size in the CTB_Types file.



10039	Cam Segment 'Resolution' cannot be zero unless the CurveType is TB_CurveType#StraightLine..
10040	Curve Type selected in a segment is not valid.
10041	Total pairs required would exceed DataType definition for MS_Array_Type based on number of segments and resolution settings in CamData.
10042	Master must be always increasing from segment to segment.
10043	Tangent Match formula error, cannot have only one segment.
10044	Tangent Blend error, must have two segments, a straight line and a Tangent Blend, in either order.
10077	Cubic Spline maximum number of consecutive segments exceeded. DataType definition for the Matrix could be increased if necessary.
10083	Unsupported Cubic Spline Sequence

Examples

Structured text to load a CamSegmentStruct:

Example 1

```



3 CamData1.LastSegment:=INT#3;
0.0000 CamData1.SlaveStart:=LREAL#0.0;

1 CamData1.CamParameters[1].CurveType:=TB_CurveType#StraightLine;
10.0000 CamData1.CamParameters[1].MasterEnd:=LREAL#10.0;
10.0000 CamData1.CamParameters[1].SlaveEnd:=LREAL#10.0;
0.5000 CamData1.CamParameters[1].Resolution:=REAL#0.5;

22 CamData1.CamParameters[2].CurveType:=TB_CurveType#TangentMatching;
20.0000 CamData1.CamParameters[2].MasterEnd:=LREAL#20.0;
22.0000 CamData1.CamParameters[2].SlaveEnd:=LREAL#22.0;
0.5000 CamData1.CamParameters[2].Resolution:=REAL#0.5;

1 CamData1.CamParameters[3].CurveType:=TB_CurveType#StraightLine;
30.0000 CamData1.CamParameters[3].MasterEnd:=LREAL#30.0;
35.0000 CamData1.CamParameters[3].SlaveEnd:=LREAL#35.0;
0.5000 CamData1.CamParameters[3].Resolution:=REAL#0.5;

```





Example 2

```



3 RICamData.LastSegment:=INT#3;
180.0000 RICamData.SlaveStart:=LREAL#180.0;

1 RICamData.CamParameters[1].CurveType:=TB_CurveType#StraightLine;
10.0000 RICamData.CamParameters[1].MasterEnd:=LREAL#10.0;
180.0000 RICamData.CamParameters[1].SlaveEnd:=LREAL#180.0;
1.0000 RICamData.CamParameters[1].Resolution:=REAL#1.0;

22 RICamData.CamParameters[2].CurveType:=TB_CurveType#TangentMatching;
350.0000 RICamData.CamParameters[2].MasterEnd:=LREAL#350.0;
350.0000 RICamData.CamParameters[2].SlaveEnd:=LREAL#350.0;
1.0000 RICamData.CamParameters[2].Resolution:=REAL#1.0;


1 RICamData.CamParameters[3].CurveType:=TB_CurveType#StraightLine;
360.0000 RICamData.CamParameters[3].MasterEnd:=LREAL#360.0;
360.0000 RICamData.CamParameters[3].SlaveEnd:=LREAL#360.0;
1.0000 RICamData.CamParameters[3].Resolution:=REAL#1.0;

```





CamMaster_Lookup



This function block provides the master position given a slave position by searching the referenced CamTable. If there may be two or more master positions for the slave, as in the case of out and back slave motion, a range of slave positions can be specified to limit the search for the corresponding master position. This function block is useful for E-Stop recovery routines.

Parameters

*_	Parameter	Data Type	Description	
VAR_IN_OUT				
B	CamTable	Y_MS_CAM_STRUCT	Cam data structure	
VAR_INPUT				
			Default	
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
V	SlaveMin	LREAL	The smallest slave position to include when searching for the master.	LREAL#0.0
V	SlavePosition	LREAL	The current slave position	LREAL#0.0
B	SlaveMax	LREAL	The largest slave position to include when searching for the master.	LREAL#0.0
VAR_OUTPUT				
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will	



			not be set. This output is reset when execute goes low.
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.
B	MasterPosition	LREAL	The master position which corresponds to the SlavePosition.

Notes

This function provide the exact master position that corresponds to the SlavePosition input by interpolating the CamTable. Consider the following CamTable:

M	S
0	0
10	0
20	5
30	10
40	20


If the SlavePosition is 15, the corresponding MasterPosition is 35.

Error Description

ErrorID	Meaning
0	No error
10045	SlavePosition not found in Y_MS_CAM_STRUCT



CamShift_Control



The CamShift_Control block manages cam shifting for applications that buffer random products such as Linear Flying Shear or Random Rotary Placer/Knife/Drill, etc. The purpose is to re synchronize the slave for each item or product arriving on the master axis.

Parameters

*_	Parameter	Data Type	Description	
VAR_IN_OUT				
B	Master	AXIS_REF	A logical reference to the master axis	
B	Slave	AXIS_REF	A logical reference to the slave axis	
V	RegistrationData	ProductBufferStruct	Structure containing all information for the circular buffer to operate.	
V	ControlData	CamSyncStruct	Structure containing all information about the cam profile that will be used to calculate and implement cam shifts	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE



V	UpdateUsePointer	BOOL	RegistrationData.UsePointer will be updated when a product has been processed only if this input is TRUE. If more than one slave follow the master, only the last slave must update the UsePointer.	FALSE
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
V	Shifting	BOOL	Set high if the function block is active and Y_CamShift is Busy.	
V	ItemsProcessed	UDINT	Provides a count of the number of products processed since this function was enabled.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
E	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	

Notes

- This function block includes a Y_CamShift block, and will execute shifts at the appropriate position based on data provided by the user via the ControlData structure.
- This shifted master position is available by reading slave axis parameter 1502.
- This function block requires the ProductBuffer function block from the PLCopen Toolbox and the CamControl block from the Cam Toolbox. These three blocks work together to provide cam engage/disengage control as well as cam shifting (synchronization) logic.
- The 'Shifting' bit is held high when a Y_CamShift is in progress.
- The CamShift_Control block uses data from RegistrationData and ControlData to make decisions on when to shift the master position and by how much to shift the position by. The user must provide valid data in the RegistrationData and ControlData structures.
- In cases where multiple slaves are synchronized to a single master, the slaves can share the same ProductBuffer . Set the last slave (last CamShift_Control function block) to update the UsePointer for the ProductBuffer.

Error Description


ErrorID	Meaning
0	No error




7282	Cam Shift Aborted. Verify that the CamShift_Control function block was not interrupted by another function block that resulted in Y_CamShift.CommandAborted
10082	Mode Error. ControlData.Mode can only be 1 (one way cam) or 2 (two way cam).

Code Example

The role of CamShift_Control in master / slave synchronization for each product is illustrated below.






Application Example

This example illustrates how the CamControl block can be applied in a linear flying shear application. In this application, the items to be cut are defective areas (knots) in a piece of wood. The code shown here performs the following actions:

1. The [ProductBuffer](#) stores the position of each defect where a cut must be made.
2. The [CamShift_Control](#) synchronizes the master (conveyor moving the wood) and slave (saw).
3. The CamControl.Engage output must be connected to Y_CamIn.Execute. (Other logic requirements may be included if necessary.)
4. Key Point: When defects are close together, the goal is to remain engaged, and use the CamShift function during the slave (saw) retraction stroke while not in contact with the wood to re-synchronize with the next defect (or knot) to be cut.
5. The CamControl.Disengage output must be connected to Y_CamOutExecute. In this application, it will cause the slave (saw) to disengage when the ProductBuffer indicates that there are no more defects to be cut.




Cam Toolbox: Function Blocks






Cam Toolbox: Function Blocks






Cam Toolbox: Function Blocks





CamSlave_FeedToLength



CamSlave_FeedToLength was designed for use with camming applications that index a slave axis forward in one direction, and require on the fly adjustments of the actual index length based on a sensor input that occurs while the slave is moving. The sensor input is on the slave axis.

Parameters

*_	Parameter	Data Type	Description
VAR_IN_OUT			
B	Master	AXIS_REF	A logical reference to the master axis



B	Slave	AXIS_REF	A logical reference to the slave axis	
V	SlavePrms	AxisParameterStruct	User Defined DataType declared in the PLCopen Toolbox.	
E	TriggerData	TRIGGER_REF	Reference to the trigger signal source. Refer to PLCopen Plus Function Block Manual for more details.	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
V	ProductSize	LREAL	This value must be the same as the total one way index of the cam profile for this slave.	LREAL#0.0
V	DistanceAfterLatch	LREAL	The desired additional travel distance after the registration mark is detected	LREAL#0.0
V	MaxPosCorrection	LREAL	Limits the amount of positive correction that can be applied	
V	MaxNegCorrection	LREAL	Limits the amount of negative correction that can be applied	
V	AdjustMode	INT	An ENUM for TIME or range of master correction, with the following values:	
V	MasterDistance	LREAL	Relative amount the master will travel (in cam master units) from when the function block first executes until the correction is complete. Only used if AdjustMode = Y_AdjustMode#MasterDistance.	
V	Duration	LREAL	Time of the correction used if AdjustMode is set for TIME mode	
V	StartCorrection	LREAL	Earliest master position where the correction can begin.	LREAL#0.0
V	FinishCorrection	LREAL	Latest master position where the correction must be completed.	LREAL#0.0
V	SensorMinimum	LREAL	The earliest slave position where a sensor position is valid for correction.	LREAL#0.0
V	SensorMaximum	LREAL	The latest slave position where a sensor position is valid for correction.	LREAL#0.0 (function block defaults to



				ProductSize if left unconnected.)
V	MissedLatchLimit	UINT	The number of consecutive product lengths that can occur without seeing a mark in the window. Valid sensor detections will reset the internal counter. The next valid sensor detection will reset the internal counter.	UINT#0 (interpreted as infinite)
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
V	ActualSize	LREAL	The actual indexed distance	
V	LatchPosition	LREAL	The slave's position in the CamTable when the latch occurred	
B	RecordedPosition	LREAL	The slaves latch position as reported by MC_TouchProbe.	
V	LimitedPosCorrection	BOOL	Indicates that the MaxPosCorrection is limiting the required correction.	
V	LimitedNegCorrection	BOOL	Indicates that the MaxNegCorrection is limiting the required correction.	
V	Adjusting	BOOL	Indicates that an adjustment is currently taking place (Busy output of Y_SlaveOffset)	
V	MissedLatch	BOOL	Indicates that a latch was detected, but it was outside of the window parameters specified.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
E	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	

Notes

- This function block requires that the ReadAxisParameters function block from the PLCopen toolbox is also running, preferably in the same task as CamSlaveFeedToLength.
- See the [CamSlave FeedToLength eLearning Module](#) on Yaskawa's YouTube Channel.

Missed Latch Detection feature:

There are two parts to this feature.



1) It will report an ErrorID 10021 if the user enters a non zero value for the MissedLatchLimit and a consecutive number of latches are not counted. (To detect a hardware failure or other problem with system such as a sensor blockage.)

2) If latches are detected, but are outside of the SensorMinimum and SensorMaximum range, it is not considered a missed latch in terms of counting up to the MissedLatchLimit. In this condition, the function block will pulse the MissedLatch output to indicate that no correction will be made because the latch is not in the specified area. The user can track the MissedLatch output pulses to make adjustments to the machine, or open the window for first time synchronization of the master and slave.

In Cam Toolbox v204, this function block was modified to report the RecordedPosition as a new output so that applications can use this information to re position or re home the axis after a manual operation without adding a separate MC_TouchProbe function block in the application. The function was also modified to prohibit its internal Y_SlaveOffset from executing if no cam is engaged.

Error Description

ErrorID	Meaning
0	No error
4370	The move could not be started because motion is prohibited. The drive may not be enabled. MC_Power.Enable_Positive or MC_Power.Enable_Negative might be low. Check MC_Power.Status output. MC_Stop.Execute might be held high, preventing motion.
4374	Torque move prohibited while non-torque moves queued or in progress.
4378	The function block is not applicable for the external axis specified
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4626	The master slave relationship is defined. A slave cannot be a master to another axis.
4633	Table size results in misaligned data. Refer to the help section "Internally Created Cam Data." A cam table will have a multiple of 16 bytes if created correctly.
4649	Invalid adjust mode
4657	Distance parameter is less than or equal to zero.
4663	Specified time was less than zero.
4673	StartPosition is outside of master's range.
4674	EndPosition is outside of master's range.
10020	ProductSize cannot be less than or equal to zero
10021	Maximum allowed consecutive missed registration marks reached
10025	Might be crossed or the same non-zero value
10053	DataPoint Error
10086	MaxPosCorrection must be zero or positive, MaxNegCorrection must be or zero or negative.
57620	The DataType connected to a function block parameter specified as ANY type does not








match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.

Applications

- Label Feeder
- Punch Press
- Intermittent Form Fill and Seal

Overview of Supporting Function Blocks






Application Example

Consider a form fill and seal application as shown below. Feed belts control payout of film for the form fill and seal machine.


Distance After Latch is set to align the end of bag with the cutter/punch



Cam Toolbox: Function Blocks



The film drive belt is the slave to a constantly running master. The nominal cam table is shown below. The master cycle is 0 - 1 units and the slave cycle is also between 0 and 1 units.



A sample screen shot of data that needs to be entered for the system described above is shown in the figure below. Care should be taken to ensure that the input parameters will generate motion that is physically achievable and desirable by the slave axis.

CamSlave_FeedToLength_1				
CamSlave_FeedToLength				
X	Master	Master	X	
Y	Slave	Slave	Y	
SlaveParams	SlavePrms	SlavePrms	SlaveParams	
Sensor	TriggerData	TriggerData	Sensor	
EnableCSFTL	Enable	Valid	●	
<i>(*ProductSize must be EQ Slave cycle of cam*)</i>	ProductSize	ActualSize	●	
<i>(*Distance from sensor to end of cam*)</i>	LREAL #0.5	DistanceAfterLatch	LatchPosition	●
	LREAL #0.50	MaxPosCorrection	LimitedPosCorrection	●
<i>(*Max Neg correction has to be negative*)</i>	LREAL #-0.50	MaxNegCorrection	LimitedNegCorrection	●
Y_AdjustMode #WithinRange	AdjustMode	Adjusting	Adjusting	
	● MasterDistance	MissedLatch	●	
	● Duration	Error	●	
<i>(*Start and End Correction have to be after the latch but before the end of the cycle*)</i>	StartCorr	StartCorrection	ErrorID	●
	EndCorr	EndCorrection		
	LREAL #0.0	SensorMinimum		
	LREAL #1.0	SensorMaximum		
	UINT #1000	MissedLatchLimit		



In the screen shot of the CamSlave_FeedToLength block shown below, the sensor detects a registration mark at 0.36201 units of the slave cycle. Assuming that the previous registration mark was captured at 0.5 units of the



Cam Toolbox: Function Blocks



slave cycle, the distance between two successive registrations is 0.86201 units (0.5 + 0.36201). The actual bag length in this case is 0.86201 units.




The calculation on how much adjustment needs to be made to make the slave axis (film feed) place the film exactly at the cutter/pinch location is explained below:

$$\text{Correction} = \text{Nominal part size (1.0)} - \text{Actual bag length (0.86201)} = -0.1379$$

This will be the amount of offset added/subtracted (for this cycle) to any previous offsets in the slave position.


A continuous sequence of short, long, short bag lengths is illustrated in the logic analyzer plots below.

The first occurrence of TouchProbe.Done in the figure triggers a calculation that shows a short bag. A small negative offset is calculated and can be seen by the dip to negative velocity at the end of the first master cycle. The registration mark in the middle of the second master cycle triggers a calculation that results in a long bag and a positive offset. This is seen as the spike in slave velocity between 0.65 and 0.86 units of the master cycle. The last registration mark in the figure (in the middle of the third master cycle) triggers a calculation that results in a short bag and a negative offset. This is seen as the dip in slave velocity between 0.65 and 0.86 units of the master cycle.





CamSlave_FeedToLength2



CamSlave_FeedToLength2 is an enhancement of CamSlave_FeedtoLength. The only difference is the increased performance in capturing latches that occur at higher frequency by incorporating the Y_ProbeContinuous function block. As with CamSlave_FeedtoLength, this function block was designed for use with camming applications that index a slave axis forward in one direction, and require on the fly adjustments of the actual index length based on a sensor input. The sensor input is on the slave axis.



Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
B	Master	AXIS_REF	A logical reference to the master axis	
B	Slave	AXIS_REF	A logical reference to the slave axis	
V	SlavePrms	AxisParameterStruct	User Defined DataType declared in the PLCopen Toolbox.	
E	TriggerData	TRIGGER_REF	Reference to the trigger signal source. Refer to PLCopen Plus Function Block Manual for more details.	
V	Buffer	CONTINUOUS_REF		
VAR_INPUT			Default	
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
V	ProductSize	LREAL	This value must be the same as the total one way index of the cam profile for this slave.	LREAL#0.0
V	DistanceAfterLatch	LREAL	The desired additional travel distance after the registration mark is detected	LREAL#0.0
V	MaxPosCorrection	LREAL	Limits the amount of positive correction that can be applied	
V	MaxNegCorrection	LREAL	Limits the amount of negative correction that can be applied	
V	AdjustMode	INT	An ENUM for TIME or range of master correction, with the following values:	
V	MasterDistance	LREAL	Relative amount the master will travel (in cam master units) from when the function block first executes until the correction is complete. Only used if AdjustMode = Y_AdjustMode#MasterDistance.	
V	Duration	LREAL	Time of the correction used if AdjustMode is set for TIME mode	
V	StartCorrection	LREAL	Earliest master position where the correction can begin.	LREAL#0.0
V	FinishCorrection	LREAL	Latest master position where the correction must be completed.	LREAL#0.0



V	SensorMinimum	LREAL	The earliest slave position where a sensor position is valid for correction.	LREAL#0.0
V	SensorMaximum	LREAL	The latest slave position where a sensor position is valid for correction.	LREAL#0.0 (function block defaults to ProductSize if left unconnected.)
V	MissedLatchLimit	UINT	The number of consecutive product lengths that can occur without seeing a mark in the window. Valid sensor detections will reset the internal counter. The next valid sensor detection will reset the internal counter.	UINT#0 (interpreted as infinite)
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
V	ActualSize	LREAL	The actual indexed distance	
V	LatchPosition	LREAL	The slave's position in the CamTable when the latch occurred	
V	LimitedPosCorrection	BOOL	Indicates that the MaxPosCorrection is limiting the required correction.	
V	LimitedNegCorrection	BOOL	Indicates that the MaxNegCorrection is limiting the required correction.	
V	Adjusting	BOOL	Indicates that an adjustment is currently taking place (Busy output of Y_SlaveOffset)	
V	MissedLatch	UDINT	Cumulative number of latches missed	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	

Notes

A Sigma-5 servo amplifier is required for use of this function block.

Error Description








ErrorID	Meaning
0	No error
4370	The move could not be started because motion is prohibited. The drive may not be enabled. MC_Power.Enable_Positive or MC_Power.Enable_Negative might be low. Check MC_Power.Status output. MC_Stop.Execute might be held high, preventing motion.
4374	Torque move prohibited while non-torque moves queued or in progress.
4378	The function block is not applicable for the external axis specified
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4406	Continuous Latch Mode not supported on Sigma II, Sigma III, or external encoders
4407	Internal buffer overflow
4408	PatternSize is out of range (1-8) or PatternCount is out of range (0-255)
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4626	The master slave relationship is defined. A slave cannot be a master to another axis.
4633	Table size results in misaligned data. Refer to the help section "Internally Created Cam Data." A cam table will have a multiple of 16 bytes if created correctly.
4649	Invalid adjust mode
4657	Distance parameter is less than or equal to zero.
4663	Specified time was less than zero.
4673	StartPosition is outside of master's range.
4674	EndPosition is outside of master's range.
10020	ProductSize cannot be less than or equal to zero
10021	Maximum allowed consecutive missed registration marks reached
10025	Might be crossed or the same non-zero value
10053	DataPoint Error
10086	MaxPosCorrection must be zero or positive, MaxNegCorrection must be or zero or negative.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.

Applications

- Label Feeder
- Punch Press


Overview of Supporting Function Blocks







CamSlave_Lookup



This function block returns the slave position corresponding to the given master position. This function block is used by [CamSlave Recover](#).

Parameters

*_	Parameter	Data Type	Description	
VAR_IN_OUT				
B	CamTable	Y_MS_CAM_STRUCT	Cam data structure	
VAR_INPUT			Default	
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
V	MasterPosition	LREAL	The position of the master axis for which the corresponding slave position is required.	LREAL#0.0
VAR_OUTPUT				
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.	
B	Error	BOOL	Set high if error has occurred during the execution of	



			the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.
V	SlavePosition	LREAL	The slave position that relates to the master as described in the CamTable.

Notes

This function provide the exact slave position that corresponds to the MasterPostion input by interpolating the CamTable. Consider the following CamTable:

M	S
0	0
10	0
20	5
30	10
40	20

If the MasterPosition is 15, the corresponding SlavePosition is 2.5.

This function determine the equivalent slave position by looking in the CamTable only, It does not include any other cam adjustments that may have been applied using any of the Y_CamAdjust function blocks.

See the [CamSlave_Lookup eLearning Module](#) on Yaskawa's YouTube Channel.

Error Description



ErrorID	Meaning
0	No error
10114	Incorrect cam table size (check the CamTable.Header.Datasize)
10045	SlavePosition not found in Y_MS_CAM_STRUCT

Example

In the example shown below, the slave position corresponding to a master position of 10.0 is calculated. It can be seen that the slave position from the cam profile is 9.9196950.




[71]	Master	9.8000000
	Slave	9.8572890
[72]	Master	9.9000000
	Slave	9.8912510
[73]	Master	10.0000000
	Slave	9.9196950
[74]	Master	10.1000000
	Slave	9.9429420
[75]	Master	10.2000000
	Slave	9.9613810





CamSlave_PullToLength



CamSlave_PullToLength was designed for applications where the slave mechanism pulls material forward but the mechanism has a reciprocating stroke. This function block incorporates the ability to capture a registration mark on the material being pulled, and make on-the-fly adjustments to the stroke length by executing a Y_CamScale function block. This block has the same basic core operation as CamSlaveFeedToLength, which was designed for slaves that move in one direction but have the same requirement.

Parameters



* _	Parameter	Data Type	Description	
VAR_IN_OUT				
B	Master	AXIS_REF	A logical reference to the master axis	
B	Slave	AXIS_REF	A logical reference to the slave axis	
V	SlavePrms	AxisParameterStruct	User Defined DataType declared in the PLCopen Toolbox.	
E	TriggerData	TRIGGER_REF	Reference to the trigger signal source. Refer to PLCopen Plus Function Block Manual for more details.	
VAR_INPUT			Default	
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
V	ProductSize	LREAL	This value must be the same as the total one way index of the cam profile for this slave.	LREAL#0.0
V	DistanceAfterLatch	LREAL	The desired additional travel distance after the registration mark is detected	LREAL#0.0
V	MaxPosCorrection	LREAL	Limits the amount of positive correction that can be applied	
V	MaxNegCorrection	LREAL	Limits the amount of negative correction that can be applied	
V	AdjustMode	INT	An ENUM for TIME or range of master correction, with the following values:	
V	MasterDistance	LREAL	Relative amount the master will travel (in cam master units) from when the function block first executes until the correction is complete. Only used if AdjustMode = Y_AdjustMode#MasterDistance.	
V	Duration	LREAL	Time of the correction used if AdjustMode is set for TIME mode	
V	StartCorrection	LREAL	Earliest master position where the correction can begin.	LREAL#0.0
V	FinishCorrection	LREAL	Latest master position where the correction must be completed.	LREAL#0.0
V	SensorMinimum	LREAL	The earliest slave position where a sensor position is valid for correction.	LREAL#0.0



V	SensorMaximum	LREAL	The latest slave position where a sensor position is valid for correction.	LREAL#0.0 (function block defaults to ProductSize if left unconnected.)
V	MissedLatchLimit	UINT	The number of consecutive product lengths that can occur without seeing a mark in the window. Valid sensor detections will reset the internal counter. The next valid sensor detection will reset the internal counter.	UINT#0 (interpreted as infinite)
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
V	ActualSize	LREAL	The actual indexed distance	
V	LatchPosition	LREAL	The slave's position in the CamTable when the latch occurred	
V	LimitedPosCorrection	BOOL	Indicates that the MaxPosCorrection is limiting the required correction.	
V	LimitedNegCorrection	BOOL	Indicates that the MaxNegCorrection is limiting the required correction.	
V	Adjusting	BOOL	Indicates that an adjustment is currently taking place (Busy output of Y_SlaveOffset)	
V	MissedLatch	UDINT	Cumulative number of latches missed	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	

Notes

This function block is an adaptation of [CamSlave_FeedToLength](#). The main difference is that this function is designed for reciprocating slave motion, and uses the Y_CamScale function block instead of the Y_SlaveOffset function block.


Error Description



ErrorID	Meaning
0	No error
10020	ProductSize cannot be less than or equal to zero
10021	Maximum allowed consecutive missed registration marks reached
10025	Might be crossed or the same non-zero value
10053	DataPoint Error
10086	MaxPosCorrection must be zero or positive, MaxNegCorrection must be or zero or negative.



CamSlave_Recover



The CamSlave_Recover block moves a Slave back into sync with the master axis after camming was interrupted unexpectedly, such as E-Stop conditions, or alarms that disable the servo. This function block is particularly useful when resuming the cam motion from the position where it was interrupted is necessary to avoid wasting products in process, or if machine characteristics demand it, or if homing and re-starting the cycle is not feasible. The CamSlave_Recover function block can be used to bring the slave axis to the position in the cam table that corresponds to the current master axis position. Linear interpolation is performed for accuracy in case of coarse resolution between points in the cam table. Once CamSlave_Recover is Done, the camming motion can resume. This function block contains a MC_MoveAbsolute function.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
B	SlaveAxis	AXIS_REF	A logical reference to the slave axis	
B	CamTable	Y_MS_CAM_STRUCT	Cam data structure	
VAR_INPUT				Default
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
B	MasterPosition	LREAL	Master axis' current position. The CamSlave_Recover function block will command the slave axis to move to the slave position	LREAL#0.0



			corresponding to this MasterPosition value.	
B	Velocity	LREAL	Velocity with which the slave axis recovers and moves to the position from the cam table corresponding to the master axis position	
B	Acceleration	LREAL	Acceleration with which the slave axis recovers and moves to the position from the cam table corresponding to the master axis position	
B	Deceleration	LREAL	Deceleration with which the slave axis recovers and moves to the position from the cam table corresponding to the master axis position	
B	Jerk	LREAL	<i>Not supported; reserved for future use. Value of the jerk in [user units / second³].</i>	
B	Direction	MC Direction	The position of the slave axis for which the corresponding master position is required.	LREAL#0.0
VAR_OUTPUT				
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.	
B	Active	BOOL	For buffered modes, this output is set high at the moment the block takes control of the axis. For non buffered modes, the outputs busy and active have the same value	
B	CommandAborted	BOOL	Set high if motion is aborted by another motion command or MC_Stop. This output is cleared with the same behavior as the Done output.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	
V	SlavePosition	LREAL	Slave position in the cam profile that corresponds to the MasterPosition input to the function block	



Notes

After CamSlave_Recover is done, in most cases, the slave will be at a position different from the home position or dwell position. Care should be taken before re-engaging the slave to the master axis. Engage Position and Engage Data inputs on the Y_CamIn block should be verified to make sure that they are set correctly. Incorrect engage position and or engage method can cause abrupt motion on the slave axis.

Reccomended steps to recover from a cam cycle interruption

- 1) Clear all alarms after an E-Stop.
- 2) Enable the slave.
- 3) Verify the MasterPosition input is the position of the master axis to where the slave must to move to re-synchronize the cam operation.
- 3) Execute CamSlave_Recover with valid inputs.
- 4) Once CamSlave_Recover.Done is TRUE, the slave is in position to continue the cam motion immediately.
- 5) **Change** the Y_CamIn.EngagePosition to the current master position. **Set** Y_CamIn.EngageData.SlaveAbsolute:= TRUE.
- 6) Execute Y_Camin. The cam will engage and when the master axis starts motion, the slave will move in synchronization with the master.

See the [CamSlave_Recover eLearning Module](#) on Yaskawa's YouTube Channel.

Error Description

ErrorID	Meaning
0	No error
4378	The function block is not applicable for the external axis specified
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4658	Velocity parameter is less than or equal to zero.
4659	Acceleration is less than or equal to zero.
4660	Deceleration is less than or equal to zero.
4641	Buffer mode does not correspond to a valid enumeration value.
4642	Direction does not correspond to a valid enumeration value.
4893	The specified external axis may not be used. A physical axis is required.
10113	ERROR: Variable (ErrorID_10113_Description) is undefined.



57620

The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.


Example


E-Stops can result in the instantaneous loss of control of the axes. Manually clearing debris or scrap from the machine and adjustments after E-Stops and alarms can cause a change in motor position, all resulting in a de synchronization of the master and slave.

The example given below illustrates how the CamSlave_Recover block can solve E-Stop recovery issues. The logic analyzer plot shows the axes when the E-Stop occurred. At this point, the Y_CamIn outputs InSync and Busy change to FALSE. A slight drift in the master axis position can be seen after the E-Stop. This can be due to axis inertia, or because of adjustments made to the machine. The CamSlave_Recover block is executed to physically move the slave to the position that corresponds to the master's current position as determined by looking in the CamTable.

The distance that the slave axis traverses in this process can be seen in the illustration. Once the CamSlave_Recover is Done, the slave can be re-engaged with the master using Y_Camin.

Important: In this recovery condition, the 'EngagePosition' must be set to the master axis' current position and the EngageData.SlaveAbsolute=TRUE must be applied.








Cam Toolbox: Function Blocks



[41]	Master	5.0000000	
	Slave	4.3333330	E-Stop
[42]	Master	6.0000000	Master: 5.97
	Slave	5.6666670	Slave : 5.61
[43]	Master	7.0000000	
	Slave	7.0000000	
[44]	Master	7.1000000	
	Slave	7.1333060	
[45]	Master	7.2000000	
	Slave	7.2664440	
[46]	Master	7.3000000	
	Slave	7.3992430	
[47]	Master	7.4000000	
	Slave	7.5315240	
[48]	Master	7.5000000	
	Slave	7.6630960	
[49]	Master	7.6000000	
	Slave	7.7937530	
[50]	Master	7.7000000	
	Slave	7.9232730	
[51]	Master	7.8000000	After recovery
	Slave	8.0514140	
[52]	Master	7.9000000	Master: 7.8609
	Slave	8.1779140	Slave : 8.1285
[53]	Master	8.0000000	
	Slave	8.3024920	



CamSlave_WindowCheck



This function block is used by the CamSlave_FeedToLength function blocks to determine when the MC_TouchProbe output is valid and should be used for correction. It compares the CamTableOutput parameter 1520 to the SensorMinimum and SensorMaximum, not the actual slave feedback.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
V	Prms	AxisParameterStruct	User Defined DataType declared in the PLCopen Toolbox.	
VAR_INPUT				
B	Enable	BOOL	The function will continue to execute while enable is held high.	Default FALSE
V	ProductSize	LREAL	This value must be the same as the total one way index of the cam profile for this slave.	LREAL#0.0
V	SensorMinimum	LREAL	The earliest slave position where a sensor position is valid for correction.	LREAL#0.0
V	SensorMaximum	LREAL	The latest slave position where a sensor position is valid for correction.	LREAL#0.0
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
V	InWindow	BOOL	Indicates the slave output	



B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Notes

If SensorMinimum and SensorMaximum are both zero, this function does not check for a window and reports InWindow as TRUE.


For the most accurate WindowCheck, this function block must be in a fast application task. Since this function is used by CamSlave_WindowCheck, that block also should be used in a fast (high priority)

Error Description

ErrorID	Meaning
0	No error
10025	Might be crossed or the same non-zero value



CamTableManager



This function block serves as a FIFO buffer for CamTableID's. Each time a new CamTableID is created, it will delete the memory allocated to the oldest CamTable by using the Y_RemoveCamTable function block from the PLCOpenPlus firmware library. This function block is used to clean up memory in applications which build cam tables on the fly. A circular buffer of four cam tables is maintained in the CamTableManager. When the function block is executed a fifth time, it releases the memory area of the oldest cam table ID. The controller can allocate this memory area for new cam tables or application code.

Parameters

<u>*</u>	Parameter	Data Type	Description	
VAR_INPUT				Default
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
V	CamTableID	UINT	The most recent CamTableID create by Y_CamFileSelect or Y_CamStructSelect	UINT#0
VAR_OUTPUT				
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.	
B	Error	BOOL	Set high if error has occurred during the execution of the function	



			block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Notes



- This function block is unnecessary in applications which use a single, static cam table.
- See the [CamTableManager eLearning Module](#) on Yaskawa's YouTube Channel.

Error Description

ErrorID	Meaning
0	No error
4887	CamTableID does not refer to a valid cam table.

Example 1


An example of using the CamTableManager is shown below. On the fifth execute of the CamTableManager block, the memory for the oldest CamTable ID gets released. In the example shown below, the memory for CamID 1 gets released. The next execution of the CamTableManager will release the memory for CamID 2.



Variable	Value	De
CamTables		
[0]	1	
[1]	2	
[2]	3	
[3]	4	
[4]	5	


Memory for Cam ID 1 gets cleared

Application Example





CamTableUpdate



This function block aids with cam file management when on the fly changes to the table data are required. It supports two tables: one which may be actively running in the motion engine, and one that may be recalculated and transferred to the motion engine. It contains the Y_CamStructSelect and Y_WriteCamTable function blocks.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
B	Slave	AXIS_REF	A logical reference to the slave axis	
B	CamTable	Y_MS_CAM_STRUCT	Cam data structure	
V	TableIDs	TableIDStruct	Contains an Active and Inactive TableID	
VAR_INPUT				Default
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
VAR_OUTPUT				
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable'	



			input, and reset if Done, CommandAborted, or Error is true.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Notes


- If both TableIDs in the TableIDs input are zero, then this block automatically uses Y_CamStructSelect to send the first CamTable and obtain the CamTableID.
- If the event causing the cam tables to update is fired too frequently, this block limits the cam table transfer and swap by holding in a Busy state while the previous table transferred is still waiting to become the active table. In this way, it helps to stage the table swapping so that the application does not resort to writing over an active table, which can cause the slave to jump.

Example 1:

In this example, it is assumed that some event has occurred which triggers the need for a new cam table to be generated using CamGenerator. CamGenerator in turn fires CamTableUpdate to send the new CamTable to the motion engine. CamTableUpdate manages the active and inactive TableIDs, which can then be used with Y_CamIn. The Table.Active variable will contain the TableID of the last table transferred, so the next time the rising edge of Y_CamIn is triggered, the new table will be used. This can be done while camming is currently engaged.




Cam Toolbox: Function Blocks



Example 2: Using Two Cam Tables

- One will be actively running the motion
- One will be "on deck" to take new changes



Error Description

ErrorID	Meaning
0	No error




Cam Toolbox: Function Blocks



4377	File reading already in progress
4378	The function block is not applicable for the external axis specified
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4387	Already copying cam data (If Execute transition to TRUE while Busy = TRUE)
4633	Table size results in misaligned data. Refer to the help section "Internally Created Cam Data." A cam table will have a multiple of 16 bytes if created correctly.
4634	Buffer size results in misaligned data
4635	Table type is not supported
4636	Invalid start index.
4637	Invalid end index
4885	Invalid header for the cam file. Cam tables must have a header indicating the number of rows, number of columns and a feed forward velocity flag.
4887	CamTableID does not refer to a valid cam table.



SlaveIndex_Lookup



This function block returns the array index value corresponding to the given slave position. This function block is used by [CamMasterLookup](#) to determine the equivalent master location for a given slave position.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
B	CamTable	Y_MS_CAM_STRUCT	Cam data structure	
VAR_INPUT			Default	
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
V	SlavePosition	LREAL	The position of the slave axis for which the corresponding master position is required.	LREAL#0.0
VAR_OUTPUT				
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or	



			'Enable' input, and reset if Done, CommandAborted, or Error is true.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.
V	SlaveIndex	UDINT	The array index of the Y_MS_CAM_STRUCT of the SlavePosition.

Notes

- The SlavePosition input should be a value between the maximum and minimum values of the slave’s position profile for the index value to be valid.
- If the SlavePosition input is a value between two slave positions in the cam table, the SlaveIndex will return the lower index.


Error Description

ErrorID	Meaning
0	No error
10045	SlavePosition not found in Y_MS_CAM_STRUCT

Example



Cam Toolbox: Function Blocks




The screenshot shows a Microsoft Excel spreadsheet with the following data:

	A	B	C	D	E	F	G	H	I	J	K	L
62	10.60	8.59										
63	10.70	8.66										
64	10.80	8.73										
65	10.90	8.79										
66	11.00	8.84										
67	11.10	8.89										
68	11.20	8.92										
69	11.30	8.95										
70	11.40	8.97										
71	11.50	8.98										
72	11.60	8.99										



SlaveRegistrationCheck



This function block was designed for use by the [CamSlave_FeedToLength](#), [CamSlave_FeedToLength2](#), and [CamSlave_PullToLength](#) function blocks. It monitors variables related to a cam slave index and fires the output "MakeCorrection" which can be connected to Y_SlaveOffset along with the AbsoluteCorrection output. The function also provides the interpolated value of the cam table output when the latch was detected.

Parameters

*	Parameter	Data Type	Description
VAR_IN_OUT			
B	Axis	AXIS_REF	Logical axis reference. This value can be located on the Configuration tab in the Hardware Configuration (logical axis number).
B	AxisPrm	AXIS_REF	See AxisParameterStruct definition in MotionBlock types folder



VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
B	DefaultSize	LREAL	Default length of the product in user units	LREAL#0.0
B	DistanceAfterLatch	LREAL	The desired additional travel distance after the registration mark is detected	LREAL#0.0
B	RecordedPosition	LREAL	Position where trigger event occurred (in user units [u]). Used with MC_TouchProbe.RecordedPosition.	LREAL#0.0
B	LatchInput	BOOL	Typically connected to MC_TouchProbe.Done, signals the function to calculate any required correction amount	FALSE
B	MissedLatchLimit	UINT	The number of consecutive product lengths that can occur without seeing a mark in the window. Valid sensor detections will reset the internal counter. The next valid sensor detection will reset the internal counter.	
V	MaxPosCorrection	LREAL	Limits the amount of positive correction that can be applied	
V	MaxNegCorrection	LREAL	Limits the amount of negative correction that can be applied	
V	SensorMinimum			
V	SensorMaximum			UINT#0 (interpreted as infinite)
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
V	ActualSize	LREAL	The actual indexed distance	
V	AbsoluteCorrection	LREAL	The absolute value of the slave offset for use with Y_SlaveOffset	
V	LatchTableReference	LREAL	The position of the latch corresponding to the cam table	
V	MakeCorrection	BOOL	Used to signal that the correction calculation is valid. Typically used in conjunction with Y_SlaveOffset.Execute. Note: this output will pulse for one scan.	
V	MissedLatch	UDINT	Cumulative number of latches missed	
V	LimitedPosCorrection	BOOL	Indicates that the MaxPosCorrection is limiting the required correction.	
V	LimitedNegCorrection	BOOL	Indicates that the MaxNegCorrection is limiting the required correction.	
V	MissedWindow	BOOL	Indicates that a latch occurred, but was ignored because it was outside the range of SensorMinimum and	



			SensorMaximum.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Notes

- This function block determines where in the cam profile the latch occurred and compares it to the expected location to make a determination about the correction required.
- This function block also monitors the travel distance of the slave, and if the slave traveled 10% more than the ProductDistance and no valid latch was detected, a missed mark is counted. If the number of consecutive missed marks equals the MissedLatchLimit input variable, ErrorID UINT#10021 is output.
- Set MissedLatchLimit=0 to disable monitoring for missed latches.
- Separate correction limits are provided for positive and negative to account for applications where it is not possible to make such corrections. For example, negative corrections typically cannot be applied to labeling applications because the material will become loose (slack).

Error Description

ErrorID	Meaning
0	No error
4377	File reading already in progress
4378	The function block is not applicable for the external axis specified
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4387	Already copying cam data (If Execute transition to TRUE while Busy = TRUE)
4633	Table size results in misaligned data. Refer to the help section "Internally Created Cam Data." A cam table will have a multiple of 16 bytes if created correctly.
4634	Buffer size results in misaligned data
4635	Table type is not supported
4636	Invalid start index.
4637	Invalid end index
4885	Invalid header for the cam file. Cam tables must have a header indicating the number of rows, number of columns and a feed forward velocity flag.
4887	CamTableID does not refer to a valid cam table.
10020	ProductSize cannot be less than or equal to zero
10021	Maximum allowed consecutive missed registration marks reached



[10086](#)

MaxPosCorrection must be zero or positive, MaxNegCorrection must be zero or negative.



Communications Toolbox


Communications Toolbox

The Communications Toolbox contains functions to provide advanced communication protocols such as DNS, SMTP, and FTP. Also included in the toolbox are a set of functions designed to parse a stream of commands and parameter data from either a serial port or TCP socket into useful machine commands.

Command Streaming Overview

The following graphic shows the organizational flow of functions that are part of the command streaming feature. Certain components of the Command Streaming code require customization for use in your project. The following must be copied from the toolbox, pasted, and renamed in your project.

1. ReName_Communications_Mgr POU
2. ReNameCommandProcessor
3. MyMachineStruct and any relevant sub structures. This may be significantly customized based on your application.



The command streaming tools provided in the Comm Toolbox are designed to interpret commands starting with a two character command code followed by either delimiter separated parameters or no parameters. Example commands are provided in this documentation.



FTP Datatype Customization:

If the file used with FTP needs to be increased in size, both the byte array declaration and the "MAXLENGTH" parameter of FILE_READ in FTP_SendFile need to be changed.

If more than 10 recipients are needed then the declaration of RecipientArray needs to be changed to reflect that.



Getting Started: Communications

Requirements for v201

To use the Communications Toolbox, your project must also contain the following:

Firmware libraries:

- YDeviceComm
- PROCONOS

User libraries:

- Yaskawa_Toolbox (v204 or higher)



Communications Toolbox: DataTypes Communications Revision History



Current Version:

***** 2013-09-02: v201 released. Requires firmware 2.2.0 and the YDeviceComm firmware library

1) ReName_CommandProcessor - Changed logic to call a sub function "GetCommand" to reduce the amount of code that

resides on the user project side.

Previous Versions:

***** 2013-08-08: v200 released. Requires firmware 2.2.0 and the YDeviceComm firmware library

1) First release, includes Email, FTP, and Command Processing functions



Data Types

Data Type: SMTP_Data

Data Type Declaration

TYPE

SMTP_Data : STRUCT

DNSIP : YC_STRING16; (* DNS server IP (local), used to perform lookup of mail server domain *)

DNSPort : UINT; (* DNS port, default is 53, leave blank unless other port is used *)

SMTPDomain : YC_STRING128; (* SMTP server domain name (e.g. smtp.yourcompany.com), used for DNS lookup *)

SMTPIP : YC_STRING16; (* The IP of the SMTP server, blank by default, provide IP to override DNS lookup *)

SMTPPort : UINT; (* SMTP port, usually 25 - note: does not support SSL encrypted SMTP *)

LocalIP : YC_STRING16; (* Local IP of the controller *)

Domain : YC_STRING128; (* Domain for SMTP EHLO/HELO command, example: yaskawa.com *)

Sender : YC_STRING128; (* Sender e-mail address, example: john_smith@yaskawa.com *)

SenderName : YC_STRING32; (* Name of sender, example: John Smith *)

Subject : YC_STRING128; (* Subject of email, example: How awesome is the e-mail function block? *)

RcptArray : rcpt_array; (* Array of rcpt_struct (up to 10, or change datatype declaration), email and name *)

NumRcpt : INT; (* Number of emails in rcpt_array *)

Timeout : TIME; (* Timeout for connecting to the SMTP server, defaults to 5s *)

END_STRUCT;

END_TYPE

Code Example

```
smtpdata.LocalIP := '192.168.1.1';
```



Communications Toolbox: DataTypes



```
smtpdata.SMTPDomain      := 'smtp.example.com';

smtpdata.Domain          := 'example.com';

smtpdata.Sender           := 'johnsmith@example.com';

smtpdata.SenderName       := 'John Smith';

smtpdata.Subject          := 'Hello from your MP2300iec';

smtpdata.RcptArray[0].email := 'yourfriend@othercompany.com';

smtpdata.RcptArray[0].name  := 'Your Friend';

smtpdata.NumRcpt           := 1;
```



Data Type: FTP_Data

Data Type Declaration

TYPE

FTP_Data : STRUCT

Username : YC_STRING32; (* Username to log in to the FTP server *)

Password : YC_STRING32; (* Password to log in to the FTP server *)

LocalIP : YC_STRING16; (* Local IP of the controller *)

FTPDdomain : YC_STRING128; (* The domain name of the FTP server that will be resolved via DNS *)

FTPIP : YC_STRING16; (* The IP of the FTP server if a domain is not known or set *)

FTPPort : UINT; (* The port to connect to the FTP server through, default 21 *)

DNSIP : YC_STRING16; (* The DNS lookup server IP *)

DNSPort : UINT; (* The DNS port to connect through, default 53 *)

Timeout : TIME; (* Timeout for connecting to the FTP server or data connection, default 5s *)

END_STRUCT;

END_TYPE

Code Example

```
ftpdata.LocalIP := '192.168.1.1';
```

```
ftpdata.FTPDomain := 'ftp.example.com';
```

```
ftpdata.DNSIP := '8.8.8.8';
```

```
ftpdata.Username := 'mp2300';
```

```
ftpdata.Password := 'securepassword';
```



Data Type: CircularBufferStruct

Data Structure used to manage a circular buffer of data used by multiple function blocks.

Data Type Declaration

```
CircularBufferStruct:STRUCT
```

```
StorePointer:INT; (* FB Output - Pointer updated when new elements added to buffer *)
```

```
UsePointer:INT; (* FB Output - Pointer updated when elements of buffer have been read *)
```

```
Size:INT; (* User Input - Size of circular buffer *)
```

```
CmdDelimiters:DelimiterArray; (* User Input - Delimiters separating Command Strings. Default is carriage  
return or carriage return line feed *)
```

```
PrmDelimiter:YTB_STRING1; (* User Input - Delimiters separating parameters within a command. Default is a  
comma *)
```

```
LastDelimiter:INT; (* Element used by GetCommand *)
```

```
Data:YTB_ByteArray8192;
```

```
END_STRUCT;
```



Data Type: CommStruct

For use with [CommunicationChannel](#) function block. Contains information about the communication interface used.

Data Type Declaration

```
CommStruct: STRUCT
```

```
CommType:INT; (* Set 1 for Serial, 2 for Ethernet *)
```

```
InactivityTimeout:TIME; (* Use this to allow the MPiec to close the socket if no communication has been received on the channel in the time required. *)
```

```
BufferSize:UDINT; (* number of bytes to read per scan from Ethernet buffer, if left at 0 entire buffer will be transferred *)
```

```
Serial:SerialConfig;
```

```
Ethernet:EthernetConfig;
```

```
END_STRUCT;
```




Data Type: DelimiterArray

Supporting array for [CircularBufferStruct](#)

Data Type Declaration

DelimiterArray: ARRAY[0..3] OF BYTE;



Data Type: EthernetConfig

Supporting data structure for CommStruct, contains information about Ethernet interface configuration.

Data Type Declaration

```
EthernetConfig: STRUCT
```

```
LocalIPAddress:STRING; (* User Input – Ethernet address of controller *)
```

```
LocalPort:UINT; (* User Input – Ethernet port number to open*)
```

```
RemoteIPAddress:STRING;
```

```
RemotePort:UINT;
```

```
END_STRUCT;
```



Data Type: RecipientArray

If more than 10 recipients are needed then the declaration of RecipientArray needs to be changed to reflect that.

Data Type Declaration

TYPE

RecipientArray : ARRAY[0..9] OF RecipientStruct;

END_TYPE



Data Type: RecipientStruct

TYPE

RecipientStruct : STRUCT

Email : YC_STRING128;

Name : YC_STRING32;

END_STRUCT;

END_TYPE



Data Type: SerialConfig

Supporting data structure for CommStruct, contains information about Serial interface configuration.

Data Type Declaration

SerialConfig: STRUCT

PortNum:UINT; (* For use with the Y_OpenSerialPort function block *)

BaudRate:DINT; (* For use with the Y_SetDeviceOption function block *)

DataBits:DINT; (* For use with the Y_SetDeviceOption function block *)

StopBits:DINT; (* For use with the Y_SetDeviceOption function block *)

Parity:DINT; (* For use with the Y_SetDeviceOption function block *)

HandShake:DINT; (* For use with the Y_SetDeviceOption function block *)

END_STRUCT;



Enumerated Types

Enumerated Type: COM_Type

Enum Type for CommType

Data Type Declaration

COM_Type:(na,Serial,Ethernet); (* Enumerated type to be used with CommStruct.CommType *)



Enumerated Type: Method

Enum Type for [GetParameter](#) Method


Data Type Declaration

Method:(Parameter,Character); (* For use with the GetParameter function. Specifies how the value is obtained. *)



Function Blocks

CommunicationChannel



The CommunicationChannel function block is designed to manage an input stream of data from either a serial or TCP socket communication interface. It collects portions of data from Y_ReadDevice each time that function's Done output goes high, and add it to a circular buffer for further analysis. The CommConfig structure must be initialized by the user to configure the necessary communication parameters.

Parameters

* _	Parameter	Data Type	Description	
VAR_IN_OUT				
B	CircularByteBuffer	CircularBufferStruct	Structure containing a data buffer and other operational information required to manage the CircularByteBuffer.	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
B	CommConfig	CommStruct	Structure containing information to be used in establishing socket or serial communication	



B	ClearBuffer	BOOL	Clears all contents of the circular buffer and resets StorePointer and UsePointer	FALSE
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
B	Socket	DINT	File handle to be used when writing to device connected to the socket. Only valid when non-zero	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	

Error Description

ErrorID	Meaning
0	No error
8705	The maximum number of concurrently open user IO devices (sockets/files) has been reached.
8706	The socket handle was invalid.
8707	The IP address string was not in a valid format.
8708	The socket could not be created.
8709	The specified address or port is already in use on the local network.
8710	The specified address or port is not available for use.
8711	Unable to accept new socket connection.
8712	Unable to bind to the specified address.
8713	The socket type argument was invalid.
8714	The local address or port was not valid.
8715	The socket could not be connected.
8716	There is no network routing path to the specified address.
8717	The socket is already connected to another endpoint.
8718	The socket connection attempt was actively refused by the remote peer.
8719	The socket was not connected to a remote endpoint. Call Y_ConnectSocket prior to Y_ReadDevice or Y_WriteDevice.
8720	An error occurred trying to get or set the device option.
8721	The communication device could not be read.
8722	The communication device could not be written.
8723	The Buffer argument to WriteDevice and ReadDevice is required.
8724	The device option ID was invalid.
8725	The device option value was not the right size or the data was out of range.



8726	The serial port ID was not a valid serial port.
8727	The serial port could not be opened.
10022	Product or circular buffer overrun / full
10023	Buffer size too small / cannot be zero

Setup

Follow these steps to initialize the CommConfig structure. Steps 1 & 2 show an optional easy way for the IEC application to automatically obtain its own IP Address. One of the inputs required for the Y_DeviceComm basic functions is the controllers own IP Address. This is necessary because the MPiec controller may have more than one physical Ethernet connector / MAC address, and the YDeviceComm functions need to know which interface to use. Steps 1 & 2 mean the user will not be required to manually type in the controllers IP address for each system deployed.

1. Add a variable of type CONTROLLER_INFO to Global Variables as shown below. The Address must be %MD3.66560.

Name /	Type	Usage	Description	Address
Controller	CONTROLLER_INFO	VAR_GLOBAL		%MD3.66560

2. Add the following code to the initialize routine to obtain controller's IP address. The variable IPAddress is a STRING. The BUF_TO_STRING function block is located in the PROCONOS firmware library. As shown below, we are using it to extract 15 bytes of the IPAddress. These bytes equate to xxx.xxx.xxx.xxx of the IP Address.

```

50  BUF_TO_STRING      (* Get the controller IP address *)
51  (
52      REQ:=TRUE,
53      BUF_FORMAT:=TRUE,
54      BUF_OFFS:=DINT#0,
55      BUF_CNT:=DINT#17,
56      BUFFER:=Controller.Network.Interface[1].IPAddress,
57      DST:=IPAddress
58  );
59  Controller.Network.Interface[1].IPAddress:=BUF_TO_STRING.BUFFER;
60  IF BUF_TO_STRING.DONE THEN
61      IPAddress:=BUF_TO_STRING.DST;
62  END_IF;

```

3. Initialize variable of data type CommStruct as shown below. Set .LocalPort to the desired connection port number that you choose to use in your application. If multiple sockets will be used, ensure they each have a unique port number.


```

67  CommConfig.CommType:=COM_Type#Ethernet;
68  CommConfig.Ethernet.LocalIPAddress:=IPAddress;
69  CommConfig.Ethernet.LocalPort:=UINT#5000;

```



DNS_LookUp



This function block performs a DNS lookup for a provided domain name (Address) using a specified DNS IP and port and returns the number of answers, the resolved IPV4 address and the Time To Live of the returned IP.

Parameters

*_	Parameter	Data Type	Description	Default
VAR_INPUT				
B	Execute	BOOL	Upon the rising edge, all inputs are read and the DNS lookup is performed. To perform a lookup on a different address or perform the same lookup again, change the value and re-trigger the execute input.	
V	LocalIP	YC_STRING16	The IP address of the controller on the local network.	
V	Address	YC_STRING128	The domain name to perform the look-up on (not an IPV4 address).	
V	DNSIP	YC_STRING16	The IP address of the DNS server to perform the lookup through.	
V	DNSPort	UINT	The port to connect to the DNS server through.	UINT#53
E	TimeOut	TIME	The amount of time the DNS server has to respond.	TIME#5s
VAR_OUTPUT				
B	Done	BOOL	Set high upon the completion of a successful DNS lookup.	



B	Busy	BOOL	Set high upon the rising edge of 'Execute' and reset if Done or Error is true.
B	Error	BOOL	Set high if an error has occurred during the DNS lookup. Cleared upon 'Execute' being reset.
B	ErrorID	UINT	If error is true, this output provides the Error ID. Cleared upon 'Execute' being reset.
E	NumAnswers	INT	The number of answers returned by the DNS server. The answer with the longest TTL is output at 'IP'
E	TTL	UDINT	The Time To Live of the DNS response (i.e. how long the DNS server caches the answer from the authoritative nameserver instead of reissuing the query).
V	IP	YC_STRING16	The 'IP' with the longest TTL that was returned by the DNS server that resolves to the domain name provided.

Notes

- 'Address' must be a domain name (i.e. yaskawa.com), not an IPV4 address. Passing an IPV4 address is what is referred to as a "reverse DNS lookup" and is not supported by this block (reason: the Y_DeviceComm library needs an IPV4 address, not a domain name).
- What DNS server(s) your controller has access to depends on the network configuration. If you do not have a local DNS server (see "Setup" below) talk to your IT professional about what DNS server options you have.
- The main purpose of this block is use in other Communications blocks, such as FTP and SMTP.

Setup

In order to perform a DNS lookup a connection to a DNS server must first be established. What DNS server you configure this block to use depends on your particular network set up. The easiest way to determine what DNS server to use (or at least to get started) is to open up the Windows command prompt (Windows Key + R -> "cmd" -> Enter) and type "ipconfig /all" and under "DNS Servers" in the Ethernet LAN section you will find the DNS server(s) that your computer is configured to use.



```

C:\WINDOWS\system32\cmd.exe
yaskawa.com
ybad.ad.yaskawa.com
ybad.com
ydev.com
drives.com

Ethernet adapter VMware Network Adapter VMnet8:

Connection-specific DNS Suffix . : 
Description . . . . . : VMware Virtual Ethernet Adapter for VMnet8
Physical Address. . . . . : 00-50-56-C0-00-08
Dhcp Enabled. . . . . : No
IP Address. . . . . : 192.168.214.1
Subnet Mask . . . . . : 255.255.255.0
Default Gateway . . . . . :

Ethernet adapter VMware Network Adapter VMnet1:

Connection-specific DNS Suffix . : 
Description . . . . . : VMware Virtual Ethernet Adapter for VMnet1
Physical Address. . . . . : 00-50-56-C0-00-01
Dhcp Enabled. . . . . : No
IP Address. . . . . : 192.168.88.1
Subnet Mask . . . . . : 255.255.255.0
Default Gateway . . . . . :

Ethernet adapter Wireless Network Connection:

Media State . . . . . : Media disconnected
Description . . . . . : Intel(R) WiFi Link 5100 AGN
Physical Address. . . . . : 00-24-D6-77-02-00

Ethernet adapter Local Area Connection:

Connection-specific DNS Suffix . : ad.yaskawa.com
Description . . . . . : Intel(R) 82567LM Gigabit Network Connection
Physical Address. . . . . : 00-26-B9-97-2F-4A
Dhcp Enabled. . . . . : Yes
Autoconfiguration Enabled . . . . . : Yes
IP Address. . . . . : 192.168.201.36
Subnet Mask . . . . . : 255.255.255.0
Default Gateway . . . . . : 192.168.201.253
DHCP Server . . . . . : 192.168.5.10
DNS Servers . . . . . : 192.168.5.10
                          192.168.5.11
Lease Obtained. . . . . : Wednesday, October 24, 2012 8:21:53 AM
Lease Expires . . . . . : Thursday, October 25, 2012 8:21:53 AM

F:\>

```

You can also perform DNS lookups from the command line which may help in verifying the results of the DNS lookup performed on the controller while setting this block up.



```
C:\WINDOWS\system32\cmd.exe

F:\>nslookup athena.yaskawa.com
Server: hqdc1.ad.yaskawa.com
Address: 192.168.5.10

Non-authoritative answer:
Name: athena.yaskawa.com
Address: 192.168.8.3

F:\>nslookup nothing.yaskawa.com
Server: hqdc1.ad.yaskawa.com
Address: 192.168.5.10

*** hqdc1.ad.yaskawa.com can't find nothing.yaskawa.com: Non-existent domain

F:\>nslookup google.com
Server: hqdc1.ad.yaskawa.com
Address: 192.168.5.10

Non-authoritative answer:
Name: google.com
Addresses: 74.125.225.131, 74.125.225.128, 74.125.225.130, 74.125.225.132,
          74.125.225.134, 74.125.225.142, 74.125.225.135, 74.125.225.133, 74.125.
          .225.136, 74.125.225.137, 74.125.225.129

F:\>_
```

The basic command structure is "nslookup [hostname] [server]" where hostname and server are both optional (if you simply type "nslookup" -> Enter it takes you in to the nslookup utility where you can then perform multiple lookups without retyping "nslookup"). For example, typing "nslookup google.com" as in the image above returns a list of IP addresses resolved for "google.com". You can also perform the lookup using a specified DNS server address which can be helpful if your block is using a different DNS server than your computer is configured to use. This is done by filling in the second optional parameter, such as "nslookup google.com 8.8.8.8" where "8.8.8.8" is a public DNS server managed by Google.



```

C:\WINDOWS\system32\cmd.exe
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\kevin_hull>nslookup google.com 8.8.8.8
Server:  google-public-dns-a.google.com
Address:  8.8.8.8

Non-authoritative answer:
Name:     google.com
Addresses: 74.125.225.136, 74.125.225.134, 74.125.225.128, 74.125.225.130
          74.125.225.135, 74.125.225.131, 74.125.225.132, 74.125.225.142, 74.125
          .225.133
          74.125.225.129, 74.125.225.137

C:\Documents and Settings\kevin_hull>_

```

Error Description


ErrorID	Meaning
0	No error
8705	The maximum number of concurrently open user IO devices (sockets/files) has been reached.
8706	The socket handle was invalid.
8707	The IP address string was not in a valid format.
8708	The socket could not be created.
8709	The specified address or port is already in use on the local network.
8710	The specified address or port is not available for use.
8711	Unable to accept new socket connection.
8712	Unable to bind to the specified address.
8713	The socket type argument was invalid.
8714	The local address or port was not valid.
8715	The socket could not be connected.
8716	There is no network routing path to the specified address.
8717	The socket is already connected to another endpoint.
8718	The socket connection attempt was actively refused by the remote peer.
8719	The socket was not connected to a remote endpoint. Call Y_ConnectSocket prior to Y_ReadDevice or Y_WriteDevice.
8720	An error occurred trying to get or set the device option.
8721	The communication device could not be read.
8722	The communication device could not be written.
8723	The Buffer argument to WriteDevice and ReadDevice is required.




8724	The device option ID was invalid.
8725	The device option value was not the right size or the data was out of range.
8726	The serial port ID was not a valid serial port.
8727	The serial port could not be opened.
12000	Read response timeout, no response was received within the supplied TimeOut
12010	Not a response (QR should be 1 but it was 0)
12011	Response was truncated because it extended beyond the 512byte UDP packet size
12012	Recursive is not available but was requested by the Query packet
12021	Format error, the name server was unable to interpret the query
12022	Server failure, the name server was unable to process the query due to an internal problem
12023	Name error, not valid for this block (only valid for Authoritative servers)
12030	Address length was less than 3 characters which is not possible
12031	Address format was incorrect as it does not contain a '.'

Example - External Address

The following example demonstrates the blocks ability to perform a lookup for an external address ("google.com") using an internal DNS server. The LocalIP, Address and DNSIP have all be configured and DNSPort and TimeOut have been left to defaults.






If you compare the output of the block ("74.125.225.131") to the nslookup performed above you will find that this IP address is in the list. You can also see that NumAnswers is set to 11 which also matches the number of answers returned above. Finally, the TTL is 0x0000012C which corresponds to 300 in decimal where 300s = 5 min, if you were to add the "Debug" option to nslookup ("nslookup -d google.com") then you would see that this TTL also matches.



FTP_SendFile



This function block uses the FTP (File Transfer Protocol) to send a file on the controller to a specified FTP server.

Parameters

*	Parameter	Data Type	Description	Default
VAR_INPUT				Default
B	Execute	BOOL	Upon the rising edge, all inputs are read and the file transfer is performed. To resend the file or send a different file, change the value(s) and re-trigger the execute input.	
V	File	YC_STRING128	The full file name and location on the controller, e.g. '/flash/user/data/example.csv'.	
V	Destination	YC_STRING64	The full file name and destination on the FTP server, e.g. 'metrics/example.csv'.	
V	FTPData	FTP_Data	The input structure that configures the FTP transfer such as FTP server address, port, etc.	
VAR_OUTPUT				
B	Done	BOOL	Set high upon the completion of a successful file transfer.	
B	Busy	BOOL	Set high upon the start of the file transfer and low upon 'Done' or 'Error' becoming true.	
B	Error	BOOL	Set high when an error occurs during the file transfer. Set low upon Execute being reset.	
B	ErrorID	BOOL	If 'Error' is true, this output provides the Error ID. Cleared upon 'Execute' being reset.	
V	ErrorString	YC_STRING256	If 'Error' is true and it is an FTP response code related error then this output contains the response string from the FTP server.	



Notes

- This block utilizes FTP, not SFTP as SSL is not currently supported in the firmware. As a result, all FTP traffic sent and received (e.g. username, password, file data) is sent **unencrypted** in **plain text** and is therefore visible to anyone with access to your internal network. However, this should not be a problem so long as the data you are sending is not of a sensitive matter and your FTP server account is CHROOT'd properly (talk to your IT professional about using FTP).
- It is suggested that your FTP server either have a internal/external domain name OR use a static IP address as a change in address will prevent the block from transferring files. See "Setup" for more details.
- Your FTP user account for this block must have "Write" privileges to be able to write files to the server. Optionally, your account may also have "Append" privileges. Note that if your destination files already exists and your user only has "Write" then the file will be overwritten. If the file exists and your user has "Append" then the file contents transferred will be appended to the existing file.

Error Description

ErrorID	Meaning
0	No error
8705	The maximum number of concurrently open user IO devices (sockets/files) has been reached.
8706	The socket handle was invalid.
8707	The IP address string was not in a valid format.
8708	The socket could not be created.
8709	The specified address or port is already in use on the local network.
8710	The specified address or port is not available for use.
8711	Unable to accept new socket connection.
8712	Unable to bind to the specified address.
8713	The socket type argument was invalid.
8714	The local address or port was not valid.
8715	The socket could not be connected.
8716	There is no network routing path to the specified address.
8717	The socket is already connected to another endpoint.
8718	The socket connection attempt was actively refused by the remote peer.
8719	The socket was not connected to a remote endpoint. Call Y_ConnectSocket prior to Y_ReadDevice or Y_WriteDevice.
8720	An error occurred trying to get or set the device option.
8721	The communication device could not be read.
8722	The communication device could not be written.
8723	The Buffer argument to WriteDevice and ReadDevice is required.



8724	The device option ID was invalid.
8725	The device option value was not the right size or the data was out of range.
8726	The serial port ID was not a valid serial port.
8727	The serial port could not be opened.
12200	Connect to FTP server timeout, no connection was established within the supplied TimeOut
12201	Connect to FTP data socket timeout, no connection was established within the supplied TimeOut
12202	QUIT error, there was an error sending the 'QUIT' command to the server
12203	The credentials for the FTP server were incorrect (either one or both username and password)
12300	File Error, no error information available
12301	Invalid file handle
12302	Maximum number of files are already opened
12304	File is already opened
12305	File is write protected or access denied
12306	File name not defined
12310	End of data reached
12312	The number of characters to be read from file is greater than the data buffer
12322	No data could be read from file
12421	Service not available, closing control connection. This may be a reply to any command if the service knows it must shut down.
12425	Can't open data connection.
12426	Connection closed; transfer aborted.
12430	Invalid username or password
12434	Requested host unavailable
12450	Requested file action not taken / Requested mail action not take (mailbox unavailable)
12451	Requested action aborted. Local error in processing
12452	Requested action not taken, insufficient storage space in system (FTP: File unavailable)
12500	Syntax error, command unrecognised
12501	Syntax error in parameters or arguments
12502	Command not implemented
12503	Bad sequence of commands
12504	Command not implemented for that parameter
12521	[domain] does not accept mail
12530	Not logged in / Access denied
12532	Need account for storing files
12550	Requested action not taken. File unavailable (e.g., file not found, no access) / Mailbox unavailable
12551	Requested action aborted. Page type unknown / User not local
12552	Requested file action aborted, exceeded storage allocation / Requested mail action aborted, exceeded storage allocation



12553	Requested action not taken, file name not allowed / mailbox name not allowed
12554	Transaction failed

Basic Functionality Example - Transferring a File

This examples demonstrates how to configure the block using the data structure, create a file to send and execute the FTP_SendFile block.

Here is the code in the "Initialize" ST program which configures the file data and the FTP structure. The FTP server is hosted on a local computer and does not have a domain name. Therefore, FTPIP was used and FTPPort was left blank as the local FTP server is configured to use the default port of 21. The LocalIP is set to the controllers IP and the username/password combination are set.


```
(* Sample file contents *)
sample_file_data := 'This is a sample file to be sent from an MP2300Siec to a local network computer via FTP';

(* FTP setup structure *)
FTP_Test_Data.FTPIP := '192.168.201.36';
FTP_Test_Data.LocalIP := '192.168.207.205';
FTP_Test_Data.Password := 'anon';
FTP_Test_Data.Username := 'anon';
```


This program works by creating a file via the PROCONOS File_Open, String_to_Buf, File_Write and File_Close blocks. The contents of the file in "sample_file_data" is converted from a YC_STRING128 to YC_BYTE128 via the "SAMPLE_TO_BUF" block. Once the file is created the destination file name is prepared and the FTP block sends the file to the server.



(* Prepare file to send *)




(* Send example.txt via FTP *)






The destination folder is empty to begin with and the FTP server log has been cleared prior to connection so that the results will be obvious.




The PrepareFile contact is set true as is the Execute contact. Once both contacts are TRUE, the FTP_SendFile block sends the newly created file.



(* Prepare file to send *)



(* Send example.txt via FTP *)





The results of this block can be seen in the destination file explorer and the FTP server log:

The screenshot shows two windows. The top window is Windows Explorer, displaying the 'metrics' folder at 'C:\Documents and Settings\logan_smith\My Documents\metrics'. A file named 'sample_2012-10-24' is listed with a size of 1 KB and a type of Text Document, modified on 10/24/2012 at 10:32 AM. A Notepad window is open over the file, containing the text: 'This is a sample file to be sent from an MP2300S1ec to a local network computer via FTP'. The bottom window is FileZilla Server (127.0.0.1), showing a log of the transfer process. The log includes the following entries:

```

(000061)10/24/2012 10:32:26 AM - (not logged in) (192.168.207.205)> Connected, sending welcome message...
(000061)10/24/2012 10:32:26 AM - (not logged in) (192.168.207.205)> 220 Welcome to logan_smith file server - FileZilla Server version 0.9.41 beta
(000061)10/24/2012 10:32:27 AM - (not logged in) (192.168.207.205)> USER anon
(000061)10/24/2012 10:32:27 AM - (not logged in) (192.168.207.205)> 331 Password required for anon
(000061)10/24/2012 10:32:27 AM - (not logged in) (192.168.207.205)> PASS ****
(000061)10/24/2012 10:32:27 AM - anon (192.168.207.205)> 230 Logged on
(000061)10/24/2012 10:32:28 AM - anon (192.168.207.205)> TYPE A
(000061)10/24/2012 10:32:28 AM - anon (192.168.207.205)> 200 Type set to A
(000061)10/24/2012 10:32:28 AM - anon (192.168.207.205)> PASV
(000061)10/24/2012 10:32:28 AM - anon (192.168.207.205)> 227 Entering Passive Mode (192,168,201,36,39,17)
(000061)10/24/2012 10:32:29 AM - anon (192.168.207.205)> STOR /metrics/sample_2012-10-24.txt
(000061)10/24/2012 10:32:29 AM - anon (192.168.207.205)> 150 Connection accepted
(000061)10/24/2012 10:32:29 AM - anon (192.168.207.205)> 226 Transfer OK
(000061)10/24/2012 10:32:30 AM - anon (192.168.207.205)> QUIT
(000061)10/24/2012 10:32:30 AM - anon (192.168.207.205)> 221 Goodbye
(000061)10/24/2012 10:32:30 AM - anon (192.168.207.205)> disconnected.

```

The FileZilla Server window also shows a table with columns for ID, Account, IP, Transfer, Progress, and Speed. The status bar at the bottom indicates 'Ready' with '5,985 bytes received' and '1,750 bytes sent'.

The contents of the file match the "sample_file_data" string and the file can be seen in the explorer. In the FTP server log all of the commands sent can be viewed and it can be seen that the file was transferred properly and successfully.

Advanced Functionality Example - Transferring a Metrics File at a Specified Rate




This examples demonstrates how to write a program to send a continuously updated metrics file (with date and time stamp) to an FTP server. This kind of functionality is extremely useful to applications requiring data acquisition as the need to connect to the controller directly is eliminated and file management is handled by the controller. For this example, the controller will continuously sample the speed and position of a servo that is jogging and the store the contents in a CSV file using the File_RW Toolbox.


The same data configuration structure was used but there is no preset message for the file as it will be created dynamically.

```
(* FTP setup structure *)
FTP_Test_Data.FTPIP := '192.168.201.36';
FTP_Test_Data.LocalIP := '192.168.207.205';
FTP_Test_Data.Password := 'anon';
FTP_Test_Data.Username := 'anon';
```

In addition to the Communications Toolbox, two additional Yaskawa toolboxes are used: File_RW_Toolbox and PLCOpen_Toolbox. The File_RW_Toolbox is used to create the CSV file that is uploaded to the FTP server and the PLCOpen_Toolbox is used to control the single servo used in this example.



Controlling this example is very simple. The servo is turned on by "ServoEnable" which then in turn starts the jog at a constant velocity. The rest of the example is controlled in the main program:





This entire program is enabled by the "MetricsEnable" contact which starts two timers: the 30 second timer which sends the CSV file and the 1 second timer which takes a sample of the current position and velocity of the servo. The filename is generated each time the file is uploaded so that the timestamp is up to date and no files are overwritten.


The results of this example can be monitored by exploring the target upload directory and examining the FTP server log:

```
(000074)11/12/2012 16:46:02 PM - (not logged in) (192.168.207.205)> Connected, sending welcome message...
(000074)11/12/2012 16:46:02 PM - (not logged in) (192.168.207.205)> 220 Welcome to logan_smith file server - FileZilla Server version 0.9.41 beta
(000074)11/12/2012 16:46:02 PM - (not logged in) (192.168.207.205)> USER anon
(000074)11/12/2012 16:46:02 PM - (not logged in) (192.168.207.205)> 331 Password required for anon
(000074)11/12/2012 16:46:02 PM - (not logged in) (192.168.207.205)> PASS ****
(000074)11/12/2012 16:46:02 PM - anon (192.168.207.205)> 230 Logged on
(000074)11/12/2012 16:46:02 PM - anon (192.168.207.205)> TYPE A
(000074)11/12/2012 16:46:02 PM - anon (192.168.207.205)> 200 Type set to A
(000074)11/12/2012 16:46:02 PM - anon (192.168.207.205)> PASV
(000074)11/12/2012 16:46:02 PM - anon (192.168.207.205)> 227 Entering Passive Mode (192,168,201,36,39,23)
(000074)11/12/2012 16:46:02 PM - anon (192.168.207.205)> STOR metrics/data_2012-11-12_17-44-18.csv
(000074)11/12/2012 16:46:02 PM - anon (192.168.207.205)> 150 Connection accepted
(000074)11/12/2012 16:46:02 PM - anon (192.168.207.205)> 226 Transfer OK
(000074)11/12/2012 16:46:02 PM - anon (192.168.207.205)> QUIT
(000074)11/12/2012 16:46:02 PM - anon (192.168.207.205)> 221 Goodbye
(000074)11/12/2012 16:46:02 PM - anon (192.168.207.205)> disconnected.
```

Name	Size	Type	Date Modified
data_2012-11-12_17-35-40	1 KB	Microsoft Office Exc...	11/12/2012 4:37 PM
data_2012-11-12_17-36-10	1 KB	Microsoft Office Exc...	11/12/2012 4:37 PM
data_2012-11-12_17-36-41	1 KB	Microsoft Office Exc...	11/12/2012 4:38 PM
data_2012-11-12_17-37-11	1 KB	Microsoft Office Exc...	11/12/2012 4:38 PM
data_2012-11-12_17-37-42	1 KB	Microsoft Office Exc...	11/12/2012 4:39 PM
data_2012-11-12_17-38-12	0 KB	Microsoft Office Exc...	11/12/2012 4:39 PM
data_2012-11-12_17-38-43	1 KB	Microsoft Office Exc...	11/12/2012 4:40 PM
data_2012-11-12_17-39-13	1 KB	Microsoft Office Exc...	11/12/2012 4:40 PM
data_2012-11-12_17-39-44	1 KB	Microsoft Office Exc...	11/12/2012 4:41 PM
data_2012-11-12_17-40-14	1 KB	Microsoft Office Exc...	11/12/2012 4:42 PM
data_2012-11-12_17-40-45	1 KB	Microsoft Office Exc...	11/12/2012 4:42 PM
data_2012-11-12_17-41-15	1 KB	Microsoft Office Exc...	11/12/2012 4:43 PM
data_2012-11-12_17-41-46	0 KB	Microsoft Office Exc...	11/12/2012 4:43 PM



GetCommand



The GetCommand function block is a supporting function block for the ReName_CommandProcessor function block. It extracts a CommandString from the CircularByteBuffer as identified by the CmdDelimiter specified in the CircularByteBuffer structure.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
V	CircularByteBuffer	CircularBufferStruct	Structure containing a data buffer and other operational information required to manage the CircularByteBuffer.	
V	CommandString	YTB_STRING512	Input string containing at least two bytes of command characters and any optional parameters separated by a PrmDelimiter.	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
VAR_OUTPUT				
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when	




			execute goes low.
B	CommandCreated	BOOL	Indicates that the CommandString VAR_IN_OUT contains a new CommandString.
B	CommandCode	INT	Integer value corresponding to the first two ASCII characters of the CommandString.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Error Description

ErrorID	Meaning
0	No error
10165	CommandString length is too long or command delimiter not found.



GetParameter



The GetParameter function block provides a single parameter Value extracted from the CommandString. This is supporting function block for use within the CommandProcessor function block.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
V	CommandString	YTB_STRING512	Input string containing parameters separated by delimiters. such as MV;1.0;-10.5;3.007	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
V	Delimiter	YTB_STRING1	String value of the character separating parameters within the CommandString	BYTE#44 (comma - ',')
B	Number	INT	Depending on Method input,	INT#0



			either the number of the parameter value to be found or	
B	Method	Method	ERROR: Variable (ParameterDescription_Method) is undefined.	Method#Parameter
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
E	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	
V	Value	STRING	Value of the parameter being searched for	
V	EndChar	INT	Last character position in the CommandString to be searched	

Notes

- There are two methods available with this function block; Values can be fetched via Parameter (Delimiter) count or by StartCharacter. The Parameter method always counts delimiters from the beginning of the CommandString to explicitly return the correct Value. If this Function block is executed in WHILE loop situation, it is more efficient to specify the next StartCharacter as the Number Input by feed the previous EndChar back into the function block.
- If Method = Method#Parameter, GetParameter will search through the command string to find the parameter corresponding to the Number input. This method is useful for commands with fewer parameters or when parameters are being read non-sequentially.
 - Example: CommandString = 'MV,2,4,6' Delimiter = ',' Number = 2
When Valid = TRUE, Value = 4
- If Method = Method#Character, GetParameter will search the command string for the next parameter starting at the character location equal to the Number input. The EndChar output can be used as feedback to the Number input to find the next parameter. This method is useful when parameters are being read sequentially and provides a large performance increase when parsing a CommandString with a large number of parameters.
 - Example: CommandString = 'MV,2,4,6' Delimiter = ',' Number = 5
When Valid = TRUE, Value = 4, EndChar = 7
- Further examples of both methods provided in ReName_CommandProcessor customization section.


Error Description



ErrorID	Meaning
0	No error
10160	CommandString length is invalid
10162	Parameter being searched for is out of range
10163	Mode input not valid
10164	Invalid character position input



InputBufferManager



The InputBufferManager function block manages a circular buffer of incoming data. It is a supporting function block for the CommunicationChannel function block. A user should not need to access this function directly.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
V	InputBuffer	YTB_ByteArray2048	Byte array containing data to be copied into the CircularByteBuffer.	
V	CircularByteBuffer	CircularBufferStruct	Structure containing a data buffer and other operational information required to manage the CircularByteBuffer.	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
V	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	INT#0
V	BytesRead	UDINT	Number of bytes to be copied from InputBuffer to CircularByteBuffer.	UDINT#0
V	ClearBuffer	BOOL	Clears all contents of the circular buffer and resets StorePointer and UsePointer	INT#0
VAR_OUTPUT				



B	Valid	BOOL	Indicates that the outputs of the function are valid.
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
E	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Notes


This is a hybrid function block that incorporates both PLCOpen specified behaviors: Enable and Execute. This was mainly done to separate two types of initialization: one that occurs when the Enable goes high, and another that occurs only when the Execute goes high.

Error Description

ErrorID	Meaning
0	No error
10022	Product or circular buffer overrun / full
10023	Buffer size too small / cannot be zero



ReName_CommandProcessor



The ReName_CommandProcessor function block is a user customizable function block that parses data from a circular buffer and copies it into a user defined structure which will be used to operate the machine.

Parameters

*_	Parameter	Data Type	Description	
VAR_IN_OUT				
V	MachineData	MyMachineStruct	A user customizable structure containing machine data used in processing commands.	
V	CircularByteBuffer	CircularBufferStruct	Structure containing a data buffer and other operational information required to manage the CircularByteBuffer.	
VAR_INPUT			Default	
B	Enable	BOOL	The function will continue to	FALSE



			execute while enable is held high.
VAR_OUTPUT			
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.
V	CommandCount	UDINT	Number of commands that have been processed since this function block was enabled.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Notes

- This function block is a template for designing a unique command line interpreter and requires customization. See the customization steps below.
- The command streaming tools provided in the Comm Toolbox are designed to interpret commands starting with a two character (two byte) command code followed by either delimiter separated parameters or no parameters. The reason for this is because two ASCII bytes can easily be converted to an INT, which is used with the CASE statement in this function block. Example commands are located in the customization steps below.

Error Description

ErrorID	Meaning
0	No error
10160	CommandString length is invalid
10161	Invalid CommandCode
10162	Parameter being searched for is out of range
10163	Mode input not valid
10164	Invalid character position input

Customization Steps

1. Copy this Function block from the Comm Toolbox, paste it into your project, and rename with a different (but similar) name.



- Data type MyMachineStruct (VAR_IN_OUT 'MachineData') is only an example structure. A custom structure must be designed to uniquely match the needs of the application. An example is shown below.

```

223     PositionArray : ARRAY[1..50] OF LREAL;
224
225     CommandStruct: STRUCT
226         Enable:BOOL;
227         HomeReg:BOOL;
228         StartMoveRelative:BOOL;
229         MoveRelativeSpeed:LREAL;
230         MoveRelativeAccel:LREAL;
231         MoveRelativeDist :LREAL;
232     END_STRUCT;
233
234     Monitor: STRUCT
235         Position: LREAL;
236         Velocity: LREAL;
237         Torque: LREAL;
238     END_STRUCT;
239
240     MotorDataStruct: STRUCT
241         Num:AXIS_REF;
242         Command: CommandStruct;
243         Monitor: Monitor;
244         LoadPosition: PositionArray;
245     END_STRUCT;
246
247     MotorDataArray : ARRAY[1..5] OF MotorDataStruct;
248
249     MachineInfo: STRUCT
250         Estop :BOOL;
251         ClearAlarms :BOOL;
252         RunMode :INT; (* machine running state *)
253         Conveyer : MotorDataStruct;
254         Arm : MotorDataArray;
255     END_STRUCT;

```

- Change the 'MachineData' DataType in the CommandProcessor function block to match your structure name.

MachineData	MachineInfo	VAR_IN_OUT
-------------	-------------	------------

- Initialize the configuration elements in CircularByteBuffer.

```

67 CBuffer.CmdDelimiters[0] := BYTE#13;
68 CBuffer.Size := INT#8192;
69 CBuffer.PrmDelimiter := ',';

```

- CmdDelimiters are used to mark the end of a complete command. Up to four characters can be specified. Typically, <cr>, which is BYTE#13 or <cr><lf>, which is BYTE#13 BYTE#10 are used. If CmdDelimiters not specified, will default functionality will automatically accept Carriage Return or Carriage Return & Line Feed.
- PrmDelimiter specifies the character that separates individual parameters within a command. If PrmDelimiter is not specified, the function will automatically default to a comma, (BYTE#44).
- Size must represent the defined size of the DataType definition for the CircularBufferStruct's "Data? Element. If Size not specified, it will default to zero and the InputBufferManager function



block will cause an error. Normally, this value is 8192 as the structure definition is in the Comm Toolbox itself. If this must be increased for any reason, modify the Comm Toolbox DataType definition and set the Size input accordingly.

- 5. Locate the comments "Customize the code below?" and "Customize the code above?"
- 6. Remove example commands to avoid potential errors in operation.

```

131      (*****
132      (*****                                     Customize the code below
133      (*****
134
135      CASE CommandCode OF
136
137          (* insert new commands here *)
138
139      ELSE
140          Error_UnsupportedCommand:=TRUE;
141      END_CASE; (* CommandCode *)
142
143      (*****
144      (*****                                     Customize the code above
145      (*****

```

- 7. Add your commands. Two examples are shown below:

a. Move Relative command

- a. MR,<axisnumber>,<distance>,<speed>,<accel/decel>
- b. Calculate the CommandCode which corresponds to the ASCII characters 'MR'. The equation is: CHAR_TO_INT('M') * 256 + CHAR_TO_INT('R') = 19794.
- c. Add the CommandCode to the case statement.
- d. Use the GetParameter function block to separate command parameters. The example below uses GetParameter with "Method#Parameter?"

```

19794 : (* MR - Move Relative *);
FOR ParameterIndex := 1 TO 4 DO
  GetParameter.CommandString:=CommandString;
  GetParameter(Number:=ParameterIndex, Method := Method#Parameter);
  CommandString:=GetParameter.CommandString;
  IF ( GetParameter.Valid := TRUE ) THEN
    CASE ParameterIndex OF
      1: AxisNum := STRING_TO_INT(GetParameter.Value);
      2: MachineData.Arm[AxisNum].Command.MoveRelativeDist := STRING_TO_LREAL(GetParameter.Value);
      3: MachineData.Arm[AxisNum].Command.MoveRelativeSpeed:= STRING_TO_LREAL(GetParameter.Value);
      4: MachineData.Arm[AxisNum].Command.MoveRelativeAccel:= STRING_TO_LREAL(GetParameter.Value);
      MachineData.Arm[AxisNum].Command.StartMoveRelative:= TRUE;
    END_CASE;
  END_IF;
END_FOR;

```

b. Load Positions command

- a. LP,<Position1>,<Position2>,...,<Position50>
- b. Calculate the CommandCode which corresponds to the ASCII characters 'LP'. The equation is: CHAR_TO_INT('L') * 256 + CHAR_TO_INT('P') = 19536
- c. Add the CommandCode to the case statement.



- d. Use the GetParameter function block to separate command parameters. The example below uses GetParameter with "Method#Character?"

```
19536 : (* LP - Load Positions *)
CharacterIndex := 0;
FOR PositionCount := 1 TO 50 DO
  GetParameter.CommandString:=CommandString;
  GetParameter(Number:=CharacterIndex, Method := Method#Character?);
  CommandString:=GetParameter.CommandString;
  CharacterIndex:= GetParameter.EndChar;
  IF ( GetParameter.Valid := TRUE ) THEN
    MachineData.Conveyor.LoadPosition[PositionCount] := STRING_TO_LREAL(GetParameter.Value);
  END_IF;
END_FOR;
```

Optional Customization Steps

The CommandProcessor can process one or many commands per scan. This is a performance tuning issue. If the host device must send several setting at once, the MPiec controller may seem slow to process all the commands based on the Task interval. If the Task Interval and priority are set such that the CommandProcessor will have time to continue scanning the CircularByteBuffer in one scan until ALL bytes have been processed, performance will be improved by changing the following CommandProcessor code:

1. Remove AND NOT(CommandCreated) from main WHILE loop as shown

```
40
41   WHILE (CircularByteBuffer.StorePointer <> CircularByteBuffer.UsePointer) (*AND NOT(CommandCreated)*) DO
42     CommandCreated:=FALSE;
```

none



ReName_CommunicationsMgr


ReName_CommunicationsMgr is a reference POU showing the recommended setup of the command stream features.

Customization Required:

1. Find the ReNameCommandProcessor Function Block and change the DataType of MachineData VAR_IN_OUT in accordance with a custom structure that you will create for your application.
2. The only other area that may require customization is located under the comment "Prepare to create the Response Output for the Command Channel". Once a connection has been established, the Y_WriteDevice function block can be used to send a buffer of data (monitor information or command responses for example) back to the device issuing commands.



SendEmail



This function block sends an e-mail via SMTP commands (Simple Mail Transfer Protocol) through a specified SMTP server. The output is highly configurable including multiple recipients, any message body structure, specified sender e-mail and name and other features listed below.

Parameters

*	Parameter	Data Type	Description
VAR_IN_OUT			
V	MessageData	SMTP_Data	A user customized data structure for configuring the e-mail block.
V	MessageBody	YC_BYTE4096	The e-mail body as a 4096 element byte array. If a larger body is required, this declaration can be changed and the library recompiled.
VAR_INPUT			Default
B	Execute	BOOL	Upon the rising edge, all inputs are read and the e-mail(s) is sent. To resend the e-mail or send a different file, change the value(s) and re-trigger the execute input.
E	BodyLength	UDINT	The length (number of bytes) of the e-mail body that will be sent. While not necessary it is highly suggested, see notes below.
VAR_OUTPUT			
B	Done	BOOL	Set high upon successfully sending an e-mail.
B	Busy	BOOL	Set high upon the start of communications with the SMTP



			server and low when 'Done' or 'Error' go high.
B	Error	BOOL	Set high when an error occurs during e-mail configuration and sending. Set low upon Execute being reset.
B	ErrorID	UINT	If Error is true, this output provides the ErrorID. Cleared upon 'Execute' being reset.
V	ErrorString	YC_STRING256	If 'Error' is true and it is an SMTP response code related error then this output contains the response string from the SMTP server.

Notes

- This block does not support SSL SMTP servers and therefore will most likely only work with local network SMTP servers. Talk with your IT professional about connecting to a local SMTP server from an MPiec Series Controller (see "Setup" below for more details about the required configuration).
- While "BodyLength" input is optional, it is highly suggested that you pass this variable to the block as it reduces packet size and the potential for large amounts of padding ("0") bytes on the recipients side. All examples include this Input and demonstrate how to get the correct length even in more complicated configurations.

Error Description

ErrorID	Meaning
0	No error
8705	The maximum number of concurrently open user IO devices (sockets/files) has been reached.
8706	The socket handle was invalid.
8707	The IP address string was not in a valid format.
8708	The socket could not be created.
8709	The specified address or port is already in use on the local network.
8710	The specified address or port is not available for use.
8711	Unable to accept new socket connection.
8712	Unable to bind to the specified address.
8713	The socket type argument was invalid.
8714	The local address or port was not valid.
8715	The socket could not be connected.
8716	There is no network routing path to the specified address.
8717	The socket is already connected to another endpoint.
8718	The socket connection attempt was actively refused by the remote peer.
8719	The socket was not connected to a remote endpoint. Call Y_ConnectSocket prior to Y_ReadDevice or Y_WriteDevice.



8720	An error occurred trying to get or set the device option.
8721	The communication device could not be read.
8722	The communication device could not be written.
8723	The Buffer argument to WriteDevice and ReadDevice is required.
8724	The device option ID was invalid.
8725	The device option value was not the right size or the data was out of range.
8726	The serial port ID was not a valid serial port.
8727	The serial port could not be opened.
12100	Connect to SMTP server timeout, no connection was established within the supplied TimeOut
12101	DATA portion of e-mail was not successful and therefore the e-mail may not send/be malformed
12102	QUIT error, there was an error sending the 'QUIT' command to the server
12103	NumRcpt cannot equal 0.
12421	Service not available, closing control connection. This may be a reply to any command if the service knows it must shut down.
12425	Can't open data connection.
12426	Connection closed; transfer aborted.
12430	Invalid username or password
12434	Requested host unavailable
12450	Requested file action not taken / Requested mail action not take (mailbox unavailable)
12451	Requested action aborted. Local error in processing
12452	Requested action not taken, insufficient storage space in system (FTP: File unavailable)
12500	Syntax error, command unrecognised
12501	Syntax error in parameters or arguments
12502	Command not implemented
12503	Bad sequence of commands
12504	Command not implemented for that parameter
12521	[domain] does not accept mail
12530	Not logged in / Access denied
12532	Need account for storing files
12550	Requested action not taken. File unavailable (e.g., file not found, no access) / Mailbox unavailable
12551	Requested action aborted. Page type unknown / User not local
12552	Requested file action aborted, exceeded storage allocation / Requested mail action aborted, exceeded storage allocation
12553	Requested action not taken, file name not allowed / mailbox name not allowed
12554	Transcation failed

Example



As this is a complicated function, additional examples are provided in separate help files listed under "Additional Examples" and prefixed with "SMTP_". The example shown here sets up the block, creates a message body and sends an e-mail to external Gmail account.


The variable EmailBodyString is of type YC_STRING256. Below is the configuration of the SMTP_Data structure:

```
(* E-mail Setup *)
EmailBodyString := 'This is a test message being sent via SMTP protocol initiated by an MP2300Siec controller.';


EmailData.DNSIP := '192.168.5.10';
EmailData.Domain := 'YASKAWA';
EmailData.LocalIP := '192.168.207.205';
EmailData.NumRcpt := INT#1;
EmailData.RcptArray[0].name := 'Logan Smith';
EmailData.RcptArray[0].email := '██████████';
EmailData.Sender := 'logan_smith@yaskawa.com';
EmailData.SenderName := 'MP2300Siec';
EmailData.SMTPDomain := 'athena.yaskawa.com';
EmailData.Subject := 'Test message from your MP2300Siec';
```

The most basic form of sending an e-mail is simply converting a string to a byte array via the STRING_TO_BUF function block provided in the PROCONOS firmware library. With the data structure shown above and this STRING_TO_BUF block, the email is configured and ready for use.

(* Pass the message into a buffer *)



(* Send the message *)




After toggling PrepareMessage, here is the result.




Communications Toolbox: Function Blocks


(* Pass the message into a buffer *)



(* Send the message *)




And to demonstrate the end result, here is the e-mail in the inbox of the Gmail account used. The sender and subject are both listed correctly and a portion of the send message can be seen.





UpdatePointer



The UpdatePointer function block is a supporting function block referenced by the GetCommand function block. It updates the UsePointer of the CircularByteBuffer structure.

Parameters

*_	Parameter	Data Type	Description
VAR_IN_OUT			
V	CircularByteBuffer	CircularBufferStruct	Structure containing a data buffer and other operational information required to manage the CircularByteBuffer.



File Read Write Toolbox

File_RW Toolbox

The File Read / Write Template is different than the other toolboxes because some of the main functions must be customized for use in every application.

The four main functions in this library are:

- Write_Binary_File
- Write_CSV_File
- Read_Binary_File
- Write_CSV_File

To use any of these functions, they must be copied and pasted into your main project as a function block with a different (but similar) name. To do this, copy and paste the structured text and the variable definitions grid from the toolbox version. These four main functions refer to other sub functions in the File Read Write toolbox, which do not require customization and can remain in the File Read Write Toolbox. There is no need to move the following function blocks:

- Read_Buffer
- Read_Line
- Read_Value

More detailed customization information and examples are provided for the help for each of the functions blocks mentioned above.

See Yaskawa's Youtube Webinar - [CSV File Transfer with the File_RW Template](#).



Getting Started: File_RW

Requirements for v202

To use the File_RW Template, your project must also contain the following:

Firmware libraries:

- PROCONOS

User libraries:

- Yaskawa_Toolbox (v204 or higher)

Using the File_RW Template

See Yaskawa's Youtube Webinar - [CSV File Transfer with the File_RW Template](#) for more info.



File_RW Revision History

Current Version:

(*****
2013-09-02 v202 released. Created using 2.4.0 firmware
*****)

- 1) ReadValue - Added "OR (x = DataBuffer.Length)" to cause EOF flag even if the <CR> is not the last byte in a line.
- 2) Read_CSV_File & Write_CSV_File - Added PreStringError 10017 to detect if the controller already has a String Conversion alarm posted before the function blocks execute.

Previous Versions:



Data Types

Data Type: ByteBufferStruct

Data Type Declaration

TYPE

ByteBufferStruct: STRUCT

Char: ByteArray4096;

FilePosition:DINT;

Length:UINT;

END_STRUCT;

END_TYPE;



Data Type: MyDataStruct

This datatype MyDataStruct and its two supporting user defined datatypes (MyData and MyDataArray) must be copied and pasted into your main project and customized to meet your specific data format.

Rename it in your main project to avoid naming conflicts, which will cause compile errors.

Data Type Declaration

TYPE

(***** Structure information relating to a CSV file
*****)

MyData : STRUCT

 XData : LREAL;

 YData : LREAL;

 ZData : LREAL;

END_STRUCT;

MyDataArray : ARRAY [UINT#0..UINT#300] OF MyData;

MyDataStruct: STRUCT

 File: MyDataArray;

 Version:STRING; (* If file versioning is used, apply a unique value to allow the identification of different file formats. *)

 Columns:INT; (* Configure this value to indicate the number of columns in the data file. *)

 Records:INT; (* This value will be updated by the function as the data is processed. *)

 MaxRecords:INT; (* Initialize MaxRecords to the NUMBER OF ELEMENTS defined in the MyDataArray definition above. *)

END_STRUCT;

END_TYPE;



Data Type: SeparatorList

Optional SeparatorList can be populated by values corresponding to ASCII characters that represent the delimiters between data in columns. For example the TAB character is BYTE#09. If no separators are specified, the function block will default to searching for comma (BYTE#44.)

Data Type Declaration

TYPE


SeparatorList:ARRAY[0..4] OF BYTE; (* User can select up to four characters that will be used as value Separators, like comma, semicolon, etc. *)

END_TYPE;



Function Blocks

Read_CSV_File



This function block will read CSV (ASCII) data from a file on the controllers flash or ram disk. The raw file data will be parsed and copied into a user defined data structure. This function block requires customization to accommodate application specific data requirements. Any variety of rows and columns and datatypes can be specified.

Parameters

*	Parameter	Data Type	Description
VAR_IN_OUT			
V	Data	MyDataStruct	A user customized data structure containing the definition of the rows and columns of data to be processed.
VAR_INPUT			
V	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.
V	FileName	STRING	The file to be read. Example
			Default
			FALSE
			STRING#"



			STRING#'flash/user/data/mydata.csv'	
V	Separators	SeparatorList	Optional. If unconnected, the default separator is a comma (BYTE#44) to detect each value column by column. If a different or multiple characters must be treated as a value separator, populate the SeparatorList with up to four byte values equating to the ASCII value of the separators.	Comma (BYTE#44)
V	HeaderRows	UINT	Optional. If connected, the value indicates the number of rows this function block must ignore before starting to look for actual data.	UINT#0
V	VerifyVersion	BOOL	Optional. If TRUE, this function block will expect the first line of the file to contain a version code for identifying the data format of the file, i.e columns, datatypes, etc.. This allows for future changes to the MyDataStruct while retaining the ability to parse older files created before a change was made to the structure of the file.	FALSE
V	BufferSize	UDINT	Specifies the number of bytes in the file to process at one time. If unconnected, the default is 2048 bytes. BufferSize can be adjusted up or down if necessary to accommodate various file sizes and will depend upon the CYCLIC task in which the Read_CSV_File function block is executed.	UDINT#2048
VAR_OUTPUT				
E	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	
V	ErrorRow	INT	If Error is true and pertains to a problem with the source data, this value will indicate the location of processing when the error occurred.	
E	ErrorCol	INT	If Error is true and pertains to a problem with the source data, this value will indicate the location of processing when the error occurred.	



Notes

- Don't forget to include the ProConOS firmware library in the project. It is required for this function block.
- The filename must conform to 8.3 format, but is not case sensitive.
- Any separator can be specified provided it is an ASCII byte, and will not be confused with the actual data.
- Header rows are not required to contain the same number of separators as the data content. (Separators are not checked in the header rows.)
- It takes 6 scans per processing of each BufferSize of data. If a file has 20480 bytes, and the BufferSize is 2048, and the function block is placed in a 100mSec scan, then the total time to process the file will be 60 scans, or 6 seconds. $(20480/2048 * 6 * 100) = 6000$ mSec.
- See Yaskawa's Youtube Webinar - [CSV File Transfer with the File_RW Template](#).

Error Description

ErrorID	Meaning
0	No error
4	File is already open.
5	File is opened, write protected or access denied.
6	File name not defined.
10	End of data reached.
12	The number of characters to be read is greater than the data buffer.
13	Invalid positioning mode or position specified is before the beginning of the file.
20	File could not be closed.
22	No data could be read.
24	Position could not be set.
10117	String Conversion Error already exists on the controller. Clear the alarm and try again.
10118	STRING_TO_BUF Conversion Error
10119	In the Data Structure, rows must be set greater than zero and columns must be set greater than zero.
10120	File could not be opened.
10121	CSV file contains an unsupported version.
10122	Row Error. The data is out of sync with the expected row / column arrangement expected.
10123	Column Start Error. The data is corrupted.
10124	Unsupported Case condition.
10125	Conversion Error. Check the ErrorRow and ErrorCol outputs for details



10126	NoDataError - The End Of File was reached, but the record count is zero
10127	TooManyRecords - DataType is not large enough
10128	MaxNotDefined - User must set the maximum number of records that can be added to structure.
10129	No Carriage return found in CSV buffer. The function searched the file for twice the length of the specified buffer and was unable to find a carriage return indicating the end of a row. Either the buffer size is too small, or the data is invalid.

Example Customization

Read_CSV_File must be customized to accommodate your data. Some supporting functions used by Read_CSV_File (ReadBuffer and ReadValue) do not require customization and can remain in the File_RW_Toolbox. To effectively use this function, follow these steps:

- 1) Copy & paste the MyDataStruct and associated datatypes into your project, and rename them to avoid conflict with MyDataStruct in the File_RW_Template.

```

64  (***** Structure information relating to a CSV file *****)
65  MyData : STRUCT
66      XData : LREAL;
67      YData : LREAL;
68      ZData : LREAL;
69  END_STRUCT;
70
71  MyDataArray : ARRAY [UINT#0..UINT#300] OF MyData;
72
73  MyDataStruct: STRUCT
74      File: MyDataArray;
75      Version:STRING; (* If file versioning is used, apply a unique value to allow the identification of different file formats *)
76      Columns:INT; (* Configure this value to indicate the number of columns in the data file. *)
77      Records:INT; (* This value will be updated by the function as the data is processed *)
78      MaxRecords:INT; (* Initialize MaxRecords to the NUMBER OF ELEMENTS defined in the MyDataArray definition above *)
79  END_STRUCT;
80
81  (***** Structure information relating to a CSV file *****)

```

- 2) Modify the "MyData" dataType definition shown above such that it represents the number of columns and the relevant datatypes. An example follows:

```

2  (***** Job *****)
3  JobData : STRUCT
4      Move_X : DINT;
5      Move_Y : DINT;
6      Outs_O1 : DINT;
7      Outs_O2 : DINT;
8      Outs_O3 : DINT;
9      Vel_X : BYTE;
10     Acc_X : BYTE;
11     Vel_Y : BYTE;
12     ACC_Y : BYTE;
13     Execute : INT;
14     Jump : BYTE;
15     Wait : INT;
16     Loop : BYTE;
17     AltX : BYTE;
18     LinkTo : INT;
19  END_STRUCT;
20
21  JobArray : ARRAY [UINT#0..UINT#3399] OF JobData;
22
23  JobStruct: STRUCT
24      Job: JobArray;
25      Version:STRING; (* If file versioning is used, apply a unique value to allow the identification of different file formats *)
26      Columns:INT; (* Configure this value to indicate the number of columns in the data file. *)
27      Records:INT; (* This value will be updated by the function as the data is processed *)
28      MaxRecords:INT; (* Initialize MaxRecords to the NUMBER OF ELEMENTS defined in the MyDataArray definition above *)
29  END_STRUCT;
30
31  (***** Job *****)

```



File_RW Toolbox: Function Blocks



The 15 columns of data defined above relate to the data shown in the following Excel file. Notice that the data has three header rows before the actual data begins. In this case, set the HeaderRows function block input correctly at UINT#3, otherwise, the data will not be read properly.

	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
1	Move_x	Move_y	Outs_01	Outs_02	Outs_03	Vel_x	Acc_x	Vel_y	Acc_y	Execute	Jump	Wait	Loop	Alt_x	Link_to
2	0	0	0	0	0	0	0	0	0	0	0	0	0	0	-1
3	1E+08	1E+08	2.1E+09	2.1E+09	2.1E+09	100	100	100	100	999	100	9999	1	1	3400
4	1	1	1	0	3401	100	100	100	100	1	0	0	0	0	0
5	2	2	2	1	3400	100	100	100	100	1	0	0	0	0	0
6	3	3	3	2	3399	100	100	100	100	1	0	0	0	0	0
7	4	4	4	3	3398	100	100	100	100	1	0	0	0	0	0
8	5	5	5	4	3397	100	100	100	100	1	0	0	0	0	0
9	6	6	6	5	3396	100	100	100	100	1	0	0	0	0	0
10	7	7	7	6	3395	100	100	100	100	1	0	0	0	0	0
11	8	8	8	7	3394	100	100	100	100	1	0	0	0	0	0
12	9	9	9	8	3393	100	100	100	100	1	0	0	0	0	0
13	10	10	10	9	3392	100	100	100	100	1	0	0	0	0	0
14	11	11	11	10	3391	100	100	100	100	1	0	0	0	0	0
15	12	12	12	11	3390	100	100	100	100	1	0	0	0	0	0
16	13	13	13	12	3389	100	100	100	100	1	0	0	0	0	0
17	14	14	14	13	3388	100	100	100	100	1	0	0	0	0	0
18	15	15	15	14	3387	100	100	100	100	1	0	0	0	0	0
19	16	16	16	15	3386	100	100	100	100	1	0	0	0	0	0
20	17	17	17	16	3385	100	100	100	100	1	0	0	0	0	0
21	18	18	18	17	3384	100	100	100	100	1	0	0	0	0	0
22	19	19	19	18	3383	100	100	100	100	1	0	0	0	0	0
23	20	20	20	19	3382	100	100	100	100	1	0	0	0	0	0
24	21	21	21	20	3381	100	100	100	100	1	0	0	0	0	0
25	22	22	22	21	3380	100	100	100	100	1	0	0	0	0	0
26	23	23	23	22	3379	100	100	100	100	1	0	0	0	0	0
27	24	24	24	23	3378	100	100	100	100	1	0	0	0	0	0
28	25	25	25	24	3377	100	100	100	100	1	0	0	0	0	0
29	26	26	26	25	3376	100	100	100	100	1	0	0	0	0	0
30	27	27	27	26	3375	100	100	100	100	1	0	0	0	0	0
31	28	28	28	27	3374	100	100	100	100	1	0	0	0	0	0
32	29	29	29	28	3373	100	100	100	100	1	0	0	0	0	0
33	30	30	30	29	3372	100	100	100	100	1	0	0	0	0	0
34	31	31	31	30	3371	100	100	100	100	1	0	0	0	0	0
35	32	32	32	31	3370	100	100	100	100	1	0	0	0	0	0
36	33	33	33	32	3369	100	100	100	100	1	0	0	0	0	0
37	34	34	34	33	3368	100	100	100	100	1	0	0	0	0	0
38	35	35	35	34	3367	100	100	100	100	1	0	0	0	0	0
39	36	36	36	35	3366	100	100	100	100	1	0	0	0	0	0


3) Initialize the data required for "MyDataStruct" as shown below. Most importantly, set Columns and MaxRecords.

```

12 ReadJobFile:= '/flash/user/data/job.csv';
13 WriteJobFile:= '/flash/user/data/JobW.csv';
14 JobData.Columns:=INT#15;
15 JobData.MaxRecords:=INT#3400; (* Set to same as DataType Definition *)

```

4) Copy & paste the Read_CSV_File function block into your main project so it can be customized. This will allow you to retain the original function in the template for future reference. Rename the function to avoid name conflict with Read_CSV_File in the Toolbox.



Variable	Value	Default value	Type
JobData			JobStruct
Job			JobArray
[0]			StruBlock
Move_X	1		DINT
Move_Y	1		DINT
Outs_01	1		DINT
Outs_02	0		DINT
Outs_03	3401		DINT
Vel_X	100		BYTE
Acc_X	100		BYTE
Vel_Y	100		BYTE
ACC_Y	100		BYTE
Execute	1		INT
Jump	0		BYTE
Wait	0		INT
Loop	0		BYTE
AltX	0		BYTE
LinkTo	0		INT
[1]			StruBlock
Move_X	2		DINT
Move_Y	2		DINT
Outs_01	2		DINT
Outs_02	1		DINT
Outs_03	3400		DINT
Vel_X	100		BYTE
Acc_X	100		BYTE
Vel_Y	100		BYTE
ACC_Y	100		BYTE
Execute	1		INT
Jump	0		BYTE
Wait	0		INT
Loop	0		BYTE
AltX	0		BYTE
LinkTo	0		INT
[2]			StruBlock

Customizing the code in the function block

- To customize the function block, go to the variables grid and rename the datatype used as the VAR_IN_OUT to the datatype you customized in step 2 above (Use the name as modified from ST code line 23 above).
- Locate the comments near the middle of the Read_CSV_File function indicating the area to be customized. Modify the lines that convert the STRING data from the file into the MyDataStruct structure.

```

151      TRUE      (* Data is ignored if HeaderRows are specified until after the specified number of header rows have been read. *)
152      IF ReadColumn.Valid AND HeaderRowsRead THEN
153
154      0          CASE UIN#3 OF (* Extract the CSV values from the file as specified by the VersionCode *)
155      (*-----*)      CUSTOMIZE THIS TEMPLATE BELOW TO ACCOMMODATE YOUR DATA AND TO ADD SUPPORT FOR DIFFERENT FILE OUTPUT VERSIONS      (*-----*)
156      (*-----*)      CUSTOMIZE THIS TEMPLATE BELOW TO ACCOMMODATE YOUR DATA AND TO ADD SUPPORT FOR DIFFERENT FILE OUTPUT VERSIONS      (*-----*)
157      (*-----*)      CUSTOMIZE THIS TEMPLATE BELOW TO ACCOMMODATE YOUR DATA AND TO ADD SUPPORT FOR DIFFERENT FILE OUTPUT VERSIONS      (*-----*)
158
159      0: (*-----*)      Non Versioned file format      (*-----*)
160
161      1          CASE ActiveColumn OF
162      1:Data.Job[Row].Move_X :=STRING_TO_DINT(ReadColumn.Value);      ActiveColumn:=ActiveColumn + INT#1;
163      2:Data.Job[Row].Move_Y:=STRING_TO_DINT(ReadColumn.Value);      ActiveColumn:=ActiveColumn + INT#1;
164      3:Data.Job[Row].Outs_01:=STRING_TO_DINT(ReadColumn.Value);      ActiveColumn:=ActiveColumn + INT#1;
165      4:Data.Job[Row].Outs_02:=STRING_TO_DINT(ReadColumn.Value);      ActiveColumn:=ActiveColumn + INT#1;
166      5:Data.Job[Row].Outs_03:=STRING_TO_DINT(ReadColumn.Value);      ActiveColumn:=ActiveColumn + INT#1;
167      6:Data.Job[Row].Vel_X:=STRING_TO_BYTE(ReadColumn.Value);      ActiveColumn:=ActiveColumn + INT#1;
168      7:Data.Job[Row].Acc_X:=STRING_TO_BYTE(ReadColumn.Value);      ActiveColumn:=ActiveColumn + INT#1;
169      8:Data.Job[Row].Vel_Y:=STRING_TO_BYTE(ReadColumn.Value);      ActiveColumn:=ActiveColumn + INT#1;
170      9:Data.Job[Row].ACC_Y:=STRING_TO_BYTE(ReadColumn.Value);      ActiveColumn:=ActiveColumn + INT#1;
171      10:Data.Job[Row].Execute:=STRING_TO_INT(ReadColumn.Value);      ActiveColumn:=ActiveColumn + INT#1;
172      11:Data.Job[Row].Jump:=STRING_TO_BYTE(ReadColumn.Value);      ActiveColumn:=ActiveColumn + INT#1;
173      12:Data.Job[Row].Wait:=STRING_TO_INT(ReadColumn.Value);      ActiveColumn:=ActiveColumn + INT#1;
174      13:Data.Job[Row].Loop:=STRING_TO_BYTE(ReadColumn.Value);      ActiveColumn:=ActiveColumn + INT#1;
175      14:Data.Job[Row].AltX:=STRING_TO_BYTE(ReadColumn.Value);      ActiveColumn:=ActiveColumn + INT#1;
176      15:Data.Job[Row].LinkTo:=STRING_TO_INT(ReadColumn.Value);      (* last one handled below *)
177      END_CASE;
178
179      1822      (*-----*)      CUSTOMIZE THIS TEMPLATE ABOVE TO ACCOMMODATE YOUR DATA AND TO ADD SUPPORT FOR DIFFERENT FILE OUTPUT VERSIONS      (*-----*)
180      (*-----*)      CUSTOMIZE THIS TEMPLATE ABOVE TO ACCOMMODATE YOUR DATA AND TO ADD SUPPORT FOR DIFFERENT FILE OUTPUT VERSIONS      (*-----*)
181      (*-----*)      CUSTOMIZE THIS TEMPLATE ABOVE TO ACCOMMODATE YOUR DATA AND TO ADD SUPPORT FOR DIFFERENT FILE OUTPUT VERSIONS      (*-----*)
182
183      2          ELSE
184      2:UnsupportedCase:=TRUE;
185      END_CASE;
186
187      IF ReadColumn.EOL THEN      (* The end of a row was detected *)
188      IF ActiveColumn=Data.Columns THEN      (* Set to the number of columns in the data *)
189      Row:=Row + INT#1;
190      Data.Records:=Row;
191      ActiveColumn:=INT#1;
192      ELSE
193      RowError:=TRUE;
194      END_IF;
195      1          END_IF;
196      3400
197      3400
198      Y_ReadAlarm_2(Enable:=TRUE);
199      IF Y_ReadAlarm_2.Valid THEN
200      ConversionError:=(Y_ReadAlarm_2.AlarmID = UDINT#16#340C0134);
201      END_IF;
202      END_IF;

```



File_RW Toolbox: Function Blocks Customizing for file versioning



The function has the capability to read multiple versions of the same file. For example, assume that initially, the design requires a data file to contain 4 columns of data to be used as INT. Later, after some machines are in the field, a design change requires that the data file must now contain 5 columns of DINT. If a version code is applied as the first row, the function block can determine how to read the file for any number of variations.

That may come later. This will allow the use of older data files as well as newer formats.

Original file specification

Modified file specification

```
original.txt - Notepad
File Edit Format View Help
20111118
3,4,7,4
234,456,344,3223
984,435,7346,333
123,4534233,9445
```

```
modified.txt - Notepad
File Edit Format View Help
20120105
767653,4786789,742323,4758656,78654
23645304,45456456,34756434,89076456,32923
98641214,4354395,7534111,7300846,3332439
1276543,4534233,9445,789786,90753
```

To use file versioning, follow the steps below:

1. Set the VerifyVersion function block input to TRUE.
2. The first line of the data file must contain a version code. The version code does NOT count as a header row. See the graphics above showing original and modified file specification
3. Customize the DataType to reflect the most current data specification.

Original DataType:

```
66 {***** JobRef *****}
67   PartData : STRUCT
68     Ref12 : INT;
69     Ref34 : INT;
70     Ref56 : INT;
71     Ref78 : INT;
72   END_STRUCT;
73
74   JobRefArray : ARRAY [UINT#0..UINT#401] OF PartData;
75
76   JobRefStruct: STRUCT
77     Ref: JobRefArray;
78     Version:STRING; (* If file versioning is used, apply a unique value to allow the identification of different file formats *)
79     Columns:INT; (* Configure this value to indicate the number of columns in the data file. *)
80     Records:INT; (* This value will be updated by the function as the data is processed *)
81     MaxRecords:INT; (* Initialize MaxRecords to the NUMBER OF ELEMENTS defined in the MyDataArray definition above *)
82   END_STRUCT;
83 {***** JobRef *****}
```

Modified DataType:



```

66 (***** JobRef *****)
67   PartData : STRUCT
68     Ref12 : DINT;
69     Ref34 : DINT;
70     Ref56 : DINT;
71     Ref78 : DINT;
72     Ref91 : DINT;
73   END_STRUCT;
74
75   JobRefArray : ARRAY [UINT#0..UINT#401] OF PartData;
76
77   JobRefStruct: STRUCT
78     Ref: JobRefArray;
79     Version:STRING; (* If file versioning is used, apply a unique value to allow the identification of different file formats *)
80     Columns:INT; (* Configure this value to indicate the number of columns in the data file. *)
81     Records:INT; (* This value will be updated by the function as the data is processed *)
82     MaxRecords:INT; (* Initialize MaxRecords to the NUMBER OF ELEMENTS defined in the MyDataArray definition above *)
83   END_STRUCT;
84 (***** JobRef *****)

```

3) Customize the Read-CSV_File function block to determine if the version code detected is supported.

Original code:

```

107 (***** MODIFY THIS TEMPLATE BELOW TO SUPPORT DIFFERENT FILE OUTPUT VERSIONS *****)
108 (***** MODIFY THIS TEMPLATE BELOW TO SUPPORT DIFFERENT FILE OUTPUT VERSIONS *****)
109 (***** MODIFY THIS TEMPLATE BELOW TO SUPPORT DIFFERENT FILE OUTPUT VERSIONS *****)
110
111 (* Verify that the file version matches one of the formats supported by this function (ADD MORE COMPARISONS AS NEEDED) *)
112 IF EQ_STRING(Data.Version, '20111118') THEN
113   VersionCode:=UINT#1;
114 END_IF;
115
116 (***** MODIFY THIS TEMPLATE ABOVE TO SUPPORT DIFFERENT FILE OUTPUT VERSIONS *****)
117 (***** MODIFY THIS TEMPLATE ABOVE TO SUPPORT DIFFERENT FILE OUTPUT VERSIONS *****)
118 (***** MODIFY THIS TEMPLATE ABOVE TO SUPPORT DIFFERENT FILE OUTPUT VERSIONS *****)

```

Modified code:

```

107 (***** MODIFY THIS TEMPLATE BELOW TO SUPPORT DIFFERENT FILE OUTPUT VERSIONS *****)
108 (***** MODIFY THIS TEMPLATE BELOW TO SUPPORT DIFFERENT FILE OUTPUT VERSIONS *****)
109 (***** MODIFY THIS TEMPLATE BELOW TO SUPPORT DIFFERENT FILE OUTPUT VERSIONS *****)
110
111 (* Verify that the file version matches one of the formats supported by this function (ADD MORE COMPARISONS AS NEEDED) *)
112 IF EQ_STRING(Data.Version, '20111118') THEN
113   VersionCode:=UINT#1;
114 ELSIF EQ_STRING(Data.Version, '20120105') THEN
115   VersionCode:=UINT#2;
116 END_IF;
117
118 (***** MODIFY THIS TEMPLATE ABOVE TO SUPPORT DIFFERENT FILE OUTPUT VERSIONS *****)
119 (***** MODIFY THIS TEMPLATE ABOVE TO SUPPORT DIFFERENT FILE OUTPUT VERSIONS *****)
120 (***** MODIFY THIS TEMPLATE ABOVE TO SUPPORT DIFFERENT FILE OUTPUT VERSIONS *****)

```

4) Customize the Read_CSV_File function block to read multiple versions.

Original code:

```

154 CASE UINT_TO_INT(VersionCode) OF (* Extract the CSV values from the file as specified by the VersionCode *)
155 (***** CUSTOMIZE THIS TEMPLATE BELOW TO ACCOMMODATE YOUR DATA AND TO ADD SUPPORT FOR DIFFERENT FILE OUTPUT VERSIONS *****)
156 (***** CUSTOMIZE THIS TEMPLATE BELOW TO ACCOMMODATE YOUR DATA AND TO ADD SUPPORT FOR DIFFERENT FILE OUTPUT VERSIONS *****)
157 (***** CUSTOMIZE THIS TEMPLATE BELOW TO ACCOMMODATE YOUR DATA AND TO ADD SUPPORT FOR DIFFERENT FILE OUTPUT VERSIONS *****)
158
159 1: (***** 20111118 file format *****)
160
161 CASE UINT_TO_INT(ActiveColumn) OF
162 1:Data.Ref[Row].Ref12:=STRING_TO_INT(ReadColumn.Value); ActiveColumn:=ActiveColumn + INT#1;
163 2:Data.Ref[Row].Ref34:=STRING_TO_INT(ReadColumn.Value); ActiveColumn:=ActiveColumn + INT#1;
164 3:Data.Ref[Row].Ref56:=STRING_TO_INT(ReadColumn.Value); ActiveColumn:=ActiveColumn + INT#1;
165 4:Data.Ref[Row].Ref78:=STRING_TO_INT(ReadColumn.Value); (* last one handled below *)
166 END_CASE;
167
168
169 (***** CUSTOMIZE THIS TEMPLATE ABOVE TO ACCOMMODATE YOUR DATA AND TO ADD SUPPORT FOR DIFFERENT FILE OUTPUT VERSIONS *****)
170 (***** CUSTOMIZE THIS TEMPLATE ABOVE TO ACCOMMODATE YOUR DATA AND TO ADD SUPPORT FOR DIFFERENT FILE OUTPUT VERSIONS *****)
171 (***** CUSTOMIZE THIS TEMPLATE ABOVE TO ACCOMMODATE YOUR DATA AND TO ADD SUPPORT FOR DIFFERENT FILE OUTPUT VERSIONS *****)
172 ELSE
173   UnsupportedCase:=TRUE;
174 END_CASE;

```

Modified code:



File_RW Toolbox: Function Blocks

```


152 CASE UINT_TO_INT(VersionCode) OF (* Extract the CSV values from the file as specified by the VersionCode *)
153 {*****
154 CUSTOMIZE THIS TEMPLATE BELOW TO ACCOMODATE YOUR DATA AND TO ADD SUPPORT FOR DIFFERENT FILE OUTPUT VERSIONS *****
155 {*****
156 CUSTOMIZE THIS TEMPLATE BELOW TO ACCOMODATE YOUR DATA AND TO ADD SUPPORT FOR DIFFERENT FILE OUTPUT VERSIONS *****
157
158 1: {***** 20111118 file format *****}
159
160 CASE UINT_TO_INT(ActiveColumn) OF
161 1:Data.Ref[Row].Ref12:=STRING_TO_DINT(ReadColumn.Value); ActiveColumn:=ActiveColumn + INT#1;
162 2:Data.Ref[Row].Ref34:=STRING_TO_DINT(ReadColumn.Value); ActiveColumn:=ActiveColumn + INT#1;
163 3:Data.Ref[Row].Ref56:=STRING_TO_DINT(ReadColumn.Value); ActiveColumn:=ActiveColumn + INT#1;
164 4:Data.Ref[Row].Ref78:=STRING_TO_DINT(ReadColumn.Value); ActiveColumn:=ActiveColumn + INT#1;
165 5:Data.Ref[Row].Ref78:=DINT#0; (* Initialize new data *) (* last one handled below *)
166 END_CASE;
167
168 2: {***** 20120105 file format *****}
169
170 CASE UINT_TO_INT(ActiveColumn) OF
171 1:Data.Ref[Row].Ref12:=STRING_TO_DINT(ReadColumn.Value); ActiveColumn:=ActiveColumn + INT#1;
172 2:Data.Ref[Row].Ref34:=STRING_TO_DINT(ReadColumn.Value); ActiveColumn:=ActiveColumn + INT#1;
173 3:Data.Ref[Row].Ref56:=STRING_TO_DINT(ReadColumn.Value); ActiveColumn:=ActiveColumn + INT#1;
174 4:Data.Ref[Row].Ref78:=STRING_TO_DINT(ReadColumn.Value); ActiveColumn:=ActiveColumn + INT#1;
175 5:Data.Ref[Row].Ref78:=STRING_TO_DINT(ReadColumn.Value); (* last one handled below *)
176 END_CASE;
177 {*****
178 CUSTOMIZE THIS TEMPLATE ABOVE TO ACCOMODATE YOUR DATA AND TO ADD SUPPORT FOR DIFFERENT FILE OUTPUT VERSIONS *****
179 {*****
180 CUSTOMIZE THIS TEMPLATE ABOVE TO ACCOMODATE YOUR DATA AND TO ADD SUPPORT FOR DIFFERENT FILE OUTPUT VERSIONS *****
181
182 ELSE
183 UnsupportedCase:=TRUE;
184 END_CASE;

```

NOTE: The capability of the function block to read multiple file versions is limited by the changes that can be made to the DataType Definition. It is not practical to use the version code to read completely different data formats. Make two copies of the Read_CSV_File and customize accordingly.



Write_CSV_File



This function block will format and write a CSV (ASCII) file to the controllers flash or ram disk. The original data is a user specified structure. This function block requires customization to accommodate application specific data requirements. Any variety of rows and columns and datatypes can be customized.

Parameters

* _	Parameter	Data Type	Description
VAR_IN_OUT			
B	Data	MyDataStruct	A user customized data structure containing the information (possibly still in binary format) to be written to a CSV file.
VAR_INPUT			Default



B	Execute	BOOL	Upon the rising edge, this function block will prepare to engage the RampIn cam profile at the master position specified in the BlendData structure.	FALSE
V	FileName	BOOL	The file to be written. Example: STRING#'ramdisk/user/data/mydata.csv'	STRING#''
V	Append	BOOL	This flag indicates whether to delete an existing file and create new data, or add to an existing file. If Append=TRUE, data will be appended.	FALSE
V	Separator	BYTE	The byte value of the ASCII character to be used for separating values of data on a line. If unconnected, the comma (BYTE#44) will be used.	BYTE#44
V	Version	UDINT	Optional. If used, this function block has the ability to be customized to select between multiple output formats.	UDINT#0
V	BufferSize	UDINT	Specifies the number of bytes in the file to process at one time. If unconnected, the default is 2048 bytes. BufferSize can be adjusted up or down if necessary to accommodate various file sizes and will depend upon the CYCLIC task in which the Read_CSV_File function block is executed.	UDINT#0
VAR_OUTPUT				
B	Done	BOOL	Set high when the slave first synchronizes with the master (Running cam profile is synchronized). This output is reset when execute goes low.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
E	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	
V	ErrorRow	INT	If Error is true and pertains to a problem with the source data, this value will indicate the location of processing when the error occurred.	
V	ErrorCol	INT	If Error is true and pertains to a problem with the source data, this value will indicate the location of processing when the error occurred.	

Notes

- Don't forget to include the ProConOS firmware library in the project. It is required for this function block.



File_RW Toolbox: Function Blocks



- It is strongly recommended to write files only to the Ramdisk portion of memory, and not the flash. Ramdisk is a temporary storage location, so the file should be read by another device using an HTTP file get command.
- See Yaskawa's Youtube Webinar - [CSV File Transfer with the File_RW Template](#).

Error Description

ErrorID	Meaning
0	No error
2	The length of the source buffer does not fit. The size of bytes to be copied assigned in BUF_CNT is larger than the available size of the SRC.
3	The length of the destination buffer does not fit. The sum of the bytes to be copied assigned in BUF_CNT and the offset in the connected byte stream assigned in BUF_OFFS is larger than the size of the connected byte stream.
4	This data type is not supported / File is already open
5	The alignment does not fit to this data type. The size to be copied assigned in BUF_CNT must be divisible by the size of the data type without a rest / File is opened, write protected or access denied
6	The conversion INTEL/MOTOROLA has failed / File name not defined
7	The string length does not fit. Additional checks are necessary for the data type string. This is described in the chapter 'String specialties'.
8	The destination buffer has a wrong data type. In some cases the data type is checked. This is described in the special chapter for each data type.
9	The offset value is not correct. In some cases the offset is checked. This is described in the special chapter for each data type.
10	The BUF_CNT does not fit. In some cases the size to be copied is checked. This is described in the special chapter for each data type.
11	The addresses of the source and the destination are the same / No memory available for writing the data
12	The number of characters to be written is greater than the data buffer
20	File could not be closed
21	File could not be deleted
23	No data could be written
10116	Problem converting string data to the output buffer
10117	String Conversion Error already exists on the controller. Clear the alarm and try again.
10118	STRING_TO_BUF Conversion Error
10119	In the Data Structure, rows must be set greater than zero and columns must be set greater than zero.
10120	File could not be opened.
10121	CSV file contains an unsupported version.
10122	Row Error. The data is out of sync with the expected row / column arrangement expected.



10123	Column Start Error. The data is corrupted.
10124	Unsupported Case condition.
10125	Conversion Error. Check the ErrorRow and ErrorCol outputs for details
10126	NoDataError - The End Of File was reached, but the record count is zero
10127	TooManyRecords - DataType is not large enough
10128	MaxNotDefined - User must set the maximum number of records that can be added to structure.
10129	No Carriage return found in CSV buffer. The function searched the file for twice the length of the specified buffer and was unable to find a carriage return indicating the end of a row. Either the buffer size is too small, or the data is invalid.

Customization Example 1

Write_CSV_File must be customized to accommodate your data. Some supporting functions used by Write_CSV_File (ReadBuffer and ReadValue) do not require customization and can remain in the File_RW_Toolbox. Two locations requiring customization are identified in the function block by several rows of comments indicating the need to customize. To effectively use this function, follow these steps:

- 1) Copy & paste the MyDataStruct and associated datatypes into your project, and rename them to avoid conflict with MyDataStruct in the File_RW_Template.

```

64  (***** Structure information relating to a CSV file *****)
65  MyData : STRUCT
66      XData : LREAL;
67      YData : LREAL;
68      ZData : LREAL;
69  END_STRUCT;
70
71  MyDataArray : ARRAY [UINT#0..UINT#300] OF MyData;
72
73  MyDataStruct: STRUCT
74      File: MyDataArray;
75      Version:STRING; (* If file versioning is used, apply a unique value to allow the identification of different file formats *)
76      Columns:INT; (* Configure this value to indicate the number of columns in the data file. *)
77      Records:INT; (* This value will be updated by the function as the data is processed *)
78      MaxRecords:INT; (* Initialize MaxRecords to the NUMBER OF ELEMENTS defined in the MyDataArray definition above *)
79  END_STRUCT;
80
81  (***** Structure information relating to a CSV file *****)

```

- 2) Modify the "MyData" dataType definition shown above such that it represents the data to be written. An example follows which shows a customized datatype:



```

2  (***** Job *****)
3  JobData : STRUCT
4      Move_X : DINT;
5      Move_Y : DINT;
6      Outs_O1 : DINT;
7      Outs_O2 : DINT;
8      Outs_O3 : DINT;
9      Vel_X : BYTE;
10     Acc_X : BYTE;
11     Vel_Y : BYTE;
12     ACC_Y : BYTE;
13     Execute : INT;
14     Jump : BYTE;
15     Wait : INT;
16     Loop : BYTE;
17     AltX : BYTE;
18     LinkTo : INT;
19     END_STRUCT;
20
21     JobArray : ARRAY [UINT#0..UINT#3399] OF JobData;
22
23     JobStruct: STRUCT
24         Job: JobArray;
25         Version:STRING; (* If file versioning is used, apply a unique value to allow the identification of different file formats *)
26         Columns:INT; (* Configure this value to indicate the number of columns in the data file. *)
27         Records:INT; (* This value will be updated by the function as the data is processed *)
28         MaxRecords:INT; (* Initialize MaxRecords to the NUMBER OF ELEMENTS defined in the MyDataArray definition above *)
29     END_STRUCT;
30
31 (***** Job *****)

```


3) Initialize the data required for "MyDataStruct" as shown below. Most importantly, set Columns and MaxRecords. MaxRecords indicates how many lines of data are to be written to the file. In the case of Append mode =TRUE, set MaxRecords to the number of lines from the MyDataStruct to be appended. Appending always starts from the first line (array element 0) of the structure and adds data to the end of the file. It is not necessary to initialize (clear) the other data elements beyond MaxRecords that may be from a previous use.

```

12     ReadJobFile:= '/flash/user/data/job.csv';
13     WriteJobFile:= '/flash/user/data/JobW.csv';
14     JobData.Columns:=INT#15;
15     JobData.MaxRecords:=INT#3400; (* Set to same as DataType Definition *)

```

4) Copy & paste the Write_CSV_File function block into your main project so it can be customized. This will allow you to retain the original function in the template for future reference. Rename the function to avoid name conflict with Write_CSV_File in the Toolbox.



Customizing the code in the function block



- 5) To customize the function block, go to the variables grid and rename the datatype used as the VAR_IN_OUT to the datatype you customized in step 2 above (Use the name as modified from ST code line 23 above).
- 6) Locate the comments near the middle of the Write_CSV_File function indicating the area to be customized. Modify the lines that convert binary data from the MyDataStruct structure to STRING data for the file.

Customizing for file versioning

The function has the capability to write multiple versions of the same structure. For example, a portion of the data from the structure can be written to one file, and a different set of data can be written to another file.

To use file versioning, follow the steps below:

- 1) Set the 'Version' function block input to a unique value (Non zero).
- 2) Customize the DataType to reflect the most current data specification.

Original DataType:

```

66 {***** JobRef *****}
67   PartData : STRUCT
68     Ref12 : INT;
69     Ref34 : INT;
70     Ref56 : INT;
71     Ref78 : INT;
72   END_STRUCT;
73
74   JobRefArray : ARRAY [UINT#0..UINT#401] OF PartData;
75
76   JobRefStruct: STRUCT
77     Ref: JobRefArray;
78     Version:STRING; (* If file versioning is used, apply a unique value to allow the identification of different file formats *)
79     Columns:INT; (* Configure this value to indicate the number of columns in the data file. *)
80     Records:INT; (* This value will be updated by the function as the data is processed *)
81     MaxRecords:INT; (* Initialize MaxRecords to the NUMBER OF ELEMENTS defined in the MyDataArray definition above *)
82   END_STRUCT;
83 {***** JobRef *****}

```

Modified DataType:

```

66 {***** JobRef *****}
67   PartData : STRUCT
68     Ref12 : DINT;
69     Ref34 : DINT;
70     Ref56 : DINT;
71     Ref78 : DINT;
72     Ref91 : DINT;
73   END_STRUCT;
74
75   JobRefArray : ARRAY [UINT#0..UINT#401] OF PartData;
76
77   JobRefStruct: STRUCT
78     Ref: JobRefArray;
79     Version:STRING; (* If file versioning is used, apply a unique value to allow the identification of different file formats *)
80     Columns:INT; (* Configure this value to indicate the number of columns in the data file. *)
81     Records:INT; (* This value will be updated by the function as the data is processed *)
82     MaxRecords:INT; (* Initialize MaxRecords to the NUMBER OF ELEMENTS defined in the MyDataArray definition above *)
83   END_STRUCT;
84 {***** JobRef *****}

```

- 3) Customize the Write_CSV_File function block to determine if a specific version if the file should be written.

Original code:

Modified code:

- 4) Customize the Write_CSV_File function block to write multiple versions.




Original code:

Modified code:

Application Example

Variable	Value	Default value
MyBuffer		
Buff		
[0]		
Sensor1Data	8098925.4772730	
Sensor2Data	8098927.3813410	
[1]		
Sensor1Data	8098929.3104715	
Sensor2Data	8098931.2347956	
[2]		
Sensor1Data	8098933.0863352	
Sensor2Data	8098934.8403711	
[3]		
Sensor1Data	8098936.5405054	
Sensor2Data	8098938.2251902	
[4]		
[5]		
[6]		
[7]		
[8]		
[9]		
Sensor1Data	8098958.1382532	
Sensor2Data	8098959.8236246	
[10]		
Sensor1Data	0.0000000	
Sensor2Data	0.0000000	



Gantry Toolbox

Gantry Toolbox

The Gantry Toolbox consists of the following:

Data Types:

Data Type	Usage
DataTypes not used directly with any of the Gantry Toolbox function blocks.	
GantryPositions	Can be used to store absolute positions within the coordinate system.
DataTypes for external use with Gantry Toolbox function blocks	
AXIS_REF	Identifies an axis
GantryStruct	Contains all information pertaining to a gantry system.
PathDetails	For Use with PathGenerator FB
DataTypes that support other DataTypes (no need for direct use by the application programmer)	
PathIdStruct	For use with PathGenerator and MovePath FBs
PathPairs	For use by PathGenerator FB
PathPointArray	For use by PathDetails STRUCT in PathGenerator FB
PathStruct	For Use with PathGenerator FB
SegmentArray	For use with MovePath FB
SegmentDetails	For use with MovePath FB
SegmentStruct	For use with MovePath FB
WPos	Supporting structure for GantryPositions
XPos	Supporting structure for GantryPositions
YPos	Supporting structure for GantryPositions
ZPos	Supporting structure for GantryPositions

Enumerated Types:

Function Block	Description
TB_PatternType	For use with PathDetails structure

Function Blocks:

MotionWorks IEC61131-3 Toolboxes: 2013-09-13



Function Block	Description
Calculate Angles	Calculates start and traversed angles for arcs (used as an input to PathGenerator function block)
Gantry Home	Moves all gantry axes in search of home by first seeking one of the limit switches, and then searching in the other direction for the C channel or index pulse.
Gantry Power	Enables or disable all axes configured as part of a gantry system.
Gantry Return Home	Moves all gantry axes back to the home position as defined by the home positions in the GantryStruct.
Gantry Stop	Executes the MC_Stop block for all axes configured as part of a gantry system.
GotoXY	Performs an absolute move the X and Y axes to a specific location within the gantry coordinate system.
GotoXYZ	Performs an absolute move the X,Y, and Z axes to a specific location within the gantry coordinate system.
GripperControl	Operates a simple gripper device if the actuator can be controlled via a digital output.
Interpolator	Calculates the required acceleration, deceleration, and velocity for both X and Y axes so that straight line motion can occur between any two points in the XY (two dimensional) coordinate system.
Interpolator3D	Calculates the required acceleration, deceleration, and velocity for X, Y and Z axes so that straight line motion can occur between any two points in three dimensional space within the gantry coordinate system.
Move Path	This function block moves X and Y axes according to a path profile generated by the PathGenerator and specified in the PathStruct structure
PathGenerator	This function block converts straight line vector and arc segment data into cam files, which will provide coordinated motion by using the Move Path function block
Pick Part	Initiates a series of actions that involves moving the XY axes to a specific location, opening a gripper actuator, moving the Z axis to a "Down" location, closing the gripper (to pick a part), and then finally moving the Z axis back to its "Up" position.
Place Part	Initiates a series of actions that involves moving the XY axes to a specific location, moving the Z axis to a "Down" location, opening the gripper (to place the part), and then finally moving the Z axis back to its "Up" position.
SegmentLookup	Used to show active segment and output flags status
XY MoveAbsolute	Used to create absolute motion for an XY gantry system
XY MoveRelative	Used to create relative motion for an XY gantry system



Getting Started: Gantry

Requirements for v203

To use the Gantry Toolbox, your project must also contain the following:

Firmware libraries:

- YMotion

User libraries:

- DataTypes_Toolbox (v200 or higher)
- Math_Toolbox (v202 or higher)
- PLCopen_Toolbox (v205 or higher)

Using the Gantry Toolbox

See Yaskawa's Youtube Webinar - [XY Interpolation via the Gantry Toolbox](#) for more info.

Gantry Revision History

Current Version:

New for Gantry v203 – All firmware library DataType definitions were moved to a new toolbox called the DataTypes Toolbox. Formerly, the PLCOpen Toolbox contained the MotionInfoTypes and the PLCTaskInfoTypes datatype files. These were removed and are now included in the DataTypes Toolbox. If upgrading from an older version of Gantry Toolbox, you must do the following:

- 1) Include the DataTypes Toolbox in your project.
- 2) Remove any other Yaskawa supplied datatype files with firmware library definitions such as
 - a. ControllInfoTypes
 - b. YDeviceCommTypes

```
(***** 2013-03-15 v203 released
*****)
```

(* Created from Gantry_Toolbox_v203_d_KH

PathPointArray increased to 2047.

- 1) GantryDataTypes file, added Tangent Axis to Gantry Struct. This axis will be tangential to X, Y axes
- 2) GantryDataTypes file, added InputConditions and StandStillDuration to Path details structure. These will be used for pause sections in the path
- 3) GantryDataTypes file, made PathPointArray size 1000
- 4) GantryDataTypes file, added StandStill and WaitForInputs enum types to TB_PatternType
- 5) GantryDataTypes file, added TangentAxisTable to PathIDStruct
- 6) GantryDataTypes file, added InputConditions and StandStillDuration to SegmentDetails
- 7) GantryDataTypes file, made SegmentArray size 1000
- 8) GantryDataTypes file, created SegmentMapArray to map between managed segments and user defined segments
- 9) GantryDataTypes file, added ManagedSegment, LastManagedSegment, AbortPath and SegmentMap to Segmentstruct
- 10) GantryDataTypes file, added TangentActive to PathDetails. Used to decide if a segment requires a tangent axis to be oriented correctly at the beginning and/or end.
- 11) Gantry_Power - Removed Alarm and Warning outputs.



- 12) Gantry_Power - Added support for a Tangent axis.
- 13) Gantry_Power - Added status word output. This word shows which axes are powered on.
- 14) Gantry_Stop - Added support to stop all configured Gantry Axes
- 15) PathGenerator - Added support for a tangent axis
- 16) PathGenerator - Added support for intermittent motion and pauses
- 17) Move_Path - Added ability to move and pause virtual master based on the segment details
- 18) Move_Path - Added InputConditions as a FB input for user inputs to restart motion at WaitForInputs segment
- 19) PathIDManager - Function block added. Removes paths from memory that are no longer needed.

Previous Versions:



Data Types

Data Types for Gantry Toolbox

The following is a complete list of all DataTypes included in the Gantry Toolbox. The list is arranged to separate those that are used internally, and not useful outside of their particular function, and those that an application program must incorporate when the programmer wishes to use the associated Function Block.

Data Type	Usage
DataTypes not used directly with any of the Gantry Toolbox function blocks.	
GantryPositions	Can be used to store absolute positions within the coordinate system.
DataTypes for external use with Gantry Toolbox function blocks	
AXIS_REF	Identifies an axis
GantryStruct	Contains all information pertaining to a gantry system.
PathDetails	For Use with PathGenerator FB
DataTypes that support other DataTypes (no need for direct use by the application programmer)	
PathIdStruct	For use with PathGenerator and MovePath FBs
PathPairs	For use by PathGenerator FB
PathPointArray	For use by PathDetails STRUCT in PathGenerator FB
PathStruct	For Use with PathGenerator FB
SegmentArray	For use with MovePath FB
SegmentDetails	For use with MovePath FB
SegmentStruct	For use with MovePath FB
WPos	Supporting structure for GantryPositions
XPos	Supporting structure for GantryPositions
YPos	Supporting structure for GantryPositions
ZPos	Supporting structure for GantryPositions



Data Type: AXIS_REF

The AXIS_REF data type identifies an axis and thus provides the interface to the hardware or virtual axes. AXIS_REF is used as VAR_IN_OUT in all Motion Control Function Blocks described in this Online help. It is represented as an input and an output connected by a horizontal line in the graphical representation of a function block.

The value of AxisNum is determined by the logical axis number assigned in the Hardware Configuration. See the Configuration tab under each axis.

Data Type Declaration

```

TYPE
  AXIS_REF:STRUCT
    AxisNum:UINT;
  END_STRUCT;
END_TYPE

```

Variable Declaration Example

Name	Type	Usage
Default		
MC_ReadActualPosition_1	MC_ReadActual...	VAR
FeedAxis	AXIS_REF	VAR_EXTER...
AlwaysTrue	AXIS_REF	ER...
ReadActualPosValid1	BOOL	ER...
ReadActualPosBusy1	BYTE	ER...
ReadActualPosError1	CTD	ER...
ReadActualPosErrorID1	CTU	ER...
ReadActualPosPosition1	CTUD	ER...
ActualPosition1	REAL	VAR_EXTER...
MC_ReadActualVelocity_1	MC_ReadActual...	VAR
ReadActualVelValid1	BOOL	VAR_EXTER...

Code Example

```

AxisX.Number:=UINT#0;
MCMoveAbsoluteX(Axis:=AxisX, Execute:=FALSE);
AxisX:=MCMoveAbsolutX.Axis;
AxisY.Number:=UINT#0;

```



Gantry Toolbox: DataTypes

```
MCMoveAbsoluteY(Axis:=AxisY, Execute:=FALSE);  
AxisX:=MCMoveAbsoluteY.Axis;
```





Data Type: GantryPositions

This datatype can be used to store absolute positions within the coordinate system. It is not used directly with any function block in the Gantry toolbox, however data from this structure can be moved into the [GantryStruct](#) prior to executing a motion function.

Data Type Declaration

TYPE

GantryPositions: STRUCT (* Structure of three dimensional locations for positioning a gantry system *)

X:[XPos](#);

Y:[YPos](#);

Z:[ZPos](#);

W:[WPos](#);

END_STRUCT;

END_TYPE;



Data Type: GantryStruct

This datatype contains all information pertaining to a gantry system.

Data Type Declaration

TYPE

GantryStruct:STRUCT (* DataType to be used in the application code *)

ID:INT; (* Can be used to uniquely identify more than one gantry in a system *)

Virtual: [AxisStruct](#); (* All data pertaining to the Virtual axis *)

X: [AxisStruct](#); (* All data pertaining to the X axis *)

Y: [AxisStruct](#); (* All data pertaining to the Y axis *)

Z: [AxisStruct](#); (* All data pertaining to the Z axis *)

W: [AxisStruct](#); (* All data pertaining to the W axis *)

XPrime: [AxisStruct](#); (* All data pertaining to the XPrime axis *)

YPrime: [AxisStruct](#); (* All data pertaining to the YPrime axis *)

ZPrime: [AxisStruct](#); (* All data pertaining to the ZPrime axis *)

Opened:BOOL; (* Gripper status *)

Closed:BOOL; (* Gripper status *)

OpenCommand:BOOL; (* Gripper open request *)

CloseCommand:BOOL; (* Gripper close request *)

GripperValue:INT; (* Constant that equates to the gripper *)

Pick:INT; (* Commanded picking location row or column to be used
as array index to actual position *)

Place:INT; (* Commanded picking location row or column to be used
as array index to actual position *)

Up:LREAL; (* mm Position of the vertical axis when "UP."



Gantry Toolbox: DataTypes

Alternate usage: ZPosition *)



Down:LREAL; (* mm Position of the vertical axis when "Down.")

Alternate usage ZPosition *)

Velocity:LREAL; (* Velocity of the gantry workpiece *)

Accel:LREAL; (* Acceleration of the gantry workpiece *)

Decel:LREAL; (* Deceleration of the gantry workpiece *)

ZVelocityUp:LREAL; (* Velocity of the vertical axis *)

ZVelocityDown:LREAL; (* Velocity of the vertical axis *)

ZAccel:LREAL; (* Acceleration of the vertical axis *)

ZDecel:LREAL; (* Deceleration of the vertical axis *)

END_STRUCT;

END_TYPE



Data Type: PathDetails

For use with the [PathGenerator](#) Function Block

Data Type Declaration

PathDetails:STRUCT

SegmentType:INT; (* Indicates linear or arc, see TB_PatternType *)

XCoord:LREAL; (* If Linear segment, the absolute coordinate of the X axis relative to the start of the path. *)

YCoord:LREAL; (* If Linear segment, the absolute coordinate of the Y axis relative to the start of the path. *)

Radius:LREAL; (* If Arc segment, the radius of the arc in XY user units. *)

StartAngle:LREAL; (* If Arc segment, the starting angle on a unit circle, 0 degree = 3 O'Clock position *)

TraversedAngle:LREAL; (* If Arc segment, the traversed angle, where CW = negative, CCW = positive *)

Resolution:REAL;

OutputFlags:DWORD; (* Indicator that can be used to control outputs along the path motion *)

VectorPosition:LREAL; (* Calculated relative travel of the tool point for the current segment *)

END_STRUCT;



Data Type: PathIDStruct

This datatype contains all information pertaining to a gantry system.

Data Type Declaration

TYPE

PathIDStruct:STRUCT

XAxisTable:UINT; (* The CamTableID for the X axis *)

YAxisTable:UINT; (* The CamTableID for the Y axis *)

PathLength:LREAL; (* The total length of the path motion of the

toolpoint, the distance the virtual master will

travel to complete the path. *)

END_STRUCT;

END_TYPE



Data Type: PathPairs

For use with the [PathGenerator](#) Function Block

Data Type Declaration

PathPairs: ARRAY[0..1024] OF UDINT; (* For use internally by the PathGenerator FB *)



Data Type: PathPointArray

For use with the [PathGenerator](#) Function Block

Data Type Declaration

PathPointArray: ARRAY[0..100] OF PathDetails;



Data Type: PathStruct

For use with the [PathGenerator](#) Function Block

Data Type Declaration

```

PathStruct: STRUCT    (* Data structure used with the PathGenerator function block *)

    Data:PathPointArray;


    Segments:INT;     (* Total datapoints specified in the path. If you need more than defined in the
PathPointArray, just increase *)

END_STRUCT;

```

PathStruct Example 1


Straight Line Path Example



```

VectorPath.Data[1] SegmentType =TB_PatternType#Straightline;
VectorPath.Data[1] XCoord =LREAL#10.0;
VectorPath.Data[1] YCoord =LREAL#10.0;

```



```

PathDetail:STRUCT
-> SegmentType:INT;
-> XCoord:LREAL;
-> YCoord:LREAL;
  Radius:LREAL;
  StartAngle:LREAL;
  TraversedAngle:LREAL;
  Resolution:REAL;
  OutputFlags:DWORD;
  MasterEnd:LREAL;
END_STRUCT;

PathPointArray: ARRAY[0..100] OF PathDetail;

PathStruct: STRUCT
  Data:PathPointArray;
  Segments:INT;
END_STRUCT;


(* ENUM Type for PathDetail's SegmentType *)
TB_PatternType:
(
  na,
  StraightLine,
  Arc

```

PathStruct Example 2



Arc Path Example



```

VectorPath.Data[2].SegmentType:=TB_PatternType#Arc;
VectorPath.Data[2].Radius:=LREAL#5.0;
VectorPath.Data[2].StartAngle:=LREAL#180.0;
VectorPath.Data[2].TraversedAngle:=LREAL#-180.0;
VectorPath.Data[2].Resolution:=REAL#0.05;
VectorPath.Data[2].OutputFlags:=DWORD#2;

PathDetail:STRUCT
  SegmentType:INT;
  XCoord:LREAL;
  YCoord:LREAL;
  Radius:LREAL;
  StartAngle:LREAL;
  TraversedAngle:LREAL;
  Resolution:REAL;
  OutputFlags:DWORD;
  MasterEnd:LREAL;
END_STRUCT;

PathPointArray: ARRAY[0..100] OF PathDetail;

PathStruct: STRUCT
  Data:PathPointArray;
  Segments:INT;
END_STRUCT;

(* ENUM Type for PathDetail's SegmentType *)
TB_PatternType:
(
  na,
  StraightLine,
  Arc
)

```

PathStruct Example 3

Complex Path Example

```

VectorPath.Data[1].SegmentType:=TB_PatternType#Straightline;
VectorPath.Data[1].XCoord:=LREAL#0.0;
VectorPath.Data[1].YCoord:=LREAL#10.0;
VectorPath.Data[1].OutputFlags:=DWORD#1;

```

```

VectorPath.Data[2].SegmentType:=TB_PatternType#Arc;
VectorPath.Data[2].Radius:=LREAL#0.5;
VectorPath.Data[2].StartAngle:=LREAL#180.0;
VectorPath.Data[2].TraversedAngle:=LREAL#-180.0;
VectorPath.Data[2].Resolution:=REAL#0.05;

```

```

VectorPath.Data[3].SegmentType:=TB_PatternType#Straightline;
VectorPath.Data[3].XCoord:=LREAL#1.0;
VectorPath.Data[3].YCoord:=LREAL#0.0;
VectorPath.Data[3].OutputFlags:=DWORD#2;

```

```


VectorPath.Data[4].SegmentType:=TB_PatternType#Arc;
VectorPath.Data[4].Radius:=LREAL#0.5;
VectorPath.Data[4].StartAngle:=LREAL#0.0;
VectorPath.Data[4].TraversedAngle:=LREAL#-180.0;
VectorPath.Data[4].Resolution:=REAL#0.05;

```

```

VectorPath.Segments := INT#4;

```





Data Type: SegmentArray

For use with the [PathGenerator](#) and [MovePath](#) function blocks

Data Type Declaration

TYPE

```
SegmentArray: ARRAY[0..200] OF SegmentDetails;
```

END_TYPE



Data Type: SegmentDetails

For use with the [PathGenerator](#) and [MovePath](#) function blocks

Data Type Declaration

TYPE

SegmentDetails: STRUCT

Segment: INT; (* Current segment number being processed *)

OutputFlags: DWORD; (* The output flags DWORD corresponding to the segment *)

VectorDistance: LREAL; (* Master end point for the segment, the path travelled

up to the end of this segment *)

END_STRUCT;

END_TYPE



Data Type: SegmentStruct

For use with the [PathGenerator](#) and [MovePath](#) function blocks

Data Type Declaration

TYPE

SegmentStruct: STRUCT

Segment: SegmentArray;

LastSegment: INT;

END_STRUCT;

END_TYPE



Data Type: WPos

Supporting structure for [GantryPositions](#).

Data Type Declaration

TYPE

WPos: ARRAY [0..11] OF LREAL; (* Array for grid coordinate positions *)

END_TYPE



Data Type: XPos

Supporting structure for [GantryPositions](#).

Data Type Declaration

TYPE

XPos: ARRAY [0..11] OF LREAL; (* Array for grid coordinate positions *)

END_TYPE



Data Type: YPos

Supporting structure for [GantryPositions](#).

Data Type Declaration

TYPE

YPos: ARRAY [0..11] OF LREAL; (* Array for grid coordinate positions *)

END_TYPE



Data Type: ZPos

Supporting structure for [GantryPositions](#).

Data Type Declaration

TYPE

ZPos: ARRAY [0..11] OF LREAL; (* Array for grid coordinate positions *)

END_TYPE



Enumerated Types

Enumerated Type: TB_PatternType

ENUM Type for [PathDetails](#)' SegmentType

Data Type Declaration

TB_PatternType:

```
(  
na, (* INT#0 - Not a valid PatternType *)  
StraightLine, (* INT#1 - Straight Line *)  
Arc (* INT#2 - Arc *)  
);
```



Enumerated Type: TB_PatternType

ENUM Type for [PathDetails](#)' SegmentType

Data Type Declaration


TB_PatternType:

```
(  
na, (* INT#0 - Not a valid PatternType *)  
StraightLine, (* INT#1 - Straight Line *)  
Arc (* INT#2 - Arc *)  
);
```




Function Blocks

Calculate_Angles



This function block uses either a) two co-ordinates and center point of an arc or b) two co-ordinates and radius of an arc to calculate start and traversed angles required for [PathStruct](#) data type in the [PathGenerator](#) function block

Parameters

<u>*</u>	Parameter	Data Type	Description	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
B	ArcDefinitionMode	INT	Data entry mode the user wants to use. 0: Two coordinates + Center coordinate of arc, 1: Two coordinates + radius of arc	0
B	X1	LREAL	X coordinate of the first coordinate	0.0
B	Y1	LREAL	Y coordinate of the first coordinate	0.0
B	X2	LREAL	X coordinate of the second coordinate	0.0
B	Y2	LREAL	Y coordinate of the second coordinate	0.0
B	XC	LREAL	X coordinate of the center coordinate	0.0
B	YC	LREAL	Y coordinate of the center coordinate	0.0



B	Radius	LREAL	Radius of arc	0.0
B	Direction	MC_Direction	0: clockwise, 1: counter clockwise	0
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	
B	StartAngle	LREAL	Angle subtended by a line drawn from the arc center to the start point of the arc with the positive X axis on an XY plane	
B	TraversedAngle	LREAL	Angle traversed by the arc generated	

Notes


- See Yaskawa's Youtube channel for [more info](#), [details](#), and [examples](#).

Error Description


ErrorID	Meaning
0	No error
10130	The center to co-ordinate distance for the two input co-ordinates are not the same
10131	Zero radius is invalid
10132	Only modes 0 (center + 2 co-ordinates) and 1 (radius + 2 coordinates) are supported
10133	The coordinates of the two data points are the same
10140	Must be greater than zero and less than 20

Example

The Calculate_Angles function block is used to calculate Start and Traversed angles which can be used by the [PathStruct](#) structure to create a path in the [PathGenerator](#) function block. The two modes of data entry for an arc are a) two co-ordinates and center point of an arc or b) two co-ordinates and radius as shown below.



The two modes of data entry are shown in detail below. Mode 0: 2 coordinates + center coordinate, Mode 1: 2 coordinates + radius. If the user plans to use Mode 1, the sign of the radius is important. This is illustrated in the figure below. The two arcs (red and blue) have the same start and end coordinates and they have the same radii. A negative radius would give rise to an obtuse arc (shown as red) and the start angle and traversed angle are 270 and -270 respectively. If a positive radius is specified, an acute arc (shown in blue) is generated. The start angle and traversed angle for the acute arc are 180 and -90 respectively.



Application example



Gantry Toolbox: Function Blocks




Step 1: Using Calculate_Angles to calculate start and traverse angles for the flower path shown below

```
Calculate_Angles_1(Execute:=TRUE,ArcDefinitionMode:=INT#1,X1:=LREAL#-1.0,X2:=LREAL#0.0,Y1:=LREAL#0.0,Y2:=LREAL#1.0,Radius:=LREAL#-1.0,Direction:=FALSE);
```

```
Calculate_Angles_2(Execute:=TRUE,ArcDefinitionMode:=INT#1,X1:=LREAL#0.0,X2:=LREAL#1.0,Y1:=LREAL#1.0,Y2:=LREAL#0.0,Radius:=LREAL#-1.0,Direction:=FALSE);
```


```
Calculate_Angles_3(Execute:=TRUE,ArcDefinitionMode:=INT#1,X1:=LREAL#1.0,X2:=LREAL#0.0,Y1:=LREAL#0.0,Y2:=LREAL#-1.0,Radius:=LREAL#-1.0,Direction:=FALSE);
```

```
Calculate_Angles_4(Execute:=TRUE,ArcDefinitionMode:=INT#1,X1:=LREAL#0.0,X2:=LREAL#-1.0,Y1:=LREAL#-1.0,Y2:=LREAL#0.0,Radius:=LREAL#-1.0,Direction:=FALSE);
```




Step 2: Use [PathGenerator](#) to create the path and [Move_Path](#) to implement XY motion



```
FlowerPath.Data[1].SegmentType:=TB_PatternType#Arc;
FlowerPath.Data[1].Radius:=LREAL#1.0;
Calculate_Angles_1(Execute:=TRUE,ArcDefinitionMode:=INT#1,X1:=LREAL#-1.0,X2:=LREAL#0.0,Y1:=LREAL#0.0,Y2:=LREAL#1.0,Radius:=LREAL#-1.0,Direction:=FALSE);
FlowerPath.Data[1].StartAngle:=Calculate_Angles_1.StartAngle;
FlowerPath.Data[1].TraversedAngle:=Calculate_Angles_1.TraversedAngle;
FlowerPath.Data[1].Resolution:=REAL#0.05;
```



Step 3: Validation using logic analyzer




Step 4: Result on XY system





Gantry_Home



This function block will move all gantry axes in search of home by first seeking one of the limit switches, and then searching in the other direction for the C channel or index pulse. This block uses the [Home_LS_Pulse](#) function block from the [PLCopen Toolbox](#). If configured, the Z axis will search for home first, then the X and Y axes will search simultaneously. This sequence was designed to prevent mechanical interferences with objects in the work coordinate system during the homing process.

Parameters

*	Parameter	Data Type	Description
VAR_IN_OUT			
V	Gantry	GantryStruct	Contains all information pertaining to a gantry system.
VAR_INPUT			
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.
VAR_OUTPUT			
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.
B	CommandAborted	BOOL	Set high if motion is aborted by another motion command or MC_Stop. This output is cleared with the same behavior as the Done output.



B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Error Description

ErrorID	Meaning
0	No error
1	Time limit exceeded
2	Distance limit exceeded
3	Torque limit exceeded
4369	The move could not be buffered because the axis motion queue is full. 16 moves is the maximum which can be buffered.
4370	The move could not be started because motion is prohibited. The drive may not be enabled. MC_Power.Enable_Positive or MC_Power.Enable_Negative might be low. Check MC_Power.Status output. MC_Stop.Execute might be held high, preventing motion.
4378	The function block is not applicable for the external axis specified
4379	A homing sequence is already in progress.
4380	MC_SetPosition can not be executed while the axis is moving.
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4382	When the axis is in rotary mode, and the MC_SetPosition tries to set a position that is equal to or greater than the MachineCycle, this error is generated, and the position is not set.
4383	Axis must be commanded at standstill when homing is attempted.
4390	Position cannot be defined while the axis is the cam master of other axes.
4391	The function block cannot be used with a virtual axis.
4396	Axis latch function already in use.
4397	Over travel limit still ON after attempting to move away from it.
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4641	Buffer mode does not correspond to a valid enumeration value.
4642	Direction does not correspond to a valid enumeration value.
4646	Mode does not correspond to a valid enumeration value.
4658	Velocity parameter is less than or equal to zero.
4659	Acceleration is less than or equal to zero.
4660	Deceleration is less than or equal to zero.
4667	Jerk is less than or equal to zero.
4893	The specified external axis may not be used. A physical axis is required.



Gantry Toolbox: Function Blocks




10037	Offset cannot be in the same direction as the original motion into the limit switch.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.
61713	An internal assertion in the motion kernel failed indicating the controller is not in a stable state. Please report this error to Yaskawa America Incorporated.

i



Gantry_Power



This function block will enable or disable all axes configured as part of a gantry system. This block uses the [AxisControl](#) function block from the [PLCopen Toolbox](#). If the gantry is configured with dual motors on the same physical axis, then the secondary or prime axes are geared to the other axis in the same physical motion plane.

Parameters

*_	Parameter	Data Type	Description	
VAR_IN_OUT				
V	Gantry	GantryStruct	Contains all information pertaining to a gantry system.	
VAR_INPUT				
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
V	ClearAlarm	BOOL	This input will clear any axis specific alarms on the Gantry axes	FALSE
VAR_OUTPUT				
V	XAxisErrorID	UINT	ErrorID on the X axis	
V	YAxisErrorID	UINT	ErrorID on the Y axis	



V	ZAxisErrorID	UINT	ErrorID on the Z axis
B	Status	BOOL	TRUE if the drive is enabled. This output is derived from the Status output of MC_Power.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
V	XPAxisErrorID	UINT	ErrorID on the X' axis
V	XPControlAlarmID	UINT	Controller ErrorID caused by the X' axis
V	YPAxisErrorID	UINT	ErrorID on the Y' axis
V	YPControlAlarmID	UINT	Controller ErrorID caused by the Y' axis
V	ZPAxisErrorID	UINT	ErrorID on the Z' axis
V	ZPControlAlarmID	UINT	Controller ErrorID caused by the Z' axis


Error Description

This function block uses the AxisControl function block from the PLCopen Toolbox. Refer to the [Error IDs from the Axis Control function block](#)

ErrorID	Meaning
0	No error
4370	The move could not be started because motion is prohibited. The drive may not be enabled. MC_Power.Enable_Positive or MC_Power.Enable_Negative might be low. Check MC_Power.Status output. MC_Stop.Execute might be held high, preventing motion.
4371	The servo drive failed to enable or disable. Check the amplifier wiring for L1 / L2 / L3
4378	The function block is not applicable for the external axis specified
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4399	The L1 / L2 / L3 power inputs on the drive may not be supplied with power, possibly due to an E-Stop condition.
4400	The Safety input (HHB) is preventing the drive from enabling.
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4641	Buffer mode does not correspond to a valid enumeration value.
4893	The specified external axis may not be used. A physical axis is required.
4894	The specified virtual axis may not be used with this function block.
45332	Sending clear alarms command to servo drive failed.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.
61713	An internal assertion in the motion kernel failed indicating the controller is not in a stable state. Please report this error to Yaskawa America Incorporated.



Gantry_Return_Home



This function block will move all gantry axes back to the home position as defined by the home positions in the [GantryStruct](#). If configured, the Z axis will move to home first, then the X and Y axes will move together. This sequence was designed to prevent mechanical interferences with objects in the work coordinate system during the homing process. This block uses the MC_MoveAbsolute function block from the PLCopenPlus firmware library. It is assumed that the home location has been previously determined either by using the [Gantry_Home](#) function block or because the system uses absolute encoders that have been calibrated to the physical machine.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
V	Gantry	GantryStruct	Contains all information pertaining to a gantry system.	
VAR_INPUT				Default
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
VAR_OUTPUT				
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.	
B	CommandAborted	BOOL	Set high if motion is aborted by another motion command	




			or MC_Stop. This output is cleared with the same behavior as the Done output.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Error Description

ErrorID	Meaning
0	No error
4369	The move could not be buffered because the axis motion queue is full. 16 moves is the maximum which can be buffered.
4370	The move could not be started because motion is prohibited. The drive may not be enabled. MC_Power.Enable_Positive or MC_Power.Enable_Negative might be low. Check MC_Power.Status output. MC_Stop.Execute might be held high, preventing motion.
4378	The function block is not applicable for the external axis specified
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4641	Buffer mode does not correspond to a valid enumeration value.
4642	Direction does not correspond to a valid enumeration value.
4658	Velocity parameter is less than or equal to zero.
4659	Acceleration is less than or equal to zero.
4660	Deceleration is less than or equal to zero.
4667	Jerk is less than or equal to zero.
4893	The specified external axis may not be used. A physical axis is required.
10034	Interpolation calculation error.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.



Gantry_Stop



This function block will execute the MC_Stop block for all axes configured as part of a gantry system.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
V	Gantry	GantryStruct	Contains all information pertaining to a gantry system.	
VAR_INPUT				
				Default
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
VAR_OUTPUT				
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.	
B	CommandAborted	BOOL	Set high if motion is aborted by another motion command or MC_Stop. This output is cleared with the same behavior as the Done output.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This	




		output is reset when 'Execute' or 'Enable' goes low.
--	--	--

Error Description

ErrorID	Meaning
0	No error
4370	The move could not be started because motion is prohibited. The drive may not be enabled. MC_Power.Enable_Positive or MC_Power.Enable_Negative might be low. Check MC_Power.Status output. MC_Stop.Execute might be held high, preventing motion.
4378	The function block is not applicable for the external axis specified
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4660	Deceleration is less than or equal to zero.
4893	The specified external axis may not be used. A physical axis is required.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.



GotoXY



This function block will perform an absolute move the X and Y axes to a specific location within the gantry coordinate system. The absolute X and Y positions must be specified in [GantryStruct](#) before executing this function block. This block calculates the required acceleration, deceleration and velocity for each axis and then executes an MC_MoveAbsolute function block simultaneously for each to create straight line motion at the tool point, however this is not considered an interpolated motion. If configured, no motion on the Z axis will occur.

Parameters

*	Parameter	Data Type	Description
VAR_IN_OUT			
V	Gantry	GantryStruct	Contains all information pertaining to a gantry system.
VAR_INPUT			
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.
VAR_OUTPUT			
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.
B	CommandAborted	BOOL	Set high if motion is aborted by another motion command or MC_Stop. This output is cleared with the same behavior as the Done output.




B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Error Description

ErrorID	Meaning
0	No error
4369	The move could not be buffered because the axis motion queue is full. 16 moves is the maximum which can be buffered.
4370	The move could not be started because motion is prohibited. The drive may not be enabled. MC_Power.Enable_Positive or MC_Power.Enable_Negative might be low. Check MC_Power.Status output. MC_Stop.Execute might be held high, preventing motion.
4378	The function block is not applicable for the external axis specified
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4641	Buffer mode does not correspond to a valid enumeration value.
4642	Direction does not correspond to a valid enumeration value.
4658	Velocity parameter is less than or equal to zero.
4659	Acceleration is less than or equal to zero.
4660	Deceleration is less than or equal to zero.
4667	Jerk is less than or equal to zero.
4893	The specified external axis may not be used. A physical axis is required.
10034	Interpolation calculation error.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.



GoToXYZ



This function block will perform an absolute move the X, Y, and Z axes to a specific location within the gantry coordinate system. The absolute positions must be specified in [GantryStruct](#) before executing this function block. This block calculates the required acceleration, deceleration and velocity for each axis and then executes an MC_MoveAbsolute function block simultaneously for each to create straight line motion at the tool point, however this is not considered an interpolated motion.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
V	Gantry	GantryStruct	Contains all information pertaining to a gantry system.	
VAR_INPUT			Default	
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
VAR_OUTPUT				
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.	
B	CommandAborted	BOOL	Set high if motion is aborted by another motion command or MC_Stop. This output is cleared with the same behavior	




			as the Done output.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Error Description

ErrorID	Meaning
0	No error
4369	The move could not be buffered because the axis motion queue is full. 16 moves is the maximum which can be buffered.
4370	The move could not be started because motion is prohibited. The drive may not be enabled. MC_Power.Enable_Positive or MC_Power.Enable_Negative might be low. Check MC_Power.Status output. MC_Stop.Execute might be held high, preventing motion.
4378	The function block is not applicable for the external axis specified
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4641	Buffer mode does not correspond to a valid enumeration value.
4642	Direction does not correspond to a valid enumeration value.
4658	Velocity parameter is less than or equal to zero.
4659	Acceleration is less than or equal to zero.
4660	Deceleration is less than or equal to zero.
4667	Jerk is less than or equal to zero.
4893	The specified external axis may not be used. A physical axis is required.
10034	Interpolation calculation error.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.



GripperControl



This function block can operate a simple gripper device if the actuator can be controlled via a digital output. It will activate an output while waiting for confirmation that a corresponding input has changed state to indicate that the gripper has successfully opened or closed.

Parameters

*_	Parameter	Data Type	Description	
VAR_IN_OUT				
V	Gantry	GantryStruct	Contains all information pertaining to a gantry system.	
VAR_INPUT				
			Default	
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
B	Open	BOOL	Command to open the gripper	
B	Close	BOOL	Command to close the gripper	
VAR_OUTPUT				
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	




Error Description

ErrorID	Meaning
0	No error
10035	Gripper Close Error (Timeout)
10036	Gripper Open Error (Timeout)



Interpolator



This function block calculates the required acceleration, deceleration, and velocity for both X and Y axes so that straight line motion can occur between any two points in the XY (two dimensional) coordinate system. This function block is used by the [GotoXY](#) function block.

Parameters

* _	Parameter	Data Type	Description	
VAR_IN_OUT				
V	Gantry	GantryStruct	Contains all information pertaining to a gantry system.	
VAR_INPUT			Default	
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
VAR_OUTPUT				
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.	
V	Vx	LREAL	X axis component of gantry velocity	



Gantry Toolbox: Function Blocks




V	Vy	LREAL	Y axis component of gantry velocity
V	ACCx	LREAL	X axis component of gantry acceleration
V	ACCy	LREAL	Y axis component of gantry acceleration
V	DECx	LREAL	X axis component of gantry deceleration
V	DECy	LREAL	Y axis component of gantry deceleration
V	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.

Error Description

ErrorID	Meaning
0	No error
10034	Interpolation calculation error.



Interpolator3D



This function block calculates the required acceleration, deceleration, and velocity for X, Y and Z axes so that straight line motion can occur between any two points in three dimensional space within the gantry coordinate system. This function block is used by the [GotoXYZ](#) function block.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
V	Gantry	GantryStruct	Contains all information pertaining to a gantry system.	
VAR_INPUT				Default
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
VAR_OUTPUT				
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is	




			completed, the Done output will not be set. This output is reset when execute goes low.
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.
V	Vx	LREAL	X axis component of gantry velocity
V	Vy	LREAL	Y axis component of gantry velocity
V	Vz	LREAL	Z axis component of gantry velocity
V	ACCx	LREAL	X axis component of gantry acceleration
V	DECx	LREAL	X axis component of gantry deceleration
V	ACCy	LREAL	Y axis component of gantry acceleration
V	DECy	LREAL	Y axis component of gantry deceleration
V	ACCz	LREAL	Z axis component of gantry acceleration
V	DECz	LREAL	Z axis component of gantry deceleration
V	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.

Error Description

ErrorID	Meaning
0	No error
10034	Interpolation calculation error.



Move_Path



Based on the axes specified in the GantryStruct, this function block can move X,Y,Z and Tangent axes according to a path profile generated by the [PathGenerator](#) and specified in the [PathStruct](#) structure. This function block typically uses the output from the [PathGenerator](#) to operate. Inputs and outputs can be monitored and controller along the path.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
V	Gantry	GantryStruct	Contains all information pertaining to a gantry system.	
V	SegmentData	SegmentStruct	Structure of data that contains the segment number, output code, and tool path endpoint for each segment in the motion path.	
VAR_INPUT			Default	
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is	FALSE



			initiated. To modify an input, change the value and re-trigger the execute input.	
V	PathID	PathIDStruct	Structure containing data to be shared between PathGenerator and MovePath functions.	n/a
B	Velocity	LREAL	Absolute value of the velocity in user units/second	LREAL#0.0
B	Acceleration	LREAL	Value of the acceleration in user units/second ² (acceleration is applicable with same sign of torque and velocity)	LREAL#0.0
B	Deceleration	LREAL	Value of the deceleration in user units/second ² (deceleration is applicable with opposite signs of torque and velocity)	LREAL#0.0
E	Jerk	LREAL	<i>Not supported; reserved for future use. Value of the jerk in [user units / second³].</i>	LREAL#0.0
VAR_OUTPUT				
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.	
B	CommandAborted	BOOL	Set high if motion is aborted by another motion command or MC_Stop. This output is cleared with the same behavior as the Done output.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
E	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	
V	ActiveSegment	INT	Indicates the active segment as the tool point moves along the path.	
V	OutputFlags	DWORD	Code which can be used to set up to 32 different outputs at various points along the motion path.	

Notes

- The motion path described is absolute relative from the start point of the move. The axes can be moved using other motion blocks prior to executing [Move Path](#) to account for offsets.



- See Yaskawa's Youtube channel for [more info](#), [details](#), and [examples](#).

Error Description


ErrorID	Meaning
0	No error
4369	The move could not be buffered because the axis motion queue is full. 16 moves is the maximum which can be buffered.
4370	The move could not be started because motion is prohibited. The drive may not be enabled. MC_Power.Enable_Positive or MC_Power.Enable_Negative might be low. Check MC_Power.Status output. MC_Stop.Execute might be held high, preventing motion.
4378	The function block is not applicable for the external axis specified
4380	MC_SetPosition can not be executed while the axis is moving.
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4382	When the axis is in rotary mode, and the MC_SetPosition tries to set a position that is equal to or greater than the MachineCycle, this error is generated, and the position is not set.
4390	Position cannot be defined while the axis is the cam master of other axes.
4394	More than 10 Y_CamIn, Y_CamOut, or MC_GearInPos function blocks for a given axis are active at the same time. Most likely the application program is not coded correctly, and the Execute input is being fired too frequently.
4395	Window parameters are outside of the cams Machine Cycle. (0 to Prm1502, the last master position in the active cam table.)
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4626	The master slave relationship is defined. A slave cannot be a master to another axis.
4633	Table size results in misaligned data. Refer to the help section "Internally Created Cam Data." A cam table will have a multiple of 16 bytes if created correctly.
4641	Buffer mode does not correspond to a valid enumeration value.
4642	Direction does not correspond to a valid enumeration value.
4643	Start mode does not correspond to a valid enumeration value.
4646	Mode does not correspond to a valid enumeration value.
4658	Velocity parameter is less than or equal to zero.
4659	Acceleration is less than or equal to zero.
4660	Deceleration is less than or equal to zero.
4667	Jerk is less than or equal to zero.
4669	Engage position is outside the cam table domain.
4670	Engage window is less than zero.
4887	CamTableID does not refer to a valid cam table.
4891	The slave axis can not be the same as the master axis.



4893	The specified external axis may not be used. A physical axis is required.
10059	The axes got out of sync during the path motion. All Cam Slaves InSync output must be on or off at the same time, or this ErrorID is generated.
57617	Instance object is NULL.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.
57874	Argument data is NULL. The EngageData input must be connected.

Example

Uses the profile described by the [PathStruct](#) data type and commands motion to the X, Y axes using a virtual axis as the master. This is shown in the figure below.



Consider the following contour:




```
VectorPath.Data[1].SegmentType:=TB_PatternType#Straightline;
VectorPath.Data[1].XCoord:=LREAL#0.0;
VectorPath.Data[1].YCoord:=LREAL#10.0;
VectorPath.Data[1].OutputFlags:=DWORD#1;
```

```
VectorPath.Data[2].SegmentType:=TB_PatternType#Arc;
VectorPath.Data[2].Radius:=LREAL#0.5;
VectorPath.Data[2].StartAngle:=LREAL#180.0;
VectorPath.Data[2].TraversedAngle:=LREAL#-180.0;
VectorPath.Data[2].Resolution:=REAL#0.05;
```


```
VectorPath.Data[3].SegmentType:=TB_PatternType#Straightline;
VectorPath.Data[3].XCoord:=LREAL#1.0;
VectorPath.Data[3].YCoord:=LREAL#0.0;
VectorPath.Data[3].OutputFlags:=DWORD#2;
```

```
VectorPath.Data[4].SegmentType:=TB_PatternType#Arc;
VectorPath.Data[4].Radius:=LREAL#0.5;
VectorPath.Data[4].StartAngle:=LREAL#0.0;
VectorPath.Data[4].TraversedAngle:=LREAL#-180.0;
VectorPath.Data[4].Resolution:=REAL#0.05;
```

```
VectorPath.Segments := INT#4;
```



The MovePath function block uses SegmentData and PathID from the [PathGenerator](#) function block and executes moves on the X and Y axes. If a profile is made up of multiple segments (4 in the example below), the active segment output indicates which segment is being run. Output flags can be set from this function block to turn outputs on. this can be useful for applications like cutting, scoring or glue dispensing where digital outputs can be used to fire end effectors.







Gantry Toolbox: Function Blocks



The logic analyzer plot of independent axis parameters from the above profile is given below. It can be seen that the outputs flags are set during segments 1 and 3. (defined in [PathStruct](#))



The actual profile plotted by the XY system is shown below





Code Example 2



Consider the following circular profile

```


(* Circular path*)
(*****)
2 CircularPath.Data[1].SegmentType:=TB_PatternType#Arc;
0.5000 CircularPath.Data[1].Radius:=LREAL#0.5;
180.0000 CircularPath.Data[1].StartAngle:=LREAL#180.0;
-360.0000 CircularPath.Data[1].TraversedAngle:=LREAL#-360.0;
0.0500 CircularPath.Data[1].Resolution:=REAL#0.05;

1 CircularPath.Segments := INT#1;

```



The logic analyzer traces from individual axes while Move_Path was busy is shown in the plot below






The actual profile plotted by the XY system is:

```

(* Circular path*)
(*****)
2 CircularPath.Data[1].SegmentType:=TB_PatternType#Arc;
0.5000 CircularPath.Data[1].Radius:=LREAL#0.5;
180.0000 CircularPath.Data[1].StartAngle:=LREAL#180.0;
-360.0000 CircularPath.Data[1].TraversedAngle:=LREAL#-360.0;
0.0500 CircularPath.Data[1].Resolution:=LREAL#0.05;

1 CircularPath.Segments := INT#1;

```



Application Example


Step1: Using Calculate_Angles FB to calculate the Start and Traverse angles for the flower path shown below.

```
Calculate_Angles_1(Execute:=TRUE, ArcDefinitionMode:=INT#1, X1:=LREAL#-1.0, X2:=LREAL#0.0, Y1:=LREAL#0.0, Y2:=LREAL#1.0, Radius:=LREAL#-1.0, Direction:=FALSE);
```

```
Calculate_Angles_2(Execute:=TRUE, ArcDefinitionMode:=INT#1, X1:=LREAL#0.0, X2:=LREAL#1.0, Y1:=LREAL#1.0, Y2:=LREAL#0.0, Radius:=LREAL#-1.0, Direction:=FALSE);
```

```
Calculate_Angles_3(Execute:=TRUE, ArcDefinitionMode:=INT#1, X1:=LREAL#1.0, X2:=LREAL#0.0, Y1:=LREAL#0.0, Y2:=LREAL#-1.0, Radius:=LREAL#-1.0, Direction:=FALSE);
```

```
Calculate_Angles_4(Execute:=TRUE, ArcDefinitionMode:=INT#1, X1:=LREAL#0.0, X2:=LREAL#-1.0, Y1:=LREAL#-1.0, Y2:=LREAL#0.0, Radius:=LREAL#-1.0, Direction:=FALSE);
```




Step 2: Use the PathGenerator FB to create the path and the Move_Path FB to implement XY motion.




```



FlowerPath.Data[1].SegmentType := TB_PatternType#Arc;
FlowerPath.Data[1].Radius := LREAL#1.0;
Calculate_Angles_1(Execute := TRUE, ArcDefinitionMode := INT#1, X1 := LREAL#-1.0, X2 := LREAL#0.0, Y1 := LREAL#0.0, Y2 := LREAL#1.0, Radius := LREAL#-1.0, Direction := FALSE);
FlowerPath.Data[1].StartAngle := Calculate_Angles_1.StartAngle;
FlowerPath.Data[1].TraversedAngle := Calculate_Angles_1.TraversedAngle;
FlowerPath.Data[1].Resolution := REAL#0.05;
    
```



Step 3: Validation using logic analyzer.




Step 4: Result on XY system.





PathGenerator



This function block pre processes path data to provide coordinated motion using the [Move_Path](#) function block. Support for X, XPrime, Y, Z, Theta, and a Tangent axis are provided.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
V	Path	PathStruct	Structure of data that describes a motion path containing straight lines and arc segments.	
V	SegmentData	SegmentStruct	Structure of data that contains the segment number, output code, and tool path endpoint for each segment in the motion path.	
VAR_INPUT				Default
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
V	TableSize	UDINT	This value must be the same as the definition of the ARRAY size of the MS_Array_Type in the MotionInfo DataTypes folder of either the PLCopen or DataTypes Toolbox.	UDINT#0




VAR_OUTPUT			
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.
V	PathID	PathIDStruct	For use by the Move_Path function block.


Notes

This function converts user defined straight line, arc segment, input and output data into cam files which produce coordinated motion. The cam files are loaded into the motion engine ready for use.

The inputs to the PathGenerator are shown below:



The outputs from the PathGenerator are shown below:



- See Yaskawa's Youtube channel for [more info](#), [details](#), and [examples](#).


Error Description

ErrorID	Meaning
<u>0</u>	No error
<u>10038</u>	CamData.LastSegment must be greater than 0 and less than 400, or whatever value has been declared as the ARRAY size in the CTB_Types file.
<u>10053</u>	DataPoint Error
<u>10054</u>	One of the segments in the path has an invalid Segment Type. Path.Data[Segment].SegmentType must be coded as either being a line (INT#1) or an arc (INT#2).
<u>10055</u>	The absolute sum of the motion for all axes relative travel from the previous segment cannot be zero. One axis must always be in motion from segment to segment, otherwise the virtual master distance cannot be calculated.
<u>10056</u>	Arc Error
<u>10057</u>	Point Error
<u>10058</u>	The start angle must be a value from 0.0 to 360.0 degrees

Usage Example




Gantry Toolbox: Function Blocks




PathStruct Example 1

Straight Line Path Example



```
VectorPath.Data[1] SegmentType = TB_PatternType#Straightline;
VectorPath.Data[1] XCoord = LREAL#10.0;
VectorPath.Data[1] YCoord = LREAL#10.0;
```

```
PathDetail:STRUCT
  SegmentType:INT;
  XCoord:LREAL;
  YCoord:LREAL;
  Radius:LREAL;
  StartAngle:LREAL;
  TraversedAngle:LREAL;
  Resolution:REAL;
  OutputFlags:DWORD;
  MasterEnd:LREAL;
END_STRUCT;
```



```
PathPointArray: ARRAY[0..100] OF PathDetail;
```


```
PathStruct: STRUCT
  Data:PathPointArray;
  Segments:INT;
END_STRUCT;
```

```
(* ENUM Type for PathDetail's SegmentType *)
TB_PatternType:
(
  na,
  StraightLine,
  Arc
```



PathStruct Example 2

Arc Path Example



```

VectorPath.Data[2].SegmentType:=TB_PatternType#Arc;
VectorPath.Data[2].Radius:=LREAL#5.0;
VectorPath.Data[2].StartAngle:=LREAL#180.0;
VectorPath.Data[2].TraversedAngle:=LREAL#-180.0;
VectorPath.Data[2].Resolution:=REAL#0.05;
VectorPath.Data[2].OutputFlags:=DWORD#2

```

```

PathDetail:STRUCT
  SegmentType:INT;
  XCoord:LREAL;
  YCoord:LREAL;
  Radius:LREAL;
  StartAngle:LREAL;
  TraversedAngle:LREAL;
  Resolution:REAL;
  OutputFlags:DWORD;
  MasterEnd:LREAL;
END_STRUCT;

PathPointArray: ARRAY[0..100] OF PathDetail;

PathStruct: STRUCT
  Data:PathPointArray;
  Segments:INT;
END_STRUCT;

(* ENUM Type for PathDetail's SegmentType *)
TB_PatternType:
(
  na,
  StraightLine,
  Arc
)

```

PathStruct Example 3



Complex Path Example

```

VectorPath.Data[1].SegmentType:=TB_PatternType#Straightline;
VectorPath.Data[1].XCoord:=LREAL#0.0;
VectorPath.Data[1].YCoord:=LREAL#10.0;
VectorPath.Data[1].OutputFlags:=DWORD#1;

```

```

VectorPath.Data[2].SegmentType:=TB_PatternType#Arc;
VectorPath.Data[2].Radius:=LREAL#0.5;
VectorPath.Data[2].StartAngle:=LREAL#180.0;
VectorPath.Data[2].TraversedAngle:=LREAL#-180.0;
VectorPath.Data[2].Resolution:=REAL#0.05;

```

```

VectorPath.Data[3].SegmentType:=TB_PatternType#Straightline;
VectorPath.Data[3].XCoord:=LREAL#1.0;
VectorPath.Data[3].YCoord:=LREAL#0.0;
VectorPath.Data[3].OutputFlags:=DWORD#2;

```

```


VectorPath.Data[4].SegmentType:=TB_PatternType#Arc;
VectorPath.Data[4].Radius:=LREAL#0.5;
VectorPath.Data[4].StartAngle:=LREAL#0.0;
VectorPath.Data[4].TraversedAngle:=LREAL#-180.0;
VectorPath.Data[4].Resolution:=REAL#0.05;

```

```

VectorPath.Segments := INT#4;

```



Application example

Step1: Using Calculate_Angles to calculate start and traverse angles for the flower path shown below

```

Calculate_Angles_1(Execute:=TRUE, ArcDefinitionMode := INT#1, X1:=LREAL#-1.0, X2:=LREAL#0.0, Y1:=LREAL#0.0, Y2:=LREAL#1.0, Radius:=LREAL#-1.0, Direction:=FALSE);

```

```

Calculate_Angles_2(Execute:=TRUE, ArcDefinitionMode := INT#1, X1:=LREAL#0.0, X2:=LREAL#1.0, Y1:=LREAL#1.0, Y2:=LREAL#0.0, Radius:=LREAL#-1.0, Direction:=FALSE);

```

```


Calculate_Angles_3(Execute:=TRUE, ArcDefinitionMode := INT#1, X1:=LREAL#1.0, X2:=LREAL#0.0, Y1:=LREAL#0.0, Y2:=LREAL#-1.0, Radius:=LREAL#-1.0, Direction:=FALSE);

```

```

Calculate_Angles_4(Execute:=TRUE, ArcDefinitionMode := INT#1, X1:=LREAL#0.0, X2:=LREAL#-1.0, Y1:=LREAL#-1.0, Y2:=LREAL#0.0, Radius:=LREAL#-1.0, Direction:=FALSE);

```




Step 2: Use PathGenerator create the path and Move_Path to implement XY motion




```

FlowerPath.Data[1].SegmentType := TB_PatternType#Arc;
FlowerPath.Data[1].Radius := LREAL#1.0;
Calculate_Angles_1(Execute := TRUE, ArcDefinitionMode := INT#1, X1 := LREAL#-1.0, X2 := LREAL#0.0, Y1 := LREAL#0.0, Y2 := LREAL#1.0, Radius := LREAL#-1.0, Direction := FALSE);
FlowerPath.Data[1].StartAngle := Calculate_Angles_1.StartAngle;
FlowerPath.Data[1].TraversedAngle := Calculate_Angles_1.TraversedAngle;
FlowerPath.Data[1].Resolution := REAL#0.05;



```



Step 3: Validation using logic analyzer




Step 4: Result on XY system





PathIDManager



This function block serves as a FIFO buffer for PathID's. Each time a new PathID is created, it will delete the memory allocated to the oldest set of CamTableIDs used for a PathID by using the Y_RemoveCamTable function block from the PLCopenPlus firmware library. This function block cleans up memory in IEC applications which build new paths on the fly. A circular buffer of four PathID tables is maintained in the PathIDManager. When the function block is executed a fifth time, it releases the memory area of the oldest PathID. The controller can allocate this memory area for new Paths or application code.

Parameters

*_	Parameter	Data Type	Description	
VAR_INPUT				Default
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
V	PathID	UINT	The most recent PathID created by Y_CamFileSelect or Y_CamStructSelect	UINT#0
VAR_OUTPUT				
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.	



B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Notes



- This function block is unnecessary in applications which use a single, static PathID.

Error Description

ErrorID	Meaning
0	No error
4887	CamTableID does not refer to a valid cam table.

Example 1


An example of using the CamTableManager is shown below; it operates very similarly to the PathIDManager function block. On the fifth execute of the PathIDManager block, the memory for the oldest Path ID gets released. In the example shown below, the memory for PathID 1 gets released. The next execution of the PathIDManager will release the memory for PathID 2.



Variable	Value	De
CamTables		
[0]	1	
[1]	2	
[2]	3	
[3]	4	
[4]	5	


Memory for Cam ID 1 gets cleared

Application Example





Pick_Part



Assuming that a gripper actuator is empty and available to pick up a part in its mechanism, this function block initiates a series of actions that involves moving the XY axes to a specific location, opening a gripper actuator, moving the Z axis to a "Down" location, closing the gripper (to pick a part), and then finally moving the Z axis back to its "Up" position.

Parameters

*_	Parameter	Data Type	Description
VAR_IN_OUT			
V	Gantry	GantryStruct	Contains all information pertaining to a gantry system.
VAR_INPUT			
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.
			Default FALSE
VAR_OUTPUT			
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.
B	CommandAborted	BOOL	Set high if motion is aborted by another motion command or MC_Stop. This output is cleared with the same behavior as the Done output.
B	Error	BOOL	Set high if error has occurred during the execution of the




			function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Error Description

ErrorID	Meaning
0	No error
4369	The move could not be buffered because the axis motion queue is full. 16 moves is the maximum which can be buffered.
4370	The move could not be started because motion is prohibited. The drive may not be enabled. MC_Power.Enable_Positive or MC_Power.Enable_Negative might be low. Check MC_Power.Status output. MC_Stop.Execute might be held high, preventing motion.
4378	The function block is not applicable for the external axis specified
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4641	Buffer mode does not correspond to a valid enumeration value.
4642	Direction does not correspond to a valid enumeration value.
4658	Velocity parameter is less than or equal to zero.
4659	Acceleration is less than or equal to zero.
4660	Deceleration is less than or equal to zero.
4667	Jerk is less than or equal to zero.
4893	The specified external axis may not be used. A physical axis is required.
10034	Interpolation calculation error.
10035	Gripper Close Error (Timeout)
10036	Gripper Open Error (Timeout)
57617	Instance object is NULL.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.



Place_Part



Given that a gripper actuator already has a part in its mechanism, this function block initiates a series of actions that involves moving the XY axes to a specific location, moving the Z axis to a "Down" location, opening the gripper (to place the part), and then finally moving the Z axis back to its "Up" position.

Parameters

*_	Parameter	Data Type	Description
VAR_IN_OUT			
V	Gantry	GantryStruct	Contains all information pertaining to a gantry system.
VAR_INPUT			
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.
VAR_OUTPUT			
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.
B	CommandAborted	BOOL	Set high if motion is aborted by another motion command or MC_Stop. This output is cleared with the same behavior as the Done output.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or




			'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Error Description

ErrorID	Meaning
0	No error
4369	The move could not be buffered because the axis motion queue is full. 16 moves is the maximum which can be buffered.
4370	The move could not be started because motion is prohibited. The drive may not be enabled. MC_Power.Enable_Positive or MC_Power.Enable_Negative might be low. Check MC_Power.Status output. MC_Stop.Execute might be held high, preventing motion.
4378	The function block is not applicable for the external axis specified
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4641	Buffer mode does not correspond to a valid enumeration value.
4642	Direction does not correspond to a valid enumeration value.
4658	Velocity parameter is less than or equal to zero.
4659	Acceleration is less than or equal to zero.
4660	Deceleration is less than or equal to zero.
4667	Jerk is less than or equal to zero.
4893	The specified external axis may not be used. A physical axis is required.
10034	Interpolation calculation error.
10035	Gripper Close Error (Timeout)
10036	Gripper Open Error (Timeout)
57617	Instance object is NULL.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.



SegmentLookup



This function block outputs the number of the segment currently active and also outputs the flags for the active segment.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
V	Segmentdata	SegmentStruct	Structure of data that contains the segment number, output code, and tool path endpoint for each segment in the motion path.	
VAR_INPUT			Default	
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
B	VectorPosition	BOOL	Position of the master vector (master axis)	FALSE
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	



B	ActiveSegment	INT	Current active segment
B	OutputFlags	DWORD	Outputs DWORD that can be used to control digital output patterns during segments

Error Description

ErrorID	Meaning
0	No error
10140	Must be greater than zero and less than 20

Example

Consider the profile shown below:

```

(*Racetrack path*)
(*=====*)

1 VectorPath.Data[1].SegmentType:=TB_PatternType#Straightline;
0.0000000 VectorPath.Data[1].XCoord:=LREAL#0.0;
10.0000000 VectorPath.Data[1].YCoord:=LREAL#10.0;
16#00000001 VectorPath.Data[1].OutputFlags:=DWORD#1;

2 VectorPath.Data[2].SegmentType:=TB_PatternType#Arc;
0.5000000 VectorPath.Data[2].Radius:=LREAL#0.5;
180.0000000 VectorPath.Data[2].StartAngle:=LREAL#180.0;
-180.0000000 VectorPath.Data[2].TraversedAngle:=LREAL#-180.0;
0.0500000 VectorPath.Data[2].Resolution:=REAL#0.05;

1 VectorPath.Data[3].SegmentType:=TB_PatternType#Straightline;
1.0000000 VectorPath.Data[3].XCoord:=LREAL#1.0;
0.0000000 VectorPath.Data[3].YCoord:=LREAL#0.0;
16#00000002 VectorPath.Data[3].OutputFlags:=DWORD#2;

2 VectorPath.Data[4].SegmentType:=TB_PatternType#Arc;
0.5000000 VectorPath.Data[4].Radius:=LREAL#0.5;
0.0000000 VectorPath.Data[4].StartAngle:=LREAL#0.0;
-180.0000000 VectorPath.Data[4].TraversedAngle:=LREAL#-180.0;
0.0500000 VectorPath.Data[4].Resolution:=REAL#0.05;



4 VectorPath.Segments := INT#4;

```

The output flags are set to DWORD#1 during segment 1 and set to DWORD#2 during segment 3. These can be seen in the logic analyzer plots from the SegmentLookup outputs.




Gantry Toolbox: Function Blocks





XY_MoveAbsolute



This function block will perform an absolute move the X and Y axes to a specific location within the gantry coordinate system. The X and Y axes must be specified in [GantryStruct](#) before executing this function block.

This block calculates the required acceleration, deceleration and velocity for each axis and then executes MC_MoveAbsolute function blocks simultaneously for each axis to create straight line motion at the tool point. This is not considered interpolated motion. If configured, no motion on the Z axis will occur.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
V	Gantry	GantryStruct	Contains all information pertaining to a gantry system.	
VAR_INPUT				
			Default	
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
B	X_Position	LREAL	Target X coordinate of the tool tip	0.0
B	Y_Position	LREAL	Target Y coordinate of the tool tip	0.0
B	Velocity	LREAL	Velocity of the tool tip	0.0
B	Acceleration	LREAL	Acceleration of the tool tip	0.0
B	Deceleration	LREAL	deceleration of the tool tip	0.0
VAR_OUTPUT				
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable'	



			input, and reset if Done, CommandAborted, or Error is true.
B	CommandAborted	BOOL	Set high if motion is aborted by another motion command or MC_Stop. This output is cleared with the same behavior as the Done output.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Error Description

ErrorID	Meaning
0	No error
4369	The move could not be buffered because the axis motion queue is full. 16 moves is the maximum which can be buffered.
4370	The move could not be started because motion is prohibited. The drive may not be enabled. MC_Power.Enable_Positive or MC_Power.Enable_Negative might be low. Check MC_Power.Status output. MC_Stop.Execute might be held high, preventing motion.
4378	The function block is not applicable for the external axis specified
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4641	Buffer mode does not correspond to a valid enumeration value.
4642	Direction does not correspond to a valid enumeration value.
4658	Velocity parameter is less than or equal to zero.
4659	Acceleration is less than or equal to zero.
4660	Deceleration is less than or equal to zero.
4667	Jerk is less than or equal to zero.
4893	The specified external axis may not be used. A physical axis is required.
10034	Interpolation calculation error.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.

Example



In the example shown below, the XY gantry tooltip is at coordinate 10,10. The target coordinate is 12,8. On executing the XY_MoveAbsolute function block, the X, Y axes move such that the tooltip's final position is 12, 8.



Gantry Toolbox: Function Blocks




The velocities, accelerations and decelerations of the two axes are calculated (in XY_MoveAbsolute) such that the individual axes start and stop at the same time instant.





XY_MoveRelative



This function block will perform a relative move on the tooltip in a gantry coordinate system. The X and Y axes must be specified in [GantryStruct](#) before executing this function block. This block calculates the required acceleration, deceleration and velocity for each axis and then executes MC_MoveRelative function blocks simultaneously for each axis to create straight line motion at the tool point. This is not considered interpolated motion. If configured, no motion on the Z axis will occur.

Parameters

*_	Parameter	Data Type	Description
VAR_IN_OUT			
V	Gantry	GantryStruct	Contains all information pertaining to a gantry system.
VAR_INPUT			
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.
B	X_Distance	LREAL	X coordinate distance to be moved
B	Y_Distance	LREAL	Y coordinate distance to be moved
B	Velocity	LREAL	Velocity of the tool tip



B	Acceleration	LREAL	Acceleration of the tool tip	0.0
B	Deceleration	BOOL	Deceleration of the tool tip	0.0
VAR_OUTPUT				
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.	
B	CommandAborted	BOOL	Set high if motion is aborted by another motion command or MC_Stop. This output is cleared with the same behavior as the Done output.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	

Error Description

ErrorID	Meaning
0	No error
4369	The move could not be buffered because the axis motion queue is full. 16 moves is the maximum which can be buffered.
4370	The move could not be started because motion is prohibited. The drive may not be enabled. MC_Power.Enable_Positive or MC_Power.Enable_Negative might be low. Check MC_Power.Status output. MC_Stop.Execute might be held high, preventing motion.
4378	The function block is not applicable for the external axis specified
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4641	Buffer mode does not correspond to a valid enumeration value.
4642	Direction does not correspond to a valid enumeration value.
4658	Velocity parameter is less than or equal to zero.
4659	Acceleration is less than or equal to zero.
4660	Deceleration is less than or equal to zero.
4667	Jerk is less than or equal to zero.
4893	The specified external axis may not be used. A physical axis is required.
10034	Interpolation calculation error.





57620

The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.

Example

In the example shown below, the X Y coordinate of the tool tip is 12,8. On commanding an XY_MoveRelative move of 12, 8, the tool tip moves to coordinates 24, 16. The velocities, accelerations and decelerations of the two axes are calculated (in XY_MoveRelative) such that the individual axes start and stop at the same time instant.





Math Toolbox


Math Toolbox

The Math toolbox contains many functions that already exist in the MotionWorks IEC Edit Wizard. The purpose for this duplication was originally to provide compatibility and support for the MP2600iec controller with its PLC operating system called eCLR. As of firmware version 1.2.3, the eCLR operating system supports EN / ENO input and outputs, but this Toolbox is still maintained for legacy support.

In addition to the many basic functions duplicated in this toolbox, some additional functionality is also provided.

Function Blocks

ATAN2



The ATAN2 function is useful in many applications involving vectors, such as finding the direction from one point to another. This two argument function is a variation of the ATAN function. For any LREAL arguments x and y , $\text{atan2}(y, x)$ is the angle between the positive x -axis of a plane and the point given by the coordinates (x, y) on it.

Parameters

* _	Parameter	Data Type	Description	
VAR_INPUT				Default
B	EN	BOOL	This function will continue to calculate the ATAN2 result while EN is held high.	FALSE
V	X	LREAL	X coordinate	LREAL#0.0
V	Y	LREAL	Y coordinate	LREAL#0.0
V	Output_Format	INT	Format of the output value. 0: radians $(-\pi, \pi]$ 1: radians $[0, 2\pi)$ 2: degrees $[0^\circ, 360^\circ)$	INT#0
VAR_OUTPUT				
B	ENO	BOOL	ENO will be high is EN is high and this function can calculate the Angle	
V	Angle	LREAL	The result of the ATAN2 calculation	


Notes




This is a function, not a function block and only provides one output. If ENO is not high when EN is high, this function cannot calculate the Angle.

Example

ATAN2 used with various output formats:



REM



This function block returns the modulo division result of two LREAL inputs. It is useful for determining the position within a MachineCycle.

Parameters

* _	Parameter	Data Type	Description	
VAR_INPUT				Default
B	EN	BOOL	This function will continue to calculate the remainder while EN his held high.	FALSE
V	Numerator	LREAL	The numerator for division, such as the free running motor position, which may be outside a desired range of values, such as 0 to 360.0	LREAL#0.0
V	Denominator	LREAL	The denominator for division, which is the desired max value for the Numerator input, such as 360.0	LREAL#0.0
VAR_OUTPUT				
B	ENO	BOOL	This output will be high if EN is high and thisfunction is able to calculate the remainder with no errors.	
V	REM	BOOL	This output contains the calculated remainder	

Error Description

This is a function, not a function block and only provides one output. If ENO is not high when EN is high, this function cannot calculate the remainder. Verify that the Denominator is not zero.

Example 1 - Structured Text

```
IF InternalMode=INT#1 THEN
```

(* These calculations are designed for a rotary knife, rotary placer, one way cam, etc. *)



```
Correction:=REM((-RegistrationData.BufferNonCyclic[TempUsePointer] - RegistrationData.SensorOffset),
CamMasterCycle) + ((ControlData.EndSyncPosition - ControlData.StartSyncPosition) / LREAL#2.0);
```

```
Duration:=RegistrationData.SensorDistance - ((ControlData.EndSyncPosition -
ControlData.StartSyncPosition) / LREAL#2.0) - (ActualPositionNonCyclic -
RegistrationData.BufferNonCyclic[TempUsePointer]);
```

ELSE



(* These calculations are designed for reciprocating cam profiles (Slave net change = zero each cycle, Out and Back *)

```
Correction:= - REM( REM(RegistrationData.BufferCyclic[TempUsePointer], CamMasterCycle) +
(RegistrationData.SensorDistance - ControlData.StartSyncPosition - ((ControlData.EndSyncPosition -
ControlData.StartSyncPosition) / LREAL#2.0))), CamMasterCycle);
```

```
Duration:=RegistrationData.SensorDistance - ControlData.StartSyncPosition - ((ControlData.EndSyncPosition
- ControlData.StartSyncPosition) / LREAL#2.0);
```

END_IF;

Example 2 - Function Block





Pack ML Toolbox

Getting Started: PackML

Requirements for v202

To use the PackML Toolbox, your project must also contain the following:

Firmware libraries:

- PROCONOS

User libraries:

- Math_Toolbox (v201 or higher)
- Yaskawa_Toolbox (v201 or higher)

Using the PackML Toolbox

See Yaskawa's [Understanding PackML Webinar](#) for an in depth look into this toolbox.



PackML Revision History

Current Version:

(***** 2012-03-28: v202 Released
*****)

- 1) Modified CM_Control_Inputs Function Block to turn off all CM commands if the EM is not active. Previously commands would still be sent unless the particular CM was deactivated.

Previous Versions:

(***** 2012-02-26: v201 released
*****)

- 1) First official release
- 2) Updated Math Toolbox link
- 3) Improved interlocking in the PackML_State_Diagram for Stop and Abort. There were instances on the beta applications

where the control could get stuck in a particular state.



Enumerated Types

Enumerated Type: PackMLState

ENUM Type for indicating the PackML state.

Data Type Declaration

```
PackMLState:(Undefined, Clearing, Stopped, Starting, Idle, Suspended,  
Execute, Stopping, Aborting, Aborted, Holding, Held, UnHolding, Suspending,  
UnSuspending, Resetting, Completing, Complete);
```

- (* Defined for PackMLState*)
- (* 0 : Undefined *)
- (* 1 : Clearing *)
- (* 2 : Stopped *)
- (* 3 : Starting *)
- (* 4 : Idle *)
- (* 5 : Suspended *)
- (* 6 : Execute *)
- (* 7 : Stopping *)
- (* 8 : Aborting *)
- (* 9 : Aborted *)
- (* 10 : Holding *)
- (* 11 : Held *)
- (* 12 : UnHolding *)
- (* 13 : Suspending *)
- (* 14 : UnSuspending *)
- (* 15 : Resetting *)



Pack ML Toolbox: DataTypes

- (* 16 : Completing *)

- (* 17 : Complete *)





Enumerated Type: PackMLState

ENUM Type for indicating the PackML state.

Data Type Declaration

```
PackMLState:(Undefined, Clearing, Stopped, Starting, Idle, Suspended,  
Execute, Stopping, Aborting, Aborted, Holding, Held, UnHolding, Suspending,  
UnSuspending, Resetting, Completing, Complete);
```

- (* Defined for PackMLState*)
- (* 0 : Undefined *)
- (* 1 : Clearing *)
- (* 2 : Stopped *)
- (* 3 : Starting *)
- (* 4 : Idle *)
- (* 5 : Suspended *)
- (* 6 : Execute *)
- (* 7 : Stopping *)
- (* 8 : Aborting *)
- (* 9 : Aborted *)
- (* 10 : Holding *)
- (* 11 : Held *)
- (* 12 : UnHolding *)
- (* 13 : Suspending *)
- (* 14 : UnSuspending *)
- (* 15 : Resetting *)
- (* 16 : Completing *)



Pack ML Toolbox: DataTypes

- (* 17 : Complete *)





DataTypes

Data Type: PackML_Commands_STRUCT

Supporting structure for [PackTags_Commands_STRUCT](#)

Data Type Declaration

```
PackML_Commands_STRUCT : STRUCT
```

```
Mode : DINT;      (* Mode command, Mode's can be customized according to the PackML standard or for the user's needs. See template documentation for more on mode customization *)
```

```
Reset : BOOL;    (* Command to Reset the Machine *)
```

```
Start : BOOL;    (* Command to Start the Machine *)
```

```
Stop : BOOL;     (* Command to Stop the Machine *)
```

```
Hold : BOOL;     (* Command to Hold the Machine *)
```

```
UnHold : BOOL;  (* Command to UnHold the Machine *)
```

```
Suspend : BOOL; (* Command to Suspend the Machine *)
```

```
UnSuspend : BOOL; (* Command to UnSuspend the Machine *)
```

```
Abort : BOOL;   (* Command to Abort the Machine *)
```

```
Clear : BOOL;   (* Command to Clear the Machine *)
```

```
StateComplete : BOOL; (* Command to enter the Completing State *)
```

```
END_STRUCT;
```



Data Type: EquipmentModule_STRUCT

Supporting data type used by [EquipmentModule_ARRAY](#).

Data Type Declaration

EquipmentModule_STRUCT: STRUCT

EnabledCMs : INT; (* Number of enabled Control Modules contained in the Equipment Module *)

CMs_Active : WORD; (* Every bit in this word indicates if a control module is active *)

CMs_NotDone : WORD; (* Every bit in this word indicates if a control module is done *)

CM_InactiveMask : WORD; (* Every bit in this word indicates if a control module is Inactive *)

CM : ControlModule_ARRAY; (* Array containing the Commands, Status and Active bits for the 16 Control Modules contained in the Equipment module *)

Cmd_Reset : BOOL; (* Command to Reset the machine *)

Sts_Resetting_SC : BOOL; (* When set, the machine is in the resetting state *)

Cmd_Start : BOOL; (* Command to Start the machine *)

Sts_Starting_SC : BOOL; (* When set, the machine is in the Starting state *)

Cmd_Stop : BOOL; (* Command to Stop the machine *)

Sts_Stopping_SC : BOOL; (* When set, the machine is in the Stopping state *)

Cmd_Hold : BOOL; (* Command to Hold the machine *)

Sts_Holding_SC : BOOL; (* When set, the machine is in the Holding state *)

Cmd_UnHold : BOOL; (* Command to Unhold the machine *)

Sts_UnHolding_SC : BOOL; (* When set, the machine is in the UnHolding state *)

Cmd_Suspend : BOOL; (* Command to Suspend the machine *)

Sts_Suspending_SC : BOOL; (* When set, the machine is in the Suspending state *)

Cmd_UnSuspend : BOOL; (* Command to UnSuspend the machine *)

Sts_UnSuspending_SC : BOOL; (* When set, the machine is in the UnSuspending state *)

Cmd_Abort : BOOL; (* Command to Abort the machine *)



Pack ML Toolbox: DataTypes



Sts_Aborting_SC : BOOL; (* When set, the machine is in the Aborting state *)

Cmd_Clear : BOOL; (* Command to Clear the machine *)

Sts_Clearing_SC : BOOL; (* When set, the machine is in the Clearing state *)

Sts_Executing_SC : BOOL; (* When set, the machine is in the Executing state *)

Cmd_StateComplete : BOOL; (* Command to enter the Completing State *)

Sts_Completing_SC : BOOL; (* When set, the machine is in the Completing state *)

ModuleActive : BOOL; (* Indicates if the module is active to receive commands *)

END_STRUCT;



Data Type: PackML_States_STRUCT

Supporting structure for [PackTags_Status_STRUCT](#)

Data Type Declaration

```
PackML_States_STRUCT : STRUCT
```

```
Clearing : BOOL;      (* Indicates the machine is in the Clearing State *)
```

```
Stopped : BOOL;      (* Indicates the machine is in the Stopped State *)
```

```
Starting : BOOL;     (* Indicates the machine is in the Starting State *)
```

```
Idle : BOOL;        (* Indicates the machine is in the Idle State *)
```

```
Suspended : BOOL;   (* Indicates the machine is in the Suspended State *)
```

```
Execute : BOOL;     (* Indicates the machine is in the Execute State *)
```

```
Stopping : BOOL;    (* Indicates the machine is in the Stopping State *)
```

```
Aborting : BOOL;   (* Indicates the machine is in the Aborting State *)
```

```
Aborted : BOOL;    (* Indicates the machine is in the Aborted State *)
```

```
Holding : BOOL;    (* Indicates the machine is in the Holding State *)
```

```
Held : BOOL;       (* Indicates the machine is in the Held State *)
```

```
UnHolding : BOOL;  (* Indicates the machine is in the UnHolding State *)
```

```
Suspending : BOOL; (* Indicates the machine is in the Suspending State *)
```

```
UnSuspending : BOOL; (* Indicates the machine is in the UnSuspending State *)
```

```
Resetting : BOOL;  (* Indicates the machine is in the Resetting State *)
```

```
Completing : BOOL; (* Indicates the machine is in the Completing State *)
```

```
Complete : BOOL;  (* Indicates the machine is in the Complete State *)
```

```
END_STRUCT;
```



Data Type: EquipmentModule_Array

Supporting Array used to pass commands and machine status to individual Equipment Modules.

Data Type Declaration

EquipmentModule_ARRAY : ARRAY[0..15] of EquipmentModule_STRUCT;



Data Type: UNitMachine_STRUCT

Contains all the information about the machine's current state for each EM and CM

Data Type Declaration

```
UNitmachine_STRUCT: STRUCT
```

```
PackML_StateControlReady : BOOL; (* Indicates when the PackML_State_Diagram function block is ready to control the machine *)
```

```
EnabledEMs : INT; (* Number of enabled equipment modules in the machine *)
```

```
EMs_Active : WORD; (* Every bit in this word indicates which equipment modules are Active *)
```

```
EMs_NotDone : WORD; (* Every bit in this word indicates which equipment modules are Not Done*)
```

```
EM_InactiveMask : WORD; (* Every bit in this word indicates which equipment modules are Inactive *)
```

```
EM : EquipmentModule_ARRAY; (* Array containing the Commands, Status and Active bits for the 16 Equipment Modules contained in the Machine*)
```

```
Sts_Resetting_SC : BOOL; (* When set, the machine is in the resetting state *)
```

```
Sts_Starting_SC : BOOL; (* When set, the machine is in the Starting state *)
```

```
Sts_Stopping_SC : BOOL; (* When set, the machine is in the Stopping state *)
```

```
Sts_Holding_SC : BOOL; (* When set, the machine is in the Holding state *)
```

```
Sts_UnHolding_SC : BOOL; (* When set, the machine is in the UnHolding state *)
```

```
Sts_Suspending_SC : BOOL; (* When set, the machine is in the Suspending state *)
```

```
Sts_UnSuspending_SC : BOOL; (*When set, the machine is in the UnSuspending state*)
```

```
Sts_Aborting_SC : BOOL; (* When set, the machine is in the Aborting state *)
```

```
Sts_Clearing_SC : BOOL; (* When set, the machine is in the Clearing state *)
```

```
Sts_Executing_SC : BOOL; (* When set, the machine is in the Executing state *)
```

```
Sts_Completing_SC : BOOL; (* When set, the machine is in the Completing state *)
```

```
END_STRUCT;
```



Data Type: PackTags_Admin_STRUCT

Data Type Declaration

PackTags_Admin_STRUCT : STRUCT

Alarm : EventHistoryArray; (* Array of Event information *)

StateCurrentTime : DINT; (* Amount of time spent in the current state *)

StateCumulativeTime : StateCumulativeArray; (* Array containing all the times spent in the different states *)

ModeCurrentTime : DINT; (* Amount of time spent in the current mode *)

ModeCumulativeTime : DINT_Array32; (* Array containing all the times spent in the different modes *)

AccumTimeSinceReset : DINT; (* Time since the cumulative and current times have been reset *)

ResetAllTimes : BOOL; (* Command to reset all timers *)

ResetCurrentModeTimes : BOOL; (* Command to reset all Current Times being tracked *)

TimeRollover : BOOL; (* Warning when the timer is approaching a roll over *)

ProdProcessed : DINT; (* Cumulative number of primary packages processed since the machine's counters and timers were reset *)

DefectiveProd : DINT; (* Cumulative number of defective packages processed since the machine's counters and timers were reset *)

ReWorkProd : DINT; (* Cumulative number of re-workable primary packages processed *)

UpstreamMessage : DINT;

DownstreamMessage : DINT;

CurrentUpstreamNodeID : DINT;

CurrentDownstreamNodeID : DINT;

END_STRUCT;



Data Type: PackTags_Status_STRUCT

Data Type Declaration

```
PackTags_Status_STRUCT : STRUCT

CommandRejected : BOOL; (* If an invalid request is given and rejected, this bit will be set *)

UnitModeCurrent : DINT; (*Current Machine Mode*)

UnitModeCurBit : DWORD; (*Current Machine Mode Bit*)

UnitModeCurrentName : STRING; (*Current Machine Mode Name*)

UnitModeRequested : BOOL; (*[1 = Acknowledges that a unit mode change has been requested]*)

UnitModeChangeInProgress : BOOL; (*[1 = Requested unit mode change in process]*)

ProcModeCurrent : DINT; (*Current Procedure Mode*)

ProcModeRequested : BOOL; (*[1 = Acknowledges that a procedure mode change has been requested]*)

ProcModeChangeInProgress : BOOL; (*[1 = Requested procedure mode change in process]*)

StateCurrent : DINT; (*Current Machine State*)

StateCurBit : DWORD;

StateCurrentName : STRING; (*Current Machine State Name*)

StateRequested : BOOL; (*[1 = Acknowledges that a state change has been requested]*)

StateChangeInProgress : BOOL; (*[1 = Requested state change in process]*)

StateChangeProgress : DINT; (* Percent Complete of current state *)

StateLastCompleted : DINT; (* Machine state last completed *)

SeqNumber : DINT;

CurMachSpd : DINT; (*Current Machine Speed In Primary Line Packages Per Minute*)

MatReady : DWORD; (*Material Interlocks*)

MatLow : DWORD; (*Material Interlocks*)

MachDesignSpeed : REAL; (* Speed the machine is designed to operate at in it's installed environment *)

State : PackML_States_STRUCT;
```



Pack ML Toolbox: DataTypes



ModeChangeNotAllowed : BOOL; (* This bit is set if an invalid mode change is requested and ignored *)

MachCycle : DINT; (* Indicates the number of completed machine cycles with or without product *)

ProdRatio : DINT; (* Quantity of primary packages per current package being produced *)

Dirty : BOOL; (* Set when the machine becomes dirty and machine must run through a cleaning cycle before production continues *)

Clean : BOOL; (* Bit is set after a cleaning cycle and reset once production begins again *)

TimeToDirty : DINT; (* Time remaining until machine becomes dirty again *)

EquipmentAllocatedToUnitModeID : DINT; (* Allocating a machine to operating a different mode than another duplicate machine *)

MachineReusableForUnitModeID : DINT; (* Indicates machine does not require immediate cleaning and can resume production in a specific time window *)

MachineReusableTimeLeft : DINT; (* Amount of time left for a system to be reusable for a specific Unit mode *)

MachineStoringProductID : DINT; (* For machines that have a storing capability *)

MachineTransferringProductID : DINT; (* For machines used in conveying, compacting and/or separating product and transferring it to other machinery *)

(* THE FOLLOWING FIELDS COME INITIALLY COMMENTED OUT TO SAVE MEMORY WHEN NOT USED *)

(* Node : Node_ARRAY; (*Node (machine) interface & ID structure*)

(* ProcessVariables : ProcessVariable_ARRAY; (* Machine Engineering Parameters *)

(* Product : Product_ARRAY; (* Machine Product/Recipe Parameters *)

(* Limits : Limit_ARRAY; (* Machine Parameter Prograble Limits *)

END_STRUCT;



Data Type: PackTags_Commands_STRUCT

Data Type Declaration

```
PackTags_Commands_STRUCT : STRUCT

UnitMode : DINT; (*Unit Mode Commanded*)

UnitModeChangeRequest : BOOL; (*[1 = Change Machine Mode to Commanded Value]*)

ProcMode : DINT; (*Procedure Mode Commanded*)

ProcModeChangeRequest : BOOL; (*[1 = Change Procedure Mode to Commanded Value]*)

CurMachSpeed : DINT; (*Machine Speed - In Primary Line Packages*)

MatReady : DWORD; (*Material Interlocks*)

MatLow : DWORD; (*Material Interlocks*)

ResetPackMLTimes : BOOL; (*[1 = Reset PackML Current Mode and State Current/Cumulative Times]*)

CntrlCmd : DINT; (* provides an alternate method of moving through the state diagram *)

StateCmd : PackML_Commands_STRUCT; (* A structure for Coordinating machine nodes *)

StateChangeRequest : BOOL; (* Indicates the state machine should proceed to the target state *)

CfgRemoteCmdEnable : BOOL;

RemoteModeCmd : DINT;

RemoteModeCmdChgReq : BOOL;

RemoteStateCmd : DINT;

RemoteStateCmdChgReq : BOOL;

TargetDownstreamNodeID : DINT;

TargetUpstreamNodeID : DINT;

ChangeNodeServicedUpstream : DINT;

ChangeNodeServicedDownstream: DINT;
```

(* THE FOLLOWING FIELDS COME INITIALLY COMMENTED OUT TO SAVE MEMORY WHEN NOT USED *)



Pack ML Toolbox: DataTypes



(* Node : Node_ARRAY; (*Node (machine) interface & ID structure*)

(* ProcessVariables : ProcessVariable_ARRAY; (* Machine Engineering Parameters *)

(* Product : Product_ARRAY; (* Machine Product/Recipe Parameters *)

(* Limits : Limit_ARRAY; (* Machine Parameter Prograble Limits *)

END_STRUCT;



Data Type: ControlModule_Array

Supporting array used to pass commands and machine status to individual Control Modules

Data Type Declaration

ControlModule_ARRAY : ARRAY[0..15] of PackML_Module_Commands_STRUCT;



Data Type: PackML_Module_Commands_STRUCT

Supporting data type used by [ControlModule_ARRAY](#)

Data Type Declaration

PackML_Module_Commands_STRUCT: STRUCT

Cmd_Reset : BOOL; (* Command to Reset the machine *)

Sts_Resetting_SC : BOOL; (* When set, the machine is in the resetting state *)

Cmd_Start : BOOL; (* Command to Start the machine *)

Sts_Starting_SC : BOOL; (* When set, the machine is in the Starting state *)

Cmd_Stop : BOOL; (* Command to Stop the machine *)

Sts_Stopping_SC : BOOL; (* When set, the machine is in the Stopping state *)

Cmd_Hold : BOOL; (* Command to Hold the machine *)

Sts_Holding_SC : BOOL; (* When set, the machine is in the Holding state *)

Cmd_UnHold : BOOL; (* Command to Unhold the machine *)

Sts_UnHolding_SC : BOOL; (* When set, the machine is in the UnHolding state *)

Cmd_Suspend : BOOL; (* Command to Suspend the machine *)

Sts_Suspending_SC : BOOL; (* When set, the machine is in the Suspending state *)

Cmd_UnSuspend : BOOL; (*Command to UnSuspend the machine *)

Sts_UnSuspending_SC : BOOL; (* When set, the machine is in the UnSuspending state *)

Cmd_Abort : BOOL; (* Command to Abort the machine *)

Sts_Aborting_SC : BOOL; (* When set, the machine is in the Aborting state *)

Cmd_Clear : BOOL; (* Command to Clear the machine *)

Sts_Clearing_SC : BOOL; (* When set, the machine is in the Clearing state *)

Sts_Executing_SC : BOOL; (* When set, the machine is in the Executing state *)

Cmd_StateComplete : BOOL; (* Command to enter the Completing State *)

Sts_Completing_SC : BOOL; (* When set, the machine is in the Completing state *)



Pack ML Toolbox: DataTypes



ModuleActive : BOOL; (* Indicates if the module is active to receive commands *)

END_STRUCT;



Data Type: Parameter_STRUCT

Supporting Structure for [Parameter_ARRAY](#)

Data Type Declaration

```
Parameter_STRUCT : STRUCT
```

```
ID : DINT; (* ID value assigned to the parameter *)
```

```
Name : STRING; (* Literal description of the parameter *)
```

```
Unit : STRING_5; (* Unit associated with the given parameter *)
```

```
Value : REAL; (*Numeric value associated with the given parameter *)
```

```
END_STRUCT;
```



Data Type: Parameter_ARRAY

An array containing the names, units and values of a given parameter

Data Type Declaration

```
Parameter_ARRAY : ARRAY[0..9] OF Parameter_STRUCT;
```



Data Type: ProcessVariable_STRUCT

Supporting structure for [ProcessVariable_ARRAY](#)

Data Type Declaration

```
ProcessVariable_STRUCT : STRUCT
```

```
ID : DINT; (* ID value assigned to the parameter *)
```

```
Name : STRING; (* Literal description of the parameter, can also be displayed on an HMI screen *)
```

```
Unit : STRING_5; (* Unit associated with the given parameter, can also be displayed on an HMI screen *)
```

```
Value : REAL; (*Numeric value associated with the given parameter, can also be displayed on an HMI screen *)
```

```
END_STRUCT;
```



Data Type: ProcessVariable_ARRAY

An array containing the names, units and values of a given parameter that are used across multiple machines and can be displayed on an HMI screen.

Data Type Declaration

```
ProcessVariable_ARRAY : ARRAY[0..9] OF ProcessVariable_STRUCT;
```



Data Type: Node_STRUCT

Supporting structure for [Node_ARRAY](#).

Data Type Declaration

```
Node_STRUCT : STRUCT
```

```
Number : INT; (* A chosen unique number of the Upstream/Downstream PackML machine *)
```

```
ControlCmdNumber : INT; (* User defined command to be sent from one node on the network to another *)
```

```
CmdValue : INT; (* A value to be associated with the ControlCmdNumber such as speed, or the mode requested to change to *)
```

```
Parameter : Parameter_ARRAY; (* An array of parameter names, values, and units of the parameter *)
```

```
END_STRUCT;
```




Data Type: Node_ARRAY

Array that contains information used to coordinating machine nodes in a cell of multiple units. The array can be expanded as needed.

Data Type Declaration

Node_ARRAY : ARRAY[0..7] OF Node_STRUCT;



Data Type: Ingredient_STRUCT

A structure of parameters containing information for a specific ingredient. Support structure for [Ingredient_ARRAY](#).

Data Type Declaration

```
Ingredient_STRUCT : STRUCT
```

```
ID : INT; (* ID value assigned to the ingredient *)
```

```
Parameter : Parameter_ARRAY; (* An array of parameters used for the specified Ingredient *)
```

```
END_STRUCT;
```



Data Type: Ingredient_ARRAY

An array that contains all the parameters for an ingredient

Data Type Declaration

`Ingredient_ARRAY : ARRAY[0..31] OF Ingredient_STRUCT;`



Data Type: Product_STRUCT

A structure containing product information

Data Type Declaration

```
Product_STRUCT : STRUCT
```

```
ProductID : INT; (* Used to indicate to the machine what product it is producing, also displayed on all HMI screens *)
```

```
ProcessVariables : ProcessVariable_ARRAY; (* Array of information containing parameters for multiple machines *)
```

```
Ingredients : Ingredient_ARRAY; (* An array containing all information regarding an ingredient *)
```

```
END_STRUCT;
```



Data Type: Product_ARRAY

An array containing product information

Data Type Declaration

```
Product_ARRAY : ARRAY[0..9] OF Product_STRUCT;
```



Data Type: Limit_STRUCT

Supporting structure for [Limit_ARRAY](#).

Data Type Declaration

```
Limit_STRUCT : STRUCT
```

```
ID : INT; (* User defined ID for the limit, 0000 reserved for no limit assigned *)
```

```
Name : STRING; (* Literal name for the limit *)
```

```
Unit : STRING_5; (* Unit of the limit value *)
```

```
Value : REAL; (* Value assigned to the limit *)
```

```
END_STRUCT;
```



Data Type: Limit_ARRAY

An array containing user defined machine limits.

Data Type Declaration

Limit_ARRAY : ARRAY[0..9] OF Limit_STRUCT;



Supporting Arrays

Arrays used by function blocks and other data types in the PackML Toolbox.

Data Type Declaration

TYPE

DINT_Array18 : ARRAY[0..17] OF DINT;

DINT_Array32 : ARRAY[0..31] OF DINT;

DINT_Array7 : ARRAY[0..6] OF DINT;

STRING_Array32 : ARRAY[0..31] OF STRING;

STRING_Array18 : ARRAY[0..17] OF STRING;

StateCumulativeArray : ARRAY[0..6] OF DINT_Array18; (* Default to max 6 Modes. Increase up to ..31 if more Modes are defined *)

STRING_5 : STRING(5);

STRING_40 : STRING(40);

STRING_200 : STRING(200);


BOOL_16 : ARRAY[0..15] OF BOOL;

END_TYPE



Function Blocks

CM_Control_Inputs



The CM_Control_Inputs function block passes the high level commands from the PackML_StateControl into each of the enabled and active Control Modules.

Parameters

*_	Parameter	Data Type	Description	
VAR_IN_OUT				
V	PML_Cmds	PackML_Commands_STRUCT	Structure that contains the current Unit mode of operation and the commands sent by PackML_StateMachine	
V	PML_States	PackML_States_STRUCT	Structure containing information about the current state the machine is operating in	
V	UnitMachine	UNitMachine_STRUCT	Structure containing all the information about the machines current state and mode of operation for all EMs and CMs	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while the enable is held high	FALSE
V	EM_Number	INT	The EM number corresponding to the EM in which this FB is located	0
V	CM_Mask	WORD	Mask to deactivate CMs. When a CM is	16#0000



			deactivated, commands will not be sent down to the CM, for testing purposes. Each bit corresponds to the same number CM to deactivate. (Example: to deactivate CM_3, set CM_Mask.X3
VAR_OUTPUT			
B	Valid	BOOL	Indicates that the outputs of the function are valid
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Enable' goes low.

Notes


- See template documentation for further details on recommended usage.

Error Description

ErrorID	Meaning
0	No Error
12560	Invalid Equipment Module number
12561	Equipment Module not enable in the system
12562	Invalid number of enabled Control Modules in selected Equipment Module



CM_Control_Outputs



The CM_Control_Outputs function block sets the State Complete bits for the control module to be passed up and assembled into the Equipment Module status in the EM00_ModuleControl worksheet.



Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
V	PML_States	PackML_States_STRUCT	Structure containing information about the current state the machine is operating in	
V	UnitMachine	UNitMachine_STRUCT	Structure containing all the information about the machines current state and mode of operation for all EMs and CMs	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while the enable is held high	FALSE
V	EM_Number	INT	The EM number corresponding to the EM in which this FB is located	0
V	CM_Number	WORD	The CM number corresponding to the CM in which this FB is located	0
B	Aborting_Done	BOOL	Setting this bit indicates that the current CM is done 'Aborting' and is ready to move to the next state	FALSE
B	Stopping_Done	BOOL	Setting this bit indicates that the current CM is done 'Stopping' and is ready to move to the next state	FALSE
B	Clearing_Done	BOOL	Setting this bit indicates that the current CM is done 'Clearing' and is ready to move to the next state	FALSE
B	Resetting_Done	BOOL	Setting this bit indicates that the current CM is done 'Resetting' and is ready to move to the next state	FALSE
B	Starting_Done	BOOL	Setting this bit indicates that the current CM is done 'Starting' and is ready to move to the next state	FALSE
B	Holding_Done	BOOL	Setting this bit indicates that the current CM is done 'Holding' and is ready to move to the next state	FALSE
B	UnHolding_Done	BOOL	Setting this bit indicates that the current CM is done	FALSE



			'UnHolding' and is ready to move to the next state	
B	Suspending_Done	BOOL	Setting this bit indicates that the current CM is done 'Suspending' and is ready to move to the next state	FALSE
B	UnSuspending_Done	BOOL	Setting this bit indicates that the current CM is done 'UnSuspending' and is ready to move to the next state	FALSE
B	Execute_Done	BOOL	Setting this bit indicates that the current CM is done 'Executing' and is ready to move to the next state	FALSE
B	Completing_Done	BOOL	Setting this bit indicates that the current CM is done 'Completing' and is ready to move to the next	FALSE
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Enable' goes low.	

Notes


- See template documentation for further details on recommended usage.

Error Description

ErrorID	Meaning
0	No Error
12560	Invalid Equipment Module number
12561	Equipment Module not enable in the system
12562	Invalid number of enabled Control Modules in selected Equipment Module



EM_ModuleSummation



The EM_Module_Summation function block rolls up all the Control Module State Complete bits for active and enabled CMs. The result is an overall Equipment Module State Complete bit that is transferred to the UN_ModuleControl Worksheet.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
V	UnitMachine	UNitMachine_STRUCT	Structure containing all the information about the machines current state and mode of operation for all EMs and CMs	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while the enable is held high	FALSE
V	EM_Number	INT	The EM number corresponding to the EM in which this FB is located	0
V	CM_Mask	WORD	Mask to deactivate CMs. When a CM is deactivated, commands will not be sent down to the CM, for testing purposes. Each bit corresponds to the same number CM to deactivate. (Example: to deactivate CM_3, set CM_Mask.X3 =TRUE)	16#0000
VAR_OUTPUT				



B	Valid	BOOL	Indicates that the outputs of the function are valid
B	CMs_Active	WORD	The list of active CMs. Same bit scheme as CM_Mask. (Example: if CMs_Active.X4 = TRUE
B	CMs_NotDone	WORD	A compilation of which Control Modules have not completed the transition task.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Enable' goes low.

Notes

- The user can identify those CMs stuck in transition by comparing the outputs CMs_Active and CMs_NotDone. These outputs are of WORD datatype, with each bit [x] representing the active status and transition status of CM[x]. Example: If the PackML command STOP was given, and CM[1] was enabled and active, but not finished stopping yet, the output of CMs_Active would be ...00111 while the output of CMs_NotDone would be ...00010. The user then knows that the process is stuck in CM[1]. The user would then go to the EM00_CM00_Control_Outputs worksheet to further drill into the problem.
- See template documentation for further details on recommended usage.

Error Description

ErrorID	Meaning
0	No Error
12560	Invalid Equipment Module number
12561	Equipment Module not enable in the system
12562	Invalid number of enabled Control Modules in selected Equipment Module



PackMLCommands_Init



The PackMLCommands_Init function block clears all commands and sets the machine to be in the stopped state.

Parameters


*	Parameter	Data Type	Description	
VAR_IN_OUT				
V	INP_PackMLCommands	PackML Module Commands_STRUCT	Structure containing the current state and commanded actions	
VAR_INPUT			Default	
B	EN	BOOL	The function will continue to execute while the enable is held high	FALSE
VAR_OUTPUT				
B	ENO	BOOL	Indicates that the outputs of the function are valid	

Notes

- Intended to be executed when initially entering the stopped state to clear all previous commands.



PackMLModeStateTimes



The PackMLModeStateTimes function block keeps track of the times spent in each mode and state of operation for the machine.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
V	AdminTags	PackTags_Admin_STRUCT	Structure containing alarm data from the machine.	
V	UnitMachine	UNitMachine_STRUCT	Structure containing all the information about the machines current state and mode of operation for all EMs and CMs	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while the enable is held high	FALSE
B	Cmd_ResetCurrModeTimes	BOOL	When set, all time counting will be stalled and all of the times	FALSE



			being counted for the Sts_ModeCurrent will be cleared.	
B	Cmd_ResetAllTimes	BOOL	When set, all times being monitored will be reset to zero. Time counting will also be stalled as long as this input is held high	FALSE
V	Sts_ModeCurrent	DINT	The current mode the machine is operating in	0
V	Sts_StateCurrent	DINT	The current state the machine is operating in	0
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid	
B	TimeRollOverWarning	BOOL	A warning is sent when any of the time accumulators is approaching rolling over	
B	Sts_StateCurrentSec	DINT	Time (in seconds) spent in the current state	
V	Sts_StateCumulativeSec	StateCumulativeArray	An array containing the times spent operating in different modes and states	
B	Sts_ModeCurrentSec	DINT	Time (in seconds) spent in the current mode	
V	Sts_ModeCumulativeSec	DINT_Array32	An array of times spent in each mode	
B	Sts_AccTimeSinceReset	DINT	Accumulated time since Cmd_ResetAllTimes went high or the program was stopped for any reason.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Enable' goes low.	

Notes

- See template documentation for further details on recommended usage.



Error Description

ErrorID	Meaning
0	No Error
12563	Time rollover warning



PackML_State_Diagram





Pack ML Toolbox: Function Blocks



The PackML_State_Diagram function block handles the operation of the state machine, including mode and state transitions, as defined in the OMAC PackML specification. This function block, when enabled, initializes the machine to be in mode 3 (Manual Mode) and in the Stopped state.

Parameters

*	Parameter	Data Type	Description
VAR_IN_OUT			
V	Cfg_ModeNames	STRING_Array32	An array of strings containing the names of the different Unit modes of operation
V	Cfg_ModeTransitions	DINT_Array32	An array of acceptable mode transition states. Mode changes into the NEW MODE can only be performed at the chosen states. Each element in the array represents a mode, and each bit in the array element represents a state. (Ex. To allow Mode Transitions for Mode 1 at Aborted (bit 9), Stopped (bit 2), and Idle (bit 4) states 0000 0000 0000 0000 0000 0010 0001 0100 = 16#0000_0214 = DINT#532 = Cfg_ModeTransitions[1])
V	Cfg_StateNames	STRING_Array18	An array of strings containing the names of all the PackML states
V	Cfg_DisableStates	DINT_Array32	An array representing each mode and their states. Each mode can disable certain states.(Ex In Manual Mode (Mode 3) disable Holding(10), Held(11), UnHolding(12), Suspended(5), Suspending(13), UnSuspending(14),Completing(16), Complete(17) = 0000 0000 0000 0011 0111 1100 0010 0000 = 16#0003_7C20 = DINT#228384 = Cfg_DisableStates[3])
V	UnitMachine	UnitMachine_STRUCT	Structure containing all the information about the machines current state and mode of operation for all EMs and CMs
VAR_INPUT			Default



B	EnableIn	BOOL	The function will continue to execute while the enable is held high	FALSE
B	Cmd_Mode	DINT	The value of the new mode the machine will transition to if possible. If the input remains unchanged, the machine will stay in the same mode of operation	0
B	Cmd_Reset	BOOL	Setting this bit sends the 'Restart' command to all enabled and active EMs if it is a legal transition from	FALSE
B	Cmd_Start	BOOL	Setting this bit sends the 'Start' command to all enabled and active EMs if it is a legal transition from the current machine state, otherwise the command will be ignored	FALSE
B	Cmd_Stop	BOOL	Setting this bit sends the 'Stop' command to all enabled and active EMs if it is a legal transition from the current machine state, otherwise the command will be ignored	FALSE
B	Cmd_Hold	BOOL	Setting this bit sends the 'Hold' command to all enabled and active EMs if it is a legal transition from the current machine state, otherwise the command will be ignored	FALSE
B	Cmd_UnHold	BOOL	Setting this bit sends the 'UnHold' command to all enabled and	FALSE



			active EMs if it is a legal transition from the current machine state, otherwise the command will be ignored	
B	Cmd_Suspend	BOOL	Setting this bit sends the 'Suspend' command to all enabled and active EMs if it is a legal transition from the current machine state, otherwise the command will be ignored	FALSE
B	Cmd_UnSuspend	BOOL	Setting this bit sends the 'UnSuspend' command to all enabled and active EMs if it is a legal transition from the current machine state, otherwise the command will be ignored	FALSE
B	Cmd_Abort	BOOL	Setting this bit sends the 'Abort' command to all enabled and active EMs if it is a legal transition from the current machine state, otherwise the command will be ignored	FALSE
B	Cmd_Clear	BOOL	Setting this bit sends the 'Clear' command to all enabled and active EMs if it is a legal transition from the current machine state, otherwise the command will be ignored	FALSE
B	Cmd_Complete	BOOL	Setting this bit sends the 'Complete' command to all	FALSE



			enabled and active EMs if it is a legal transition from the current machine state, otherwise the command will be ignored	
V	Cfg_RemoteModeCmd	DINT	The remotely requested mode to transition to	0
B	Inp_RemoteModeCmdChangeReq	BOOL	When this input is set, the machine will transition to the mode set by Cfg_RemoteModeCmd if it is a legal transition from the current state of the machine	FALSE
V	Inp_RemoteStateCmd	DINT	The remotely requested state to transition to	0
B	Inp_RemoteStateCmdChangeReq	BOOL	When this input is set, the machine will transition to the state set by Cfg_RemoteStateCmd if it is a legal transition from the current state of the machine	FALSE
VAR_OUTPUT				
B	EnableOut	BOOL	Indicates that the outputs of the function are valid	
B	Clearing	BOOL	When this bit is set, the machine is in the 'Clearing' state	
B	Stopped	BOOL	When this bit is set, the machine is in the 'Stopped' state	
B	Starting	BOOL	When this bit is set, the machine is in the 'Starting' state	
B	Idle	BOOL	When this bit is set, the machine is in the 'Idle' state	
B	Suspended	BOOL	When this bit is set, the machine is in the 'Suspended' state	
B	Execute	BOOL	When this bit is set, the machine is in the 'Execute' state	



B	Stopping	BOOL	When this bit is set, the machine is in the 'Stopping' state
B	Aborting	BOOL	When this bit is set, the machine is in the 'Aborting' state
B	Aborted	BOOL	When this bit is set, the machine is in the 'Aborted' state
B	Holding	BOOL	When this bit is set, the machine is in the 'Holding' state
B	Held	BOOL	When this bit is set, the machine is in the 'Held' state
B	UnHolding	BOOL	When this bit is set, the machine is in the 'UnHolding' state
B	Suspending	BOOL	When this bit is set, the machine is in the 'Suspending' state
B	UnSuspending	BOOL	When this bit is set, the machine is in the 'UnSuspending' state
B	Resetting	BOOL	When this bit is set, the machine is in the 'Resetting' state
B	Completing	BOOL	When this bit is set, the machine is in the 'Completing' state
B	Complete	BOOL	When this bit is set, the machine is in the 'Complete' state
B	ModeChangeNotAllowed	BOOL	When this bit is set, the requested Mode change isn't allowed and the machine will remain in the current mode and state.
V	Sts_StateCurrent	DINT	Number in decimal corresponding to the current state the machine is in
V	Sts_StateCurrentName	STRING	The name of the current state the machine is in
V	Sts_StateCurrentBits	DWORD	DWORD indicating the current state the machine is in (Ex. If Sts_StateCurrentBits[x] = 1, then the machine is in State x)
V	Sts_ModeCurrent	DINT	Number in decimal corresponding to the current mode the machine is in
V	Sts_ModeCurrentName	STRING	The name of the current mode the machine is in
V	StsModeCurrentBits	DWORD	DWORD indicating the current mode the machine is in (Ex. If Sts_ModeCurrentBits[x] = 1, then the machine is in State x)




Notes

- Should always be enabled when program is running to ensure proper operation of the state machine.
- See template documentation for further details on recommended usage.



UN_ModuleSummation



The UN_ModuleSummation function block rolls up all the Equipment Module State Complete bits for active, enabled EMs. The result is an overall PMLs State Complete bit that is transferred to the PackML_StateControl function.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
V	UnitMachine	UNitMachine_STRUCT	Structure containing all the information about the machines current state and mode of operation for all EMs and CMs	
V	PML_Cmds	PackML_Commands_STRUCT	Structure that contains the current Unit mode of operation and the commands sent by PackML_StateMachine	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while the enable is held high	FALSE
V	EM_Mask	WORD	Mask to deactivate EMs. When an EM is deactivated, commands will not be sent down to the EM, for testing purposes. Each bit corresponds to the same number EM to deactivate. (Example: to	16#0000



			deactivate EM_3, set EM_Mask.X3 =TRUE)
VAR_OUTPUT			
B	Valid	BOOL	Indicates that the outputs of the function are valid
B	EMs_Active	WORD	The list of active EMs. Same bit scheme as EM_Mask. (Example: if EMs_Active.X4 = TRUE then EM_4 is active)
B	EMs_NotDone	WORD	A compilation of which Equipment Modules have not completed the transition task.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Enable' goes low.

Error Description

ErrorID	Meaning
0	No Error

PLCopen Toolbox

PLCopen Toolbox

This toolbox already includes the PLCTaskInfoTypes and MotionBlockTypes DataTypes files typically included when starting a new project, so delete them from your project to avoid compile errors that indicate duplicate DataType definition.

Certain versions of this toolbox refer to the Math Toolbox for additional functionality. You must also include the Math Toolbox in your project to avoid compile errors.

See the [PLCopen Toolbox eLearning Modules](#) on Yaskawa's Youtube channel for video tutorials and examples.

The PLCopen Toolbox consists of the following:

Data Types:

Data Type	Description
AXIS_REF	Identifies an axis
AxisParamData	Supporting structure for AxisPrmArray. Used by the ReadAxisParameters function block
AxisParameterStruct	For use with the ReadAxisParameters function block
AxisPrmArray	Used by the ReadAxisParameters function block
AxisStruct	For use as a container for all axis related data. (Customizable)
CAMSWITCH_ARRAY	Supporting structure for CAMSWITCH_REF. Used by the Y_DigitalCamSwitch function block
CAMSWITCH_REF	Used by the Y_DigitalCamSwitch function block
CAMSWITCH_STRUCT	Supporting structure for CAMSWITCH_ARRAY. Used by the Y_DigitalCamSwitch function block
HomeStruct	For use with any HOME_*** function block
IndividualParamDetails	Used by the ReadAxisParameters function block
LatchBufferArray	Supporting structure for ProductBufferStruct. Used by the ReadAxisParameters function block
MoveStruct	For use with MC_MoveAbsolute, MC_MoveRelative, and MC_MoveVelocity
ProductBufferStruct	For use with the ProductBuffer function block
SWERROR_STRUCT	Used by the Y_DigitalCamSwitch function block
TRACK_ARRAY	Supporting structure for TRACK_REF. Used by the Y_DigitalCamSwitch function block
TRACK_REF	Used by the Y_DigitalCamSwitch function block
TRACK_STRUCT	Supporting structure for TRACK_ARRAY. Used by the Y_DigitalCamSwitch



function block

Enumerated Types:

Enumerated Type	Description
MC_Direction	For use with the Reverse_MC_Direction function block to select positive or negative direction for LimitDirection and PulseDirection
TB_AxisType	For use with the ReadAxisParameters function block to select the type of axis, such as servo, external encoder, VFD, etc.

Programs:

Program	Description
Initialize	A template of code which can be copied to reduce the time required to enter initialization code into your project.

Function Blocks:

Function Block	Description
AbsolutePositionManager	This function block can serve as a central point for monitoring, clearing, and defining the position of an absolute encoder.
AccDecLimits	Manages the parameters associated with enabling/disabling the acceleration and deceleration limits.
Axes_Interlock	Checks MC_ReadAxisError and the actual position of both axes to verify that they are both free of alarms and within the position tolerance specified.
AxisControl	Combines MC_Power, MCReadAxisError, and MC_Reset and provides separate outputs for controller and drive alarms and warnings.
AxisStatus	Uses MC_ReadAxisError to provide further breakdown of the ErrorClass and AxisErrorID.
ControllerAlarm	Provides a BOOL output to indicate if there is a controller alarm not related to an axis.
HighSpeedOutput	Combines several of the parameters for use with the High Speed Output function available on the LIO-01, LIO-02, LIO-06, and MP2600iec. It allows changing the "OnPosition" value on the fly. While the "OnPosition" will be triggered at the hardware level with a response time of 13us, the output will be turned off when either the MinDistance has been travelled or the MinTime has elapsed, which will be based on the application scan in which this function is operating.
Home_LS	Combines the PLCopen function blocks MC_StepLimitSwitch,



	MC_MoveRelative, and MC_SetPosition.
Home_LS_Pulse	Combines the PLCopen function blocks MC_StepLimitSwitch, MC_StepRefPulse, MC_MoveRelative, and MC_SetPosition.
Home_Pulse	Combines the PLCopen function blocks MC_StepRefPulse, MC_MoveRelative, and MC_SetPosition.
Jog	Combines the PLCopen functions MC_MoveVelocity and MC_Stop.
MoveRelative_ByTime	Converts the MoveTime input into acceleration, velocity, and deceleration.
PositionLimits	Enables or disables the position limit function.
ProductBuffer	Uses MC_TouchProbe and provides an array of recorded latch positions for the axis specified.
ReadAxisParameters	Reads all the commonly updated axis parameters that may be used within an application and copies them to an AxisParameterStruct.
Reverse_MC_Direction	Changes the enumerated type MC_Direction#positive_direction to MC_Direction#negative_direction or vice versa.
VelocityLimits	Enables or disables the velocity limit function.
Y_DigitalCamSwitch	Commands a group of discrete output bits analogous to a set of mechanical cam controlled switches driven by a rotating shaft.



Getting Started: PLCopen

Requirements for v205

To use the PLCopen Toolbox, your project must also contain the following:

Firmware libraries:

- YMotion
 - Only required if using the [ReadAxisParameters](#) function block

User libraries:

- DataTypes_Toolbox (v200 or higher)
- Math_Toolbox (v202 or higher)
 - Only required if using the [ProductBuffer](#) function block

Current Version:

New for PLCopen v205 – All firmware library DataType definitions were moved to a new toolbox called the DataTypes Toolbox. Formerly, the PLCopen Toolbox contained the MotionInfoTypes and the PLCTaskInfoTypes datatype files. These were removed and are now included in the DataTypes Toolbox. If upgrading from an older version of PLCopen Toolbox, you must do the following:

- 1) Include the DataTypes Toolbox in your project.
- 2) Remove any other Yaskawa supplied datatype files with firmware library definitions such as
 - a. ControllInfoTypes
 - b. YDeviceCommTypes

(***** 2013-09-01 v205 released - developed using firmware 2.5.0
 *****)

- 1) Removed references to Math Toolbox functions where possible. Only the ProductBuffer function block still requires the Math Toolbox.
- 2) Because of the reintroduction of functions with EN/ENO, the MP2600 requires firmware 2.1.
- 3) Moved all datatype definitions for firmware libraries to a new DataTypes Toolbox. Upgrading to PLCopen v205 will require deleting any Yaskawa firmware datatypes files and adding the DataTypes Toolbox.
- 4) JogToPosition - Fixed method in which a change of speed is detected to refire MC_MoveVelocity.

Previous Versions:

(***** 2013-03-15 v204 released - developed using firmware 2.4.0
 *****)

- 1) ProductBuffer - Swapped position of RegistrationData and ProductAxis to conform to VAR_IN_OUT convention.
- 2) AccDecLimits - Fixed several copy / paste errors and variable naming confusion.
- 3) AbsoluteEncoderManager - Verified operation using Signa-II 2 digit alarm formats.

(***** 2012-10-29 v203 released - developed using firmware 2.4.0
 *****)

- 1) AbsoluteEncoderManager - Removed the 'Active' contact from rung 5 to clear alarms that have been reset.
- 2) ReadAxisParameters - Added 14 parameters. (Mainly limit parameters)



- 3) Jog_To_Position - Improved deceleration ramp.
- 4) Feed_To_Length - Added. This function will index a default amount, and update the final target based on a registration input.

(***** 2012-06-29 v202 released - developed using firmware 2.2.1
 *****)

- 1) ReadAxisParameters - Added the following parameters FilterCmdVelocity 1021, CmdAcceleration 1022, and postFilterCmdTorque 1024.
- 2) PLCTaskInfoTypes - Added DataTypes to mirror the 2.0 additions for high resolution task timing.
- 3) AbsolutePositionManager - Added additional alarm detection to catch A830, A840, and ACC0 alarms. Also added code to clear EncoderAlarmID and ControllerAlarmID when the block goes inactive.
- 4) Jog_To_Position - Added. For rotary applications that must stop at a specific location.
- 5) HighSpeedOutput - Fixed issue with MinTime. Was not working correctly if Min Time not zero. (YEU)

(***** 2011-12-08 v201 released - developed using firmware 2.0.0
 *****)

- 1) ProductBuffer - Added two optional inputs to allow FB to operate in a test or simulation mode.
- 2) ReadAxisParameters - Disabled reading parameter 1311 because it causes an error on MP2600iec. This parameter is scheduled to return a zero instead of an ErrorID in firmware 2.2.
- 3) ReadAxisParameters - Fixed two swapped values CamOffset and CamScale were swapped in v200.

(***** 2011-07-29 v200 released - developed using firmware 2.0.0
 *****)

Built from v022beta

ReadAxisParameters - Upgraded to use the new Y_ReadMultipleParameters firmware function block.



(***** 2011-02-24 v022beta created - developed using firmware 2.0.0
*****)

- 1) Home_Init - Added for users who prefer to avoid structured text POU for initializing the HomeStruct
- 2) Math Toolbox - Upgraded to v004 with Enable / Valid as function block I/O for compatibility with FW 2.1*)
- 3) Changed AxisControl to allow clearing a drive warning while the servo is enabled.

(***** 2011-01-24 v021 released - developed using firmware 1.2.3
*****)

- 1) HighSpeedOutput - Added. For simplified operation with the external encoder high speed output.
- 2) Home_LS_Pulse - Added a MC_MoveRelative between searching for the limit switch and C channel to prevent ErrorID 4397 from occurring: "Over travel limit still ON after attempting to move away from it."
- 3) Axes_Interlock - Enhanced to work with axes configured for rotary mode.

(***** 2010-10-04 v020 released. developed using firmware 1.2.2.9
*****)

- 1) Jog - Rewrote function to follow the 'Enable' template standard created for ST functions.
- 2) ProductBuffer - Improved lockout operation when a manual offset was applied. See ProductBuffer FB comments for more details.
- 3) Jog - Improved Done output (It will only pulse; this block is a special case of Enable type)
- 4) AxisParams Struct - Added CamTableCumulativeOutput
- 5) Home_LS - Fixed rung 6 (incorrect execute bit), duplicated StartOffset from rung 5.
- 6) DigitalCamSwitch - Added. See the initialize POU for example data setup.
- 7) ReadAxisParameters - Added LoadType and MachineCycle parameters.
- 8) AbsolutePositionManager - Added. For confirmation that the absolute position was set and valid
- 9) Moved Math functions to Math Toolbox



(***** 2010-02-03 v019 released
*****)

- 1) CamGenerator - Added.
- 2) CamSlaveFeedToLength - Removed MC_AbortTrigger.
- 3) Fixed Missed Latch counter (not initialized properly)
- 4) Added CamMaster_Lookup, and SlaveIndex_Lookup
- 5) Added MissedLatch and LatchPosition outputs to CamSlave_FeedToLength
- 6) Improved ProductBuffer FB to account for external encoder master (prm 1016 / 1006 switch)
- 7) Added CamBlend function block
- 8) Added WindowCheck function block
- 9) CamGenerator formula type 4 (Cycloidal) changed to 3 (Simple harmonic). It was incorrectly identified.*)
- 10) Added ParamTypes input to ReadAxisParameters to increase efficiency of the function (Provides selective parameter reads by group.)
- 11) MOVED ALL CAMMING SUPPORT FUNCTIONS TO CAM TOOLBOX - FOR PRO VERSION ONLY.
- 12) The "PLCTaskInfoTypes" DataType file was removed from this Toolbox. If you need to replace it in your project, open a second copy of MotionWorks IEC, and open a project that already has the PLCTaskInfoTypes DataType file, then copy & paste it into your project explorer.

(***** 2009-10-27 v018 released
*****)

- 1) Added SensorWindow input to CamSlave FeedToLength
- 2) Added PositionLimits, VelocityLimits, and AccDecLimits function blocks
- 3) Removed Enable Servo FB, use AxisControl FB
- 4) Removed the variable Speed from HomeStruct, it was not used for anything.
- 5) Converted Home blocks removed all Set or RESET coils.
- 6) Added MOVE_UNIT & MOVE_LREAL function block to provide compatibility with MP2600iec.
- 7) AxesInterlock does not support rotary mode axes.



- 8) ReadAxisParameters changed to increase efficiency.
- 9) Added some outputs such as 'Valid' to some blocks for increased consistency with PLCopen.
- 10) First version formalized with help documentation.

(***** 2009-07-15 v017 released
 *****)

- 1) Created Home_Pulse, Homes to C Channel, performs moves offset and defines position.
- 2) Removed R_TRIGs from the ErrorID portion of Home_LS, Home_LS_Pulse, and Home_Pulse because it was preventing the blocks from showing errors.
- 3) Updated ProductBuffer function block for both modularized and non modularized latch data.
- 4) Updated ReadAxisParameters to include VAR_IN_OUT (for speed) and additional input parameter to specify axis type. Also reduced parameter set to eliminate those that typically do not change.
- 5) Added MC_Status data.
- 6) Improved interlock logic in Home_LS_Pulse, Home_LS, Home_Pulse functions, added CommandAborted as output, and fixed a typo in all three blocks where the variable attached to the Busy output of one of the internal blocks was referencing an error bit.

(***** 2009-05-28 v016 released
 *****)

- 1) Y_AdjustMode in the DataTypes file was incorrectly named Y_AdjustMethod.
- 2) Added NOT(Busy) to the Execute of MC_TouchProbe in CamSlave_FeedToLength. New Error code in firmware 1.1.2.5 caused new problem if the block was executed when already executing. This may occur if there is bounce on the input sensor.
- 3) Fixed MoveRelative_ByTime - calculations would cause error if negative distance. Also added checks for negative time (causes error) and zero distance (No Error)



(***** 2009-05-07 v015 released
*****)

1) Added interlock to Jog's MC_MoveVelocity to prevent rising edge of exe if Stop is busy to prevent ErrorID 4370 from appearing.

2) Added Axes_Interlock function.

(***** 2009-04-16 v014 released
*****)

(* Fixed AxisControl and Enable Servo to allow a re attempt to enable servo if MC_Power has Error. *)

(* Previously they had a normally closed contact from the MC_Power FB preventing the block from enabling *)

(* again. Also changed these two blocks to reset Error & ErrorID outputs when Enable=FALSE *)

(* Changed the Jog Block Error and ErrorID outputs to only come on if JogFwd or JogRev is On *)

(* Added CommandAborted to the Busy interlock circuits of Home_LS_Pulse and Home_LS. *)

(***** 2009-03-30 v013 released
*****)

Released version of v012.

1) Explicitly set some parameters in ReadAxisParameters to LREAL#0.0 and documented as being unavailable.

because they were causing Access Violation Errors when viewed in the Watch Window.

(***** 2009-01-27 v012 created
*****)

1) This version was released to a few people as a work in progress.

2) PLCopenPlus-v_2_2 firmware library used and included with this version.

3) Added LatchPositionNonCyclic to the AxisParameterStruct structure for ReadAxisParameters FB.

4) Corrected naming of Cam parameters 1500, 1501, 1502.

5) Corrected AxisStatus FB, Drive Warnings and Errors were backwards.

6) Changed AxisControl.ControlAlarmID And AxisStaus.ControlAlarmID to a 32 bit UDINT output.



- 7) Jog converted to PLCopen convention (outputs) and code converted to ST.
- 8) Added CamSlave_FeedToLength, which uses MC_TouchProbe, SlaveRegistrationCheck, and Y_SlaveOffset.

(***** 2009-01-27 v011 released
 *****)

- 1) PLCopenPlus-v_2_2 firmware library used and included with this version.
- 2) Added AxisStruct STRUCT
- (* Fixes *)
- 3) Simplified MoveRelativeByTime function, removed additional interlocks, and just copied MC_MoveRelative outputs to MoveRelativeByTime outputs. *)
- 4) Made corrections to the AxisParameterArray, added cam parameters. NOTE: will require controller firmware 1.1.0.4 or greater to read some of the cam parameters. Set the READ flag for those parameters to FALSE if you are using older firmware.

(***** 2009-01-12 v010 released
 *****)

- 1) PLCopenPlus-v_2_1 firmware library used and included with this version.
- 2) Changed interface of homing blocks to use HomeStruct. Makes FB smaller and quicker to enter home data.
- 3) Added example initialization code as a Program POU to enable cut & paste to speed development.
- 4) Open the Toolbox as a project in a second copy of MotionWorks IEC as a project to see the Initialization POU.
- 5) Added 'ControllerAlarm' function block to provide BOOL output when there is a controller alarm.
 (Uses Y_ReadAlarm and compares the AlarmID for non zero.
- 6) Added Homed BOOL to HomeStruct.

(***** 2008-11-05 v009 released
 *****)



- 1) Completed and tested the MoveRelative_ByTime function.
- 2) Previous versions would not allow the block to run more than once.

(***** 2008-10-17 v008 released
 *****)

- 1) In Home_LS_Pulse and Home_LS, added Reset Coil for Homing Done at the last rung.

(***** 2008-10-10 v007 released
 *****)

- 1) Added BOOL outputs to AxisControl (DriveAlarm, DriveWarning)
- 2) Fixed DriveWarningID and DriveAlarmID, they were backwards.

(***** 2008-10-02 v005 released
 *****)

Added Functions:

- 1) AxisControl
- 2) AxisStatus

Fixes:

- 3) Changed errant F_TRIG functions used in Home_LS_Pulse for ErrorID to R_TRIG.

(***** 2008-09-22 v004 released
 *****)

Changes:

- 1) EnableServo, upgraded to include ErrorClass output from MC_ReadAxisError from PLCopen.
- 2) FIRMWARE library 1.0.4.5 and PLCopenPlus-v_2_1
- 3) Includes structures for axis parameters and homing functions

Not complete:



4) MoveRelative_ByTime

(***** 2008-08-29 v003 released
*****)

Added Functions:

- 1) Home_LS_Pulse
- 2) Home_LS
- 3) ReadAxisParameters

Not complete:

- 4) MoveRelative_ByTime
- 5) NOTE: v0035 supplied with the MP2300Siec_Sales_Demo_v001

(***** 2008-05-20 v002 released
*****)

Includes:

- 1) EnableServo
- 2) Jog

Not complete:

- 3) MoveRelative_ByTime



Data Types

Data Types for PLCopen Toolbox

The following is a complete list of all DataTypes included in the PLCopen toolbox. The list is arranged to separate those that are used internally, and not useful outside of their particular function, and those that an application program must incorporate when the programmer wishes to use the associated Function Block.

Data Type	Usage
DataTypes for use with function blocks in the PLCopen firmware library	
HomeStruct	For use with any HOME_*** function block
MoveStruct	For use with MC_MoveAbsolute, MC_MoveRelative, and MC_MoveVelocity
DataTypes for external use with the PLCopen Toolbox function blocks	
AXIS_REF	Identifies an axis
AxisParamStruct	For use with the CamSlave_FeedToLength and CamSlave_WindowCheck function blocks.
AxisStruct	For use as a container for all axis related data. (Customizable)
MC_Direction	ENUM type for indicating positive or negative direction for LimitDirection and PulseDirection of the Reverse_MC_Direction function block
ProductBufferStruct	For use with the ProductBuffer function block
TB_AxisType	ENUM type for indicating the axis type for the ReadAxisParameters function block
DataTypes that support other DataTypes (no need for direct use by the programmer)	
AxisParamData	Supporting structure for AxisPrmArray. Used by the ReadAxisParameters function block
CAMSWITCH_ARRAY	Supporting structure for CAMSWITCH_REF. Used by the Y_DigitalCamSwitch function block
CAMSWITCH_STRUCT	Supporting structure for CAMSWITCH_ARRAY. Used by the Y_DigitalCamSwitch function block.
LatchBufferArray	Supporting structure for ProductBufferStruct Used by the ReadAxisParameters function block
TRACK_ARRAY	Supporting structure for TRACK_REF. Used by the Y_DigitalCamSwitch function block
TRACK_STRUCT	Supporting structure for TRACK_ARRAY. Used by the Y_DigitalCamSwitch function block
DataTypes used internally by PLCopen Toolbox function blocks	
AxisPrmArray	Used by the ReadAxisParameters function block
CAMSWITCH_REF	Used by the Y_DigitalCamSwitch function block
IndividualParamDetails	Used by the ReadAxisParameters function block
SWERRORSTRUCT	Used by the Y_DigitalCamSwitch function block
TRACK_REF	Used by the Y_DigitalCamSwitch function block



Data Type: AXIS_REF

The AXIS_REF data type identifies an axis and thus provides the interface to the hardware or virtual axes. AXIS_REF is used as VAR_IN_OUT in all Motion Control Function Blocks described in this Online help. It is represented as an input and an output connected by a horizontal line in the graphical representation of a function block.

The value of AxisNum is determined by the logical axis number assigned in the Hardware Configuration. See the Configuration tab for each axis.

Data Type Declaration

TYPE

AXIS_REF:STRUCT

AxisNum:UINT;

END_STRUCT;

END_TYPE

Variable Declaration Example

Name	Type	Usage
Default		
MC_ReadActualPosition_1	MC_ReadActual...	VAR
FeedAxis	AXIS_REF	VAR_EXTER...
AlwaysTrue	AXIS_REF	ER...
ReadActualPosValid1	BOOL	ER...
ReadActualPosBusy1	BYTE	ER...
ReadActualPosError1	CTD	ER...
ReadActualPosErrorID1	CTU	ER...
ReadActualPosPosition1	CTUD	ER...
ActualPosition1	REAL	VAR_EXTER...
MC_ReadActualVelocity_1	MC_ReadActual...	VAR
ReadActualVelValid1	BOOL	VAR_EXTER...

Code Example

```
AxisX.Number:=UINT#0;
MCMoveAbsoluteX(Axis:=AxisX, Execute:=FALSE);
AxisX:=MCMoveAbsolutX.Axis;
AxisY.Number:=UINT#0;
MCMoveAbsoluteY(Axis:=AxisY, Execute:=FALSE);
AxisX:=MCMoveAbsolutY.Axis;
```



Data Type: AxisParamData

Supporting structure for [AxisPrmArray](#). Used by the [ReadAxisParameters](#) function block.

Data Type Declaration

```
TYPE
```

```
AxisParamData:ARRAY[0..60] OF IndividualParamDetails;
```

```
END_TYPE
```



Data Type: AxisParameterStruct

For use with the [ReadAxisParameters](#) function block.

Data Type Declaration

TYPE

AxisParameterStruct:STRUCT

ActualPosition:LREAL; (* 1000 *)
ActualPositionCyclic:LREAL; (* 1005 *)
ActualPositionNonCyclic:LREAL; (* 1006 *)
ActualTorque:LREAL; (* 1004 *)
ActualVelocity:LREAL; (* 1001 *)
AtVelocity:BOOL; (* 1141 *)
BufferedMotionBlocks:LREAL; (* 1600 *)
CamMasterCycle:LREAL; (* 1512 *)
CamMasterPosition:LREAL; (* 1500 *)
CamMasterShiftedCyclic:LREAL; (* 1502 *)
CamMasterShiftedPosition:LREAL; (* 1501 *)
CamMasterScale:LREAL; (* 1510 *)
CamMasterShift:LREAL; (* 1511 *)
CamOffset:LREAL; (* 1531 *)
CamScale:LREAL; (* 1530 *)
CamShiftRemaining:LREAL; (* 1513 *)
CamState:LREAL; (* 1540 *)
CamTableIDEngaged:LREAL; (* 1541 *)
CamTableOutput:LREAL; (* 1520 *)
CommandedAcceleration:LREAL; (* 1012 *)



PLCopen Toolbox: DataTypes

```
CommandedPosition:LREAL;      (* 1010 *)  
  
CommandedPositionCyclic:LREAL;  (* 1015 *)  
  
CommandedPositionNonCyclic:LREAL; (* 1016 *)  
  
CommandedTorque:LREAL;         (* 1014 *)  
  
CommandedVelocity:LREAL;      (* 1011 *)  
  
InPosition:BOOL;              (* 1140 *)  
  
LatchPositionNonCyclic:LREAL;  (* 1031 *)  
  
PositionError:LREAL;          (* 1130 *)  
  
PositionWindow:LREAL;         (* 1120 *)  
  
END_STRUCT;  
  
END_TYPE
```





Data Type: AxisPrmArray

Used by the [ReadAxisParameters](#) function block.

Data Type Declaration

```
TYPE
```

```
AxisPrmArray: STRUCT
```

```
Param: AxisParamData;
```

```
END_STRUCT;
```

```
END_TYPE
```



Data Type: AxisStruct

For use as a container for all axis related data. (Customizable)

Data Type Declaration

TYPE

AxisStruct: STRUCT

Ref:AXIS_REF; (* Used with the Axis VAR_IN_OUT of many PLCopen function blocks *)

JogSpeed:LREAL; (* In user units/sec as defined in the Hardware Configuration *)

RunSpeed:LREAL; (* In user units/sec as defined in the Hardware Configuration *)

Position:LREAL; (* In user units as defined in the Hardware Configuration *)

Acceleration:LREAL; (* In user units/sec² as defined in the Hardware Configuration *)

Deceleration:LREAL; (* In user units/sec² as defined in the Hardware Configuration *)

Jerk:LREAL; (* In user units/sec/sec/sec as defined in the Hardware Configuration *)

Status:BOOL; (* To indicate if the drive is enabled *)

Warning:BOOL;

Alarm:BOOL;

DriveAlarmID:UINT;

DriveWarningID:UINT;

ControlAlarmID:UDINT;

Prm:[AxisParameterStruct](#);

Home:[HomeStruct](#);

Latch:RegistrationStruct;

Cam:[CamStruct](#);

END_STRUCT;



PLCopen Toolbox: DataTypes

END_TYPE





Data Type: CAMSWITCH_ARRAY

Supporting structure for [CAMSWITCH_REF](#). Used by the [Y_DigitalCamSwitch](#) function block.

Data Type Declaration

TYPE

CAMSWITCH_ARRAY: ARRAY[0..255] OF [CAMSWITCH_STRUCT](#);

END_TYPE



Data Type: CAMSWITCH_REF

Used by the [Y_DigitalCamSwitch](#) function block.

Data Type Declaration

TYPE

CAMSWITCH_REF:STRUCT

MasterType: INT; (* 0 = Infinite/Rotary, 1 = Finite/Linear *)

MachineCycle: LREAL;

(*This number should match the setting in the Hardware Configuration. Valid for Type = 0.*)

LastSwitch; INT; (* To limit the evaluation of the array *)

Switch:[CAMSWITCH_ARRAY](#);

END_STRUCT;

END_TYPE



Data Type: CAMSWITCH_STRUCT

Supporting structure for [CAMSWITCH_ARRAY](#). Used by the [Y_DigitalCamSwitch](#) function block.

Data Type Declaration

TYPE

CAMSWITCH_STRUCT:STRUCT

TrackNumber:INT;

(* A reference to the track number to which this switch is to be applied.

The PLS block will support up to 32 tracks. There is no limit to how many

switches can be assigned to a single track except for the maximum of 256 switches. *)

FirstOnPosition:LREAL;

(* Lower boundary where the switch is ON. *)

LastOnPosition:LREAL;

(* Upper boundary where the switch is ON. If LastOnPosition < FirstOnPosition,

then the switch should be OFF between the positions (inverse cam switch) *)

AxisDirection:INT;

(* The direction of the master for which this switch applies.

0 = Both Pos and Neg; 1 = Positive Only (future); 2 = Negative Only (future)

ONLY 0 should be implemented at this time. *)

CamSwitchMode:INT;

(* Position vs Time-Based output. 0 = Position. 1 = Time. *)

Duration:DINT;

(* The duration of the switch. If CamSwitchMode = 0 (Position) AND Duration

<> 0.0, this Duration will serve as a Maximum ON time for the switch. A setting

of 0.0 means infinite time. If CamSwitchMode = 1 (Time), this duration will

serve as the ON time of the switch once FirstOnPosition has been reached.



PLCopen Toolbox: DataTypes
A setting of 0.0 will result in a block error.*)



END_STRUCT;

END_TYPE



Data Type: HomeStruct

For use with all HOME_*** function blocks.

Data Type Declaration

TYPE

HomeStruct: STRUCT

Direction:INT; (* Used in conjunction with MC_StepLimit Function Block *)

SwitchMode:INT; (* Configuration for action of the home sensor. [See MC_SwitchMode] *)

TorqueLimit:LREAL; (* Default if unused [ZERO] is 100.00% of rated torque *)

ApproachVelocity:LREAL;

ApproachTimeLimit:LREAL; (* In seconds *)

ApproachDistanceLimit:LREAL;

AccDec:LREAL;

CreepVelocity:LREAL;

CreepTimeLimit:LREAL; (* In seconds *)

CreepDistanceLimit:LREAL;

Offset:LREAL; (* Position offset to MOVE after finding the last input device
(sensor of C channel) *)

OffsetVelocity:LREAL;

Position:LREAL; (* This is the location that will be defined when all homing
actions are complete, including the offset move. *)

Homed:BOOL; (* Flag to indicate that the axis was successfully homed *)

END_STRUCT;

END_TYPE



Data Type: IndividualParamDetails

Used by the [ReadAxisParameters](#) function block.

Data Type Declaration

IndividualParamDetails:STRUCT (* For internal use of the ReadAxisParameters Function Block *)

Num:UINT;

BValue:BOOL;

DValue:DINT;

LRValue:LREAL;

PType:INT; (* 1=BOOL, 2=BYTE, 3=INT, 4=DINT, 5=LREAL *)

AxisMask:WORD;

TypeMask:WORD;

END_STRUCT;



Data Type: LatchBufferArray

Supporting structure for [ProductBufferStruct](#) Used by the [ReadAxisParameters](#) function block.

Data Type Declaration

```
TYPE
```

```
LatchBufferArray: ARRAY[0..100] OF LREAL;
```

```
END_TYPE
```




Data Type: MoveStruct

For use with MC_MoveAbsolute, MC_MoveRelative, and MC_MoveVelocity.

Data Type Declaration

TYPE

MoveStruct:STRUCT

Position:LREAL; (* In user units as defined in the Hardware Configuration *)

Velocity:LREAL; (* In user units/sec as defined in the Hardware Configuration *)

Acceleration:LREAL; (* In user units/sec² as defined in the Hardware Configuration *)

Deceleration:LREAL; (* In user units/sec² as defined in the Hardware Configuration *)

Jerk:LREAL; (* In user units/sec/sec/sec as defined in the Hardware Configuration *)

END_STRUCT;

END_TYPE



Data Type: ProductBufferStruct

For use with the [ProductBuffer](#) function block.

Data Type Declaration

TYPE

ProductBufferStruct: STRUCT

BufferSize:INT; (* INPUT - Maximum number of registration marks to be tracked. (Circular buffer size). *)

BufferNonCyclic:[LatchBufferArray](#); (* OUTPUT - Array (circular buffer) of all recorded registration marks (unmodularized latch values). *)

BufferCyclic:[LatchBufferArray](#); (* OUTPUT - Array (circular buffer) of all recorded registration marks (modularized latch values). *)

Sensor:TRIGGER_REF; (* INPUT - TRIGGER_REF for the axis which registration marks are to be detected. *)

SensorDistance:LREAL; (* INPUT - Distance in units of the master axis from the registration sensor to the required synchronization point with a slave axis. *)

SensorOffset:LREAL; (* INPUT - If the sensor is an exact multiple of machine cycles from cut position, this number would be zero. *)

ManualOffset:LREAL; (* INPUT - Amount to adjust the synchronization point, typically comes from HMI. *)

LockoutDistance:LREAL; (* INPUT - Distance after recording a latch that another latch would be ignored as potential noise. *)

ProductAwayDistance:LREAL; (* INPUT - The distance the product travels from its initial detection until it is safely past the slave operation. *)

StorePointer:INT; (* OUTPUT - Array Index of the latch data that was stored after MC_TouchProbe. *)

UsePointer:INT; (* INPUT - Array Index of the latch data. *)

PrevUsePointer:INT; (* INPUT - Array Index of the previous latch data. *)



```
END_STRUCT;
```

```
END_TYPE
```

NOTES:

INPUT - Indicates a value that the USER must supply to the ProductBuffer function block.

OUTPUT - Indicates a value that the ProductBuffer function block will write to the structure for use in the application.

The following structure values are not used by the ProductBuffer function block, but are defined in the ProductBufferStruct because typical applications that can benefit from this function require this data for successful operation:

- SensorDistance
- SensorOffset
- ProductAwayDistance



Data Type: SWERROR_STRUCT

Used by the [Y_DigitalCamSwitch](#) function block

Data Type Declaration

TYPE

SWERROR_STRUCT: STRUCT

TrackNumber: INT;

(* The last switch number where an invalid setting for TrackNumber occurred *)

FirstOnPosition: INT;

(* The last switch number where an invalid setting for FirstOnPosition occurred *)

LastOnPosition: INT;

(* The last switch number where an invalid setting for LastOnPosition occurred *)

AxisDirection: INT;

(* The last switch number where an invalid setting for AxisDirection occurred *)

CamSwitchMode: INT;

(* The last switch number where an invalid setting for CamSwitchMode occurred *)

Duration: INT;

(* The last switch number where an invalid setting for Duration occurred *)

ImproperOnPosition: INT;

(* The last switch number where an improper relationship between FirstOnPosition and LastOnPosition occurred *)

OnOffPositionError: INT;

(* The last switch number where the OnCompensationScaler and/or OffCompensationScaler resulted in an improper relationship between the modified FirstOn and LastOn positions. *)

END_STRUCT;





Data Type: TRACK_ARRAY

Supporting structure for [TRACK_REF](#). Used by the [Y_DigitalCamSwitch](#) function block.

Data Type Declaration

TYPE

TRACK_ARRAY: ARRAY[0..31] OF [TRACK_STRUCT](#);

END_TYPE



Data Type: TRACK_REF

Used by the [Y_DigitalCamSwitch](#) function block.

Data Type Declaration

TYPE

TRACK_REF:STRUCT

Track:[TRACK_ARRAY](#);

END_STRUCT;

END_TYPE



Data Type: TRACK_STRUCT

Supporting structure for [TRACK_ARRAY](#). Used by the [Y_DigitalCamSwitch](#) function block.

Data Type Declaration

TYPE

TRACK_STRUCT:STRUCT

OnCompensationScaler:LREAL;

(* Compensation for the FirstOnPosition of each switch on the track. + = advance, - = delay*)

OffCompensationScaler:LREAL;

(* SpeedCompensation for the LastOnPosition of each switch on the track.*)

Value: BOOLEAN;

(* The resulting status of the track after evaluating and combining all switches that affect the track.*)

END_STRUCT;

END_TYPE



Enumerated Types

Enumerated Type: MC_Direction

ENUM type for indicating the axis type for the [Reverse MC Direction](#) function block.

Data Type Declaration

(* ENUM Type for LimitDirection and PulseDirection *)

```
MC_Direction:(positive_direction, negative_direction);
```



Enumerated Type: TB_AxisType

ENUM type for indicating the axis type for the [ReadAxisParameters](#) function block.

Data Type Declaration

(* ENUM Type for AxisCode *)

```
TB_AxisType:(Servo, VFD, Stepper, Virtual, External);
```



PTB_Initialize


This is not a function block but a Program POU in the Toolbox. Its purpose is to reduce the time required to enter initialization code into your project. If you use the provided datatypes, time can be saved by copying and pasting structured text code from this POU into your Initialization POU, then replacing the string "Replace_Me?" with another name meaningful to the application.

This POU is not intended to be selected for execution in a task in your application program.



Function Blocks

AbsolutePositionManager



This function monitors for any controller or servo alarm related to the absolute encoder or battery backed encoder offset data stored in the controller. It can serve as the single point of monitoring, clearing, and defining the position of an absolute encoder. This function includes a retained Boolean output variable that once set, requires that the alarm be cleared through this function, and that the position of the encoder is redefined. The intention is to prevent the machine from operating until the position of the absolute encoder has been calibrated to the machine coordinates.

This function includes the following PLCopen function blocks: MC_ReadAxisError, MC_ReadAlarm, MC_ResetAbsoluteEncoder, Y_ClearAlarm and MC_SetPosition.

Parameters

*_	Parameter	Data Type	Description
VAR_IN_OUT			
B	Axis	AXIS_REF	Logical axis reference. This value can be located on the



			Configuration tab in the Hardware Configuration (logical axis number).
VAR_INPUT			Default
B	Enable	BOOL	The function will continue to execute while enable is held high.
V	SetPosition	BOOL	Value of the absolute position [u] to be set when homing is done. The reference
V	Position	LREAL	A positive or negative value within the coordinate system in user units.
V	ResetEncoder	BOOL	Initiates the Y_ResetAbsoluteEncoder function to clear any absolute encoder related SERVOPACK alarm, including A.810 and A.CC0
VAR_OUTPUT			
B	Valid	BOOL	Indicates that the outputs of the function are valid.
V	SetPositionDone	BOOL	Indicates that MC_SetPosition has successfully completed.
V	PositionValid	BOOL	Indicates that the absolute encoder has no alarms, and the MC_SetPosition has been used at some point in the past to align the encoder with the mechanical system.
V	ResetDone	BOOL	Indicates that the ResetEncoder request has completed successfully.
V	EncoderAlarmID	UINT	SERVOPACK alarm related to the absolute encoder.
V	ControllerAlarmID	UDINT	Controller alarm related to the SRAM or battery, which stores the absolute encoder offset.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Notes

- Check the Hardware Configuration to ensure that the alarm format for Sigma III and higher drives is set for 3 digit alarm mode.
- See the [AbsolutePositionManager eLearning Module](#) on Yaskawa's YouTube channel.

Error Description


ErrorID	Meaning
4378	The function block is not applicable for the external axis specified
4380	MC_SetPosition can not be executed while the axis is moving.



4382	When the axis is in rotary mode, and the MC_SetPosition tries to set a position that is equal to or greater than the MachineCycle, this error is generated, and the position is not set.
4390	Position cannot be defined while the axis is the cam master of other axes.
4391	The function block cannot be used with a virtual axis.
4401	Axis latch function already in use.
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4646	Mode does not correspond to a valid enumeration value.
45335	Failed to initialize absolute encoder.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.



AccDecLimits



This function block manages the parameters associated with enabling/disabling the acceleration and deceleration limits. The limits can be enabled or disabled and the values of the limits can be input and verified at the output. The outputs are provided as an echo from the motion engine. This function allows for streaming of variable limits.

Parameters

* _	Parameter	Data Type	Description	
VAR_IN_OUT				
B	Axis	AXIS_REF	Logical axis reference. This value can be located on the Configuration tab in the Hardware Configuration (logical axis number).	
VAR_INPUT			Default	
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
V	LimitAccDecEnable	BOOL	Enables or Disables the Limit Accel Decel function. Parameter 1222 and 1232 are combined	FALSE
V	LimitAccelPositive	LREAL	Parameter 1221	LREAL#0.0




V	LimitAccelNegative	LREAL	Parameter 1220	LREAL#0.0
V	LimitDecelPositive	LREAL	Parameter 1231	LREAL#0.0
V	LimitDecelNegative	LREAL	Parameter 1230	LREAL#0.0
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
V	LimitAccDecEnableEcho	BOOL	Echo of Parameter 1222 ANDed with 1232	
V	LimitAccelPositiveEcho	LREAL	Echo of parameter 1221 echoed from motion engine	
V	LimitAccelNegativeEcho	LREAL	Echo of parameter 1220 echoed from motion engine	
V	LimitDecelPositiveEcho	LREAL	Echo of parameter 1231 echoed from motion engine	
V	LimitDecelNegativeEcho	LREAL	Echo of parameter 1230 echoed from motion engine	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	

Notes

The function block uses MC_ReadBoolParameter, MC_WriteBoolParameter, MC_ReadParameter, and MC_WriteParameter.




Hardware Configuration



Always Loaded at power up


Application Program



Changing Accel / Decel limit values via MC_WriteParameter at run time will supersede the values stored in the Hardware Configuration, but the Hardware Configuration values will be reloaded at power up.

LimitAccelEnable [1222]
LimitAccelPositive [1221]
LimitAccelNegative [1220]

LimitDecelEnable [1232]
LimitDecelPositive [1231]
LimitDecelNegative [1230]



Accel / Decel Limits

- The software acceleration & deceleration limits are managed by the MP2000ie controller.
- When an acceleration or deceleration limit is exceeded, a controller alarm will be generated, obtainable via the MC_ReadAxisError function block, or the web server.
- The controller alarm will be 16#3202 0005 if the positive position limit is exceeded and 16#3202 0006 if the negative position limit is exceeded.

Acceleration Limits

- Acceleration is defined as increasing velocity away from zero.
- The parameters are called LimitAccelPositive and LimitAccelNegative, with values of UINT#1221 and UINT#1220 respectively. Use the MC_WriteParameter function block for these and all controller side parameters. Acceleration limit parameters are in user units / sec².
- To disable the acceleration limit, set LimitAccelEnable, parameter 1222 to zero.

Deceleration Limits

- Deceleration is defined by decreasing velocity towards zero.



PLCopen Toolbox: Function Blocks




- The parameters are called LimitDecelPositive and LimitDecelNegative, with values of UINT#1231 and UINT#1230 respectively. Use the MC_WriteParameter function block for these and all controller side parameters. Deceleration limit parameters are in user units / sec².
- To disable the deceleration limit, set LimitDecelEnable, parameter 1232 to zero.

Error Description

ErrorID	Meaning
0	No error
4378	The function block is not applicable for the external axis specified
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4648	The parameter number does not exist for the specified axis
10030	Positive Acceleration Limit must be greater than 0.
10031	Negative Acceleration Limit must be less than 0.
10032	Positive Deceleration Limit must be greater than 0.
10033	Negative Deceleration Limit must be less than 0.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.



Axes_Interlock



This function block checks MC_ReadAxisError and the actual position of both axes to verify that they are both free of alarms and within the position tolerance specified. It is intended for use with axes that operate on the same mechanical load and must remain within tolerance to avoid equipment damage, such as an X, X Prime gantry system. The output "Locked?" will be high to indicate that the axes are synchronized and free of errors.

Support for axes configured in rotary mode requires controller firmware 1.2.3 and PLCopen Toolbox v021.

Parameters

* _	Parameter	Data Type	Description	
VAR_IN_OUT				
B	Axis1	AXIS_REF	Logical axis reference. This value can be located on the Configuration tab in the Hardware Configuration (logical axis number).	
B	Axis2	AXIS_REF	Logical axis reference. This value can be located on the Configuration tab in the Hardware Configuration (logical axis number).	
VAR_INPUT			Default	
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
V	Tolerance	LREAL	The allowable position difference between the two axes in user units.	LREAL#0.0



V	Offset	LREAL	Offset between the two axes. This value will be considered when comparing the positions	LREAL#0.0
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
B	Locked	BOOL	Indicates TRUE if neither axis has an alarm and the position deviation is less than the specified tolerance.	
B	Deviation	BOOL	The amount of positional difference between the two axes.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	

Notes

- It is assumed that the axes have the same user units because they are operating the same load.
- See the [AxesInterlock eLearning Module](#) on Yaskawa's YouTube channel.


Error Description

ErrorID	Meaning
0	No error
4378	The function block is not applicable for the external axis specified
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.

e



AxisControl



This function block combines MC_Power, MC_ReadAxisError, and MC_Reset and provides separate outputs for controller and drive alarms and warnings.

Parameters

*_	Parameter	Data Type	Description	
VAR_IN_OUT				
B	Axis	AXIS_REF	Logical axis reference. This value can be located on the Configuration tab in the Hardware Configuration (logical axis number).	
VAR_INPUT				
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
E	EnablePositive	BOOL	Not Supported	FALSE
E	EnableNegative	BOOL	Not Supported	FALSE



V	AlarmClear	BOOL	Clears axis related alarms using MC_Reset	FALSE
VAR_OUTPUT				
B	Status	BOOL	TRUE if the drive is enabled. This output is derived from the Status output of MC_Power.	
V	AxisAlarm	BOOL	Indicates if there is an axis specific alarm on either the controller or drive.	
V	DriveWarning	BOOL	Indicates a warning on the drive, such as any A.9x display on the drive.	
V	DriveWarningID	UINT	Indicates the drive warning number, such as 95 (overload warning). Refer to the drive manual for troubleshooting.	
V	DriveAlarmID	UINT	Indicates the drive alarm number, such as C9 (encoder disconnected). Refer to the drive manual for troubleshooting.	
V	ControllerAlarmID	UDINT	Indicates the controller alarm ID number, such as 3302 0018. (shown in hex.) Refer to the Controller AlarmID list in the PLCopenPlus manual for troubleshooting.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
E	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	

Notes

When attempting to clear an alarm, the enable input must be FALSE or the alarm reset function will be blocked from executing.

We recommend viewing the alarm and warning output ID's in Hex, because all Yaskawa ServoPack documentation lists the amplifier alarm codes in Hex. This simplifies alarm identification. Note that MotionWorks IEC may show the value at the output in decimal. For example, a DriveAlarmID of 2064 converted to hex is 810, which is the Servopack alarm for the absolute encoder. "A81" will be displayed on the front of the Servopack.

Remember that this function only reports axis specific alarms and warnings. For general system alarms, use the Y_ReadAlarms function block from the PLCopenPlus firmware library.

Error Description


ErrorID	Meaning
0	No error
4370	The move could not be started because motion is prohibited. The drive may not be enabled. MC_Power.Enable_Positive or MC_Power.Enable_Negative might be low. Check MC_Power.Status output. MC_Stop.Execute might be held high, preventing motion.
4371	The servo drive failed to enable or disable. Check the amplifier wiring for L1 / L2 / L3



4378	The function block is not applicable for the external axis specified
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4399	The L1 / L2 / L3 power inputs on the drive may not be supplied with power, possibly due to an E-Stop condition.
4400	The Safety input (HHB) is preventing the drive from enabling.
4414	MECHATROLINK Communications to the drive was disrupted. Execute MC_Reset to restore the connection.
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4641	Buffer mode does not correspond to a valid enumeration value.
4893	The specified external axis may not be used. A physical axis is required.
4894	The specified virtual axis may not be used with this function block.
45332	Sending clear alarms command to servo drive failed.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.
61713	An internal assertion in the motion kernel failed indicating the controller is not in a stable state. Please report this error to Yaskawa America Incorporated.



AxisStatus



This function block uses MC_ReadAxisError to provide further breakdown of the ErrorClass and AxisErrorID by providing BOOL and UINT outputs for the drive faults, and a DINT value for the controller alarm which is consistent with the 32 bit controller alarm reporting in the web server. This function was created for use inside the AxisControl function block in the PLCopen Toolbox. This function's outputs are available at the output of the AxisControl function block.

Parameters

* _	Parameter	Data Type	Description
VAR_IN_OUT			
B	Axis	AXIS_REF	Logical axis reference. This value can be located on the Configuration tab in the Hardware Configuration (logical axis number).
VAR_INPUT			Default
B	Enable	BOOL	The function will continue to execute while enable is held high. FALSE



VAR_OUTPUT			
B	Valid	BOOL	Indicates that the outputs of the function are valid.
V	DriveWarning	BOOL	Indicates a warning on the drive, such as any A.9x display on the drive.
V	DriveAlarm	BOOL	Indicates an alarm on the drive, such as A.71, overload. Refer to the appropriate drive manual for troubleshooting.
V	ControllerAlarm	BOOL	Indicates a controller side axis alarm.
V	DriveWarningID	UINT	Indicates the drive warning number, such as 95 (overload warning). Refer to the drive manual for troubleshooting.
V	DriveAlarmID	UINT	Indicates the drive alarm number, such as C9 (encoder disconnected). Refer to the drive manual for troubleshooting.
V	ControllerAlarmID	UDINT	Indicates the controller alarm ID number, such as 3302 0018. (shown in hex.) Refer to the Controller AlarmID list in the PLCopenPlus manual for troubleshooting.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
E	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Notes


We recommend viewing the alarm and warning output ID's in Hex, because all Yaskawa ServoPack documentation lists the amplifier alarm codes in Hex. This simplifies alarm identification. Use the Debug Dialog menu in MotionWorks IEC to change the debug value display type. The controller alarm list in the webserver and in the PLCopenPlus help manual show the controller alarms in hex also.

Error Description

ErrorID	Meaning
0	No error
4378	The function block is not applicable for the external axis specified
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.



ControllerAlarm



This function block provides a BOOL output to indicate if there is a controller alarm not related to an axis. It uses the Y_ReadAlarm function block and determines if the AlarmID output is non-zero. This function is useful because the PLCopenPlus function Y_ReadAlarm does not have a Boolean output, just the AlarmID.

Parameters

* _	Parameter	Data Type	Description	Default
VAR_INPUT				Default
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
V	Alarm	BOOL	Indicates if the controller has a non-axis related alarm.	
V	AlarmID	UDINT	This output provides the Controller Alarm ID. This output is reset when execute goes low.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
E	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	

Notes

It is best to view the AlarmID Hex, because the Controller AlarmID list in the PLCopen manual displays all alarm codes in hex. This simplifies alarm identification.



Error Description

ErrorID	Meaning
0	No error
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.



Feed_To_Length



FeedToLength was designed for use with applications that index forward in one direction, and require on the fly adjustments of the actual index length based on a sensor input that occurs while the axis is moving. This block is a hybrid function block, meaning it use both types of PLCopen behaviors: Enable and Execute. The reason for this is so the function can monitor for consecutive latches and flag an Error for that condition. The Enable input allows this feature to operate. The Execute input initiates each move.

Parameters

*_	Parameter	Data Type	Description
VAR_IN_OUT			
B	Axis	AXIS_REF	Logical axis reference. This value can be located on the Configuration tab in the Hardware Configuration (logical axis number).
V	TriggerData	TRIGGER_REF	Reference to the trigger signal source



VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
V	DefaultDistance	LREAL	The default product length. This is the distance the axis will travel if a registration mark is not detected.	LREAL#0.0
V	DistanceAfterLatch	LREAL	The desired additional travel distance after the registration mark is detected	LREAL#0.0
B	Velocity	LREAL	Absolute value of the velocity in user units/second	LREAL#0.0
B	Acceleration	LREAL	Value of the acceleration in user units/second ² (acceleration is applicable with same sign of torque and velocity)	LREAL#0.0
B	Deceleration	LREAL	Value of the deceleration in user units/second ² (deceleration is applicable with opposite signs of torque and velocity)	LREAL#0.0
E	Jerk	LREAL	<i>Not supported; reserved for future use. Value of the jerk in [user units / second³].</i>	
V	MaxCorrection	LREAL	Limits the amount of correction that can be applied	LREAL#0.0
V	SensorMinimum	LREAL	The earliest slave position where a sensor position is valid for correction.	LREAL#0.0
V	SensorMaximum	LREAL	The latest slave position where a sensor position is valid for correction.	LREAL#0.0
V	MissedLatchLimit	UINT	The number of consecutive product lengths that can occur without seeing a mark in the window. Valid sensor detections will reset the internal counter. The next valid sensor detection will reset the internal counter.	UINT#0
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is	



			true.
B	CommandAborted	BOOL	Set high if motion is aborted by another motion command or MC_Stop. This output is cleared with the same behavior as the Done output.
V	ActualSize	LREAL	The actual indexed distance
V	LatchPosition	LREAL	The slave's position in the CamTable when the latch occurred
V	LimitedCorrection	BOOL	Indicates that the MaxCorrection is limiting the required correction.
V	MissedLatch	BOOL	Cumulative number of latches missed
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Error Description


ErrorID	Meaning
0	No error
4369	The move could not be buffered because the axis motion queue is full. 16 moves is the maximum which can be buffered.
4370	The move could not be started because motion is prohibited. The drive may not be enabled. MC_Power.Enable_Positive or MC_Power.Enable_Negative might be low. Check MC_Power.Status output. MC_Stop.Execute might be held high, preventing motion. If MC_Stop has control of the axis, no other function block can override the "Stopping" state. Other blocks that try to cause motion while MC_Stop has control of the axis will generate this error. Also verify that the limit switches are not active by checking the Global Variables for the axis. Also, a motion block may be attempting to abort an MC_TorqueControl move.
4378	The function block is not applicable for the external axis specified
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4391	The function block can not be used with a virtual axis.
4396	Axis latch function already in use.
4402	The scan compensation delay parameter 1305 is only valid for external encoders.
4403	The High Speed Output functionality is only available on external encoders.
4406	Continuous Latch Mode not supported on external encoders or non-Sigma V servopacks.
4624	
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4630	Trigger or pattern reference is not valid



4641	Buffer mode does not correspond to a valid enumeration value.
4642	Direction does not correspond to a valid enumeration value.
4648	The parameter number does not exist for the specified axis
4658	Velocity parameter is less than or equal to zero.
4659	Acceleration is less than or equal to zero.
4660	Deceleration is less than or equal to zero.
4667	Jerk is less than or equal to zero.
4676	The time value must be within 0 to 10 MECHATROLINK cycles.
4893	The specified external axis may not be used. A physical axis is required.
4894	The specified virtual axis may not be used with this function block.
10020	ProductSize cannot be less than or equal to zero
10021	Maximum allowed consecutive missed registration marks reached
10025	Might be crossed or the same non-zero value
10053	DataPoint Error
57617	Instance object is NULL.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type. The size of the variable connected to these parameters is not checked during compilation but validated at run time. Typically errors occur when a variable of type AXIS_REF is not connected to an Axis VAR_IN_OUT, or a variable of type Y_Engage_Data is not connected to the Y_CamIn function block.


Example

Consider a case where the default distance between successive products is 6.2832 units. Let the distance between the sensor (wired to the high speed registration input) and the target position where the product will be processed be 3.1416 units. DistanceAfterLatch = 3.1416.




MaxCorrection limits the correction if an erroneous registration mark is captured and the calculation results in a large correction distance.


Sensor Minimum and Sensor Maximum provide window in which a registration mark must be seen to be considered a valid registration mark. In this example, the mark is expected around 3.1416 units, therefore a valid window is 2 .0 to 4.5 units. Set the window as small as appropriate for the application.



The FeedToLength function block will position the axis exactly 3.1416 units (DistanceAfterLatch) after the registration mark was detected.




The FeedToLength function block will position the axis exactly 3.1416 units (DistanceAfterLatch) after the registration mark is detected for varying product lengths.



4



HighSpeedOutput



This function block combines several of the parameters for use with the High Speed Output function available on the LIO-01, LIO-02, LIO-06, and MP2600iec. It allows changing the "OnPosition" value on the fly. While the "OnPosition" will be triggered at the hardware level with a response time of 13us, the output will be turned off when either the MinDistance has been travelled or the MinTime has elapsed, which will be based on the application scan in which this function is operating.

Parameters

*_	Parameter	Data Type	Description	
VAR_IN_OUT				
B	Axis	AXIS_REF	Logical axis reference. This value can be located on the Configuration tab in the Hardware Configuration (logical axis number).	
VAR_INPUT			Default	
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
V	OnPosition	LREAL	Position at which output must turn on	LREAL#0.0
V	MinDistance	LREAL	Minimum distance that must occur before the output turns off.	LREAL#0.0
V	MinTime	TIME	Minimum time that must elapse before the output must turn off.	T#0s
VAR_OUTPUT				



B	Valid	BOOL	Indicates that the outputs of the function are valid.
V	Status	BOOL	Indicates the status of the hardware
V	OutputCount	UDINT	Indicates the number of times the output turned on.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Notes

High Speed Output Quick Reference



Device	Output Number	Pin Number	Software Default Name
LIO-01	DO-01	A14	M□□_DO_01
LIO-02	DO-01	A14	M□□_DO_01
LIO-06	DO-07	49	M□□_DO_07
MP2600	DO-07	44, 49	MO1_DO_01

- See the [HighSpeedOutput eLearning Module](#) on Yaskawa's YouTube channel.

Error Description


ErrorID	Meaning
0	No error
4401	Axis latch function already in use.
4402	The scan compensation delay parameter 1305 is only valid for external encoders.
4403	The High Speed Output functionality is only available on external encoders.
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.

Timing Diagram





Home_Init



This function block provides a method to initialize the HomeStruct data for use with all HOME_** function blocks. It is useful for programmers who prefer to avoid structured text for initializing HomeStruct values.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
B	HomeData	HomeStruct	Logical axis reference. This value can be located on the Configuration tab in the Hardware Configuration (logical axis number).	
VAR_INPUT				Default
B	Enable	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify	FALSE



			an input, change the value and re-trigger the execute input.	
B	Direction	MC_Direction	Direction of travel for homing	
B	SwitchMode	MC_SwitchMode	Edge On is the only mode supported	
B	TorqueLimit	LREAL	Torque limit while attempting homing. In percentage of rated torque of the servo	
B	ApproachVelocity	LREAL	Velocity used to approach limit switch or c channel	
B	ApproachTimeLimit	LREAL	Time limit for the homing attempt. In seconds	
B	ApproachDistanceLimit	LREAL	Distance limit for the homing attempt	
B	AccDec	LREAL	Acceleration/deceleration for offset moves.	
B	LimitBackOffDistance	LREAL	Distance limit for back off after a limit switch is encountered	
B	CreepVelocity	LREAL	Velocity to creep to C channel	
B	CreepTimeLimit	LREAL	Time limit for the creep attempt. In seconds	
B	CreepDistanceLimit	LREAL	Distance limit for the creep attempt	
B	Offset	LREAL	Offset distance to move after limit switch or C channel	
B	OffsetVelocity	LREAL	Velocity of the offset move after limit switch or C channel	
B	Position	HomeStruct	Position to be defined as the home position	All zeros in structure
VAR_OUTPUT				
B	Valid	BOOL	Set high if the function block is active and there are no errors	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
E	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	

Error Description

No Errors will be generated.



Home_LS



This function block combines the PLCopen function blocks MC_StepLimitSwitch, MC_MoveRelative, and MC_SetPosition to make a sequence that detects the limit switch, performs an offset move away from the limit, and sets a home position.

Parameters

*_	Parameter	Data Type	Description
VAR_IN_OUT			
B	Axis	AXIS_REF	Logical axis reference. This value can be located on the Configuration tab in the Hardware Configuration (logical axis number).
VAR_INPUT			
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.
B	HomeData	HomeStruct	User defined Data Type in the PLCopen Toolbox, contains all related homing parameters.
VAR_OUTPUT			
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the



			action is completed, the Done output will not be set. This output is reset when execute goes low.
B	CommandAborted	BOOL	Set high if motion is aborted by another motion command or MC_Stop. This output is cleared with the same behavior as the Done output.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
E	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Error Description

ErrorID	Meaning
0	No error
1	Time limit exceeded
2	Distance limit exceeded
3	Torque limit exceeded
4369	The move could not be buffered because the axis motion queue is full. 16 moves is the maximum which can be buffered.
4370	The move could not be started because motion is prohibited. The drive may not be enabled. MC_Power.Enable_Positive or MC_Power.Enable_Negative might be low. Check MC_Power.Status output. MC_Stop.Execute might be held high, preventing motion.
4378	The function block is not applicable for the external axis specified
4379	A homing sequence is already in progress.
4380	MC_SetPosition can not be executed while the axis is moving.
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4382	When the axis is in rotary mode, and the MC_SetPosition tries to set a position that is equal to or greater than the MachineCycle, this error is generated, and the position is not set.
4383	Axis must be commanded at standstill when homing is attempted.
4390	Position cannot be defined while the axis is the cam master of other axes.
4396	Axis latch function already in use.
4397	Over travel limit still ON after attempting to move away from it.
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4641	Buffer mode does not correspond to a valid enumeration value.
4642	Direction does not correspond to a valid enumeration value.
4646	Mode does not correspond to a valid enumeration value.
4658	Velocity parameter is less than or equal to zero.
4659	Acceleration is less than or equal to zero.
4660	Deceleration is less than or equal to zero.



4667	Jerk is less than or equal to zero.
4893	The specified external axis may not be used. A physical axis is required.
10037	Offset cannot be in the same direction as the original motion into the limit switch.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.
61713	An internal assertion in the motion kernel failed indicating the controller is not in a stable state. Please report this error to Yaskawa America Incorporated.

Example

Use a ST POU to initialize the data required for HomeData. To save time, copy & paste the example initialization into your project.

(** Copy & Paste, then search & replace the headings in the following section to speed the initialization of the homing data. **)

HomeStruct_ReplaceMe.AccDec:=LREAL#500.0; (* In User units /sec² as set in the Hardware Configuration *)

HomeStruct_ReplaceMe.ApproachDistanceLimit:=LREAL#500.0; (* In User units as set in the Hardware Configuration *)

HomeStruct_ReplaceMe.ApproachTimeLimit:=LREAL#500.0; (* In seconds *)

HomeStruct_ReplaceMe.ApproachVelocity:=LREAL#500.0; (* In User units / sec as set in the Hardware Configuration *)

HomeStruct_ReplaceMe.CreepDistanceLimit:=LREAL#500.0; (* In User units as set in the Hardware Configuration *)

HomeStruct_ReplaceMe.CreepTimeLimit:=LREAL#500.0; (* In seconds *)

HomeStruct_ReplaceMe.CreepVelocity:=LREAL#500.0; (* In User units / sec as set in the Hardware Configuration *)

HomeStruct_ReplaceMe.Direction:=INT#0; (* MC_Direction#Positive_Direction; *)

HomeStruct_ReplaceMe.Offset:=LREAL#500.0; (* In User units as set in the Hardware Configuration *)

HomeStruct_ReplaceMe.OffsetVelocity:=LREAL#500.0; (* In User units / sec as set in the Hardware Configuration *)


HomeStruct_ReplaceMe.Position:=LREAL#500.0; (* In User units as set in the Hardware Configuration *)

HomeStruct_ReplaceMe.SwitchMode:=INT#2; (* MC_SwitchMode#EdgeOn; *)

HomeStruct_ReplaceMe.TorqueLimit:=LREAL#500.0; (* In percentage of rated torque of the servo *)



Home_LS_Pulse



This function block combines the PLCopen function blocks MC_StepLimitSwitch, MC_StepRefPulse, MC_MoveRelative, and MC_SetPosition to make a sequence that detects the limit switch, reverses to the C channel, performs an offset move away from the limit, and sets a home position.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
B	Axis	AXIS_REF	Logical axis reference. This value can be located on the Configuration tab in the Hardware Configuration (logical axis number).	
VAR_INPUT			Default	
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
B	HomeData	HomeStruct	User defined Data Type in the PLCopen Toolbox, contains all related homing parameters.	All zeros in structure
VAR_OUTPUT				
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable'	



			input, and reset if Done, CommandAborted, or Error is true.
B	CommandAborted	BOOL	Set high if motion is aborted by another motion command or MC_Stop. This output is cleared with the same behavior as the Done output.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
E	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Notes

See the [Home_LS_Pulse eLearning Module](#) on Yaskawa's YouTube channel.

Error Description

ErrorID	Meaning
0	No error
1	Time limit exceeded
2	Distance limit exceeded
3	Torque limit exceeded
4369	The move could not be buffered because the axis motion queue is full. 16 moves is the maximum which can be buffered.
4370	The move could not be started because motion is prohibited. The drive may not be enabled. MC_Power.Enable_Positive or MC_Power.Enable_Negative might be low. Check MC_Power.Status output. MC_Stop.Execute might be held high, preventing motion.
4378	The function block is not applicable for the external axis specified
4379	A homing sequence is already in progress.
4380	MC_SetPosition can not be executed while the axis is moving.
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4382	When the axis is in rotary mode, and the MC_SetPosition tries to set a position that is equal to or greater than the MachineCycle, this error is generated, and the position is not set.
4383	Axis must be commanded at standstill when homing is attempted.
4390	Position cannot be defined while the axis is the cam master of other axes.
4396	Axis latch function already in use.
4397	Over travel limit still ON after attempting to move away from it.
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4641	Buffer mode does not correspond to a valid enumeration value.




4642	Direction does not correspond to a valid enumeration value.
4646	Mode does not correspond to a valid enumeration value.
4658	Velocity parameter is less than or equal to zero.
4659	Acceleration is less than or equal to zero.
4660	Deceleration is less than or equal to zero.
4667	Jerk is less than or equal to zero.
4893	The specified external axis may not be used. A physical axis is required.
10037	Offset cannot be in the same direction as the original motion into the limit switch.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.
61713	An internal assertion in the motion kernel failed indicating the controller is not in a stable state. Please report this error to Yaskawa America Incorporated.

Example

i



Home_Pulse



This function block combines the PLCopen function blocks MC_StepRefPulse, MC_MoveRelative, and MC_SetPosition to make a sequence that detects the limit switch, reverses to the C channel, performs an offset move away from the limit, and sets a home position.

Parameters

*_	Parameter	Data Type	Description	
VAR_IN_OUT				
B	Axis	AXIS_REF	Logical axis reference. This value can be located on the Configuration tab in the Hardware Configuration (logical axis number).	
VAR_INPUT			Default	
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
B	HomeData	HomeStruct	User defined Data Type in the PLCopen Toolbox, contains all related homing parameters.	All zeros in structure
VAR_OUTPUT				
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.	
B	Done	BOOL	Set high when the commanded action has been completed	



			successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.
B	CommandAborted	BOOL	Set high if motion is aborted by another motion command or MC_Stop. This output is cleared with the same behavior as the Done output.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
E	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Error Description

ErrorID	Meaning
0	No error
1	Time limit exceeded
2	Distance limit exceeded
3	Torque limit exceeded
4369	The move could not be buffered because the axis motion queue is full. 16 moves is the maximum which can be buffered.
4370	The move could not be started because motion is prohibited. The drive may not be enabled. MC_Power.Enable_Positive or MC_Power.Enable_Negative might be low. Check MC_Power.Status output. MC_Stop.Execute might be held high, preventing motion.
4378	The function block is not applicable for the external axis specified
4379	A homing sequence is already in progress.
4380	MC_SetPosition can not be executed while the axis is moving.
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4382	When the axis is in rotary mode, and the MC_SetPosition tries to set a position that is equal to or greater than the MachineCycle, this error is generated, and the position is not set.
4383	Axis must be commanded at standstill when homing is attempted.
4390	Position cannot be defined while the axis is the cam master of other axes.
4396	Axis latch function already in use.
4397	Over travel limit still ON after attempting to move away from it.
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4641	Buffer mode does not correspond to a valid enumeration value.
4642	Direction does not correspond to a valid enumeration value.
4646	Mode does not correspond to a valid enumeration value.
4658	Velocity parameter is less than or equal to zero.
4659	Acceleration is less than or equal to zero.




4660	Deceleration is less than or equal to zero.
4667	Jerk is less than or equal to zero.
4893	The specified external axis may not be used. A physical axis is required.
10037	Offset cannot be in the same direction as the original motion into the limit switch.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.
61713	An internal assertion in the motion kernel failed indicating the controller is not in a stable state. Please report this error to Yaskawa America Incorporated.

Example



Jog



This function block combines the PLCopen functions MC_MoveVelocity and MC_Stop to provide a jogging feature only while the Forward or Reverse inputs are TRUE. The function will default to stopping the axis when neither (or both).

Parameters

*_	Parameter	Data Type	Description	
VAR_IN_OUT				
B	Axis	AXIS_REF	Logical axis reference. This value can be located on the Configuration tab in the Hardware Configuration (logical axis number).	
VAR_INPUT				
V	Forward	BOOL	Runs the axis in a forward direction when TRUE.	FALSE
V	Reverse	BOOL	Runs the axis in a Reverse direction when TRUE.	FALSE
B	Velocity	LREAL	Absolute value of the velocity in user units/second	LREAL#0.0
B	Acceleration	LREAL	Value of the acceleration in user units/second ² (acceleration is applicable with same sign of torque and velocity)	LREAL#0.0
B	Deceleration	LREAL	Value of the deceleration in user units/second ² (deceleration is applicable with opposite signs of	LREAL#0.0



			torque and velocity)	
B	Jerk	LREAL	<i>Not supported; reserved for future use. Use S-Curve parameters 1300 and 1301. Value of the jerk in [user units / second^3].</i>	LREAL#0.0
VAR_OUTPUT				
B	InVelocity	BOOL	Set high when the axis first reaches the specified velocity (function is complete). This output is reset when execute goes low.	
B	Done	BOOL	Turns on for one scan when the axis comes to a stop after both Forward and Reverse inputs go FALSE.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	

Notes

- The velocity can be changed on the fly without toggling the Forward or Reverse input. The code inside this function block will detect if the velocity has changed, and automatically re trigger the MC_MoveVelocity function block inside. Starting in PLCopen Toolbox v202, changes in Acceleration and Deceleration are detected and can be changed on the fly.
- See the [Jog eLearning Module](#) on Yaskawa's YouTube channel.

Error Description

ErrorID	Meaning
0	No error
4369	The move could not be buffered because the axis motion queue is full. 16 moves is the maximum which can be buffered.
4370	The move could not be started because motion is prohibited. The drive may not be enabled. MC_Power.Enable_Positive or MC_Power.Enable_Negative might be low. Check MC_Power.Status output. MC_Stop.Execute might be held high, preventing motion.
4378	The function block is not applicable for the external axis specified
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4641	Buffer mode does not correspond to a valid enumeration value.




PLCopen Toolbox: Function Blocks



4642	Direction does not correspond to a valid enumeration value.
4659	Acceleration is less than or equal to zero.
4660	Deceleration is less than or equal to zero.
4665	Velocity parameter is negative.
4667	Jerk is less than or equal to zero.
4893	The specified external axis may not be used. A physical axis is required.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.



Jog_To_Position



This function block combines the PLCopen functions MC_MoveVelocity and MC_MoveAbsolute to provide a jogging feature specifically for rotary axes that must stop at a specific position after an indefinite period of motion.

Parameters

* _	Parameter	Data Type	Description	
VAR_IN_OUT				
B	Axis	AXIS_REF	Logical axis reference. This value can be located on the Configuration tab in the Hardware Configuration (logical axis number).	
VAR_INPUT				Default
V	Forward	BOOL	Runs the axis in a forward direction when TRUE.	FALSE
V	Reverse	BOOL	Runs the axis in a Reverse direction when TRUE.	FALSE
B	Velocity	LREAL	Absolute value of the velocity in user units/second	LREAL#0.0
B	Acceleration	LREAL	Value of the acceleration in user units/second ² (acceleration is applicable	LREAL#0.0



			with same sign of torque and velocity)	
B	Deceleration	LREAL	Value of the deceleration in user units/second ² (deceleration is applicable with opposite signs of torque and velocity)	LREAL#0.0
E	Jerk	LREAL	<i>Not supported; reserved for future use. Use S-Curve parameters 1300 and 1301. Value of the jerk in [user units / second³].</i>	LREAL#0.0
V	StopPosition	LREAL	Once the Forward and Reverse inputs are false, the axis will decelerate to a stop at the specified StopPosition using the specified deceleration rate	LREAL#0.0
VAR_OUTPUT				
B	InVelocity	BOOL	Set high when the axis first reaches the specified velocity (function is complete). This output is reset when execute goes low.	
B	Done	BOOL	Turns on for one scan when the axis comes to a stop after both Forward and Reverse inputs go FALSE.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.	
B	CommandAborted	BOOL	Set high if motion is aborted by another motion command or MC_Stop. This output is cleared with the same behavior as the Done output.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
E	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	

Notes

The velocity, acceleration, and deceleration can be changed on the fly without toggling the Forward or Reverse input. The code inside this function block will detect if the input values have changed, and automatically re-trigger the MC_MoveVelocity function block inside. Starting in PLCopen Toolbox v202, changes in Acceleration and Deceleration are detected and can be changed on the fly.

Error Description


ErrorID	Meaning
0	No error
4369	The move could not be buffered because the axis motion queue is full. 16 moves is the maximum which can be buffered.
4370	The move could not be started because motion is prohibited. The drive may not be enabled. MC_Power.Enable_Positive or MC_Power.Enable_Negative might be low. Check



	MC_Power.Status output. MC_Stop.Execute might be held high, preventing motion.
4378	The function block is not applicable for the external axis specified
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4641	Buffer mode does not correspond to a valid enumeration value.
4642	Direction does not correspond to a valid enumeration value.
4659	Acceleration is less than or equal to zero.
4660	Deceleration is less than or equal to zero.
4665	Velocity parameter is negative.
4667	Jerk is less than or equal to zero.
4893	The specified external axis may not be used. A physical axis is required.
10060	The axis must be configured as a rotary type for this function block to be applicable.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.



Example 1

In the first example the speed is low enough and the deceleration high enough that the axis can stop within one revolution. This is the easiest condition.




Example 2

In this example, the axis requires about 13 revolutions to come to a stop at the specified velocity and deceleration. The data "SlowNow" in green is an internal monitoring bit which results from a calculation made to determine a position that will allow the motion profile to follow the deceleration rate to the specified StopPosition. Notice there is a very brief delay between the time the Forward jog request is removed and the axis starts decelerating. This allow the axis to decelerate smoothly to the StopPosition. The pink data indicates when the MC_MoveAbsolute is active.




Example 3

The third example shows a deceleration to stop at 52 degrees.





MoveRelative_ByTime



This function block converts the MoveTime input into acceleration, velocity, and deceleration for a 1/3, 1/3, 1/3 trapezoidal move profile which will complete in the MoveTime specified. It uses the MC_MoveRelative function block.

Parameters

* _	Parameter	Data Type	Description
VAR_IN_OUT			
B	Axis	AXIS_REF	Logical axis reference. This value can be located on the Configuration tab in the Hardware Configuration (logical axis number).
VAR_INPUT			
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.
V	Distance	LREAL	A relative positive or negative value within the coordinate system in user units
V	MoveTime	LREAL	The time required (in seconds) for the move to complete.
VAR_OUTPUT			
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action



			is completed, the Done output will not be set. This output is reset when execute goes low.
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.
B	Active	BOOL	For buffered modes, this output is set high at the moment the block takes control of the axis. For non buffered modes, the outputs Busy and Active have the same value.
B	CommandAborted	BOOL	Set high if motion is aborted by another motion command or MC_Stop. This output is cleared with the same behavior as the Done output.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
E	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Notes

- Because this function creates a 1/3, 1/3, 1/3 trapezoidal move, it may not be appropriate for very long moves, because the calculated commanded speed may be too high.
- See the [MoveRelative_ByTime eLearning Module](#) on Yaskawa's YouTube channel.

Error Description


ErrorID	Meaning
0	No error
4369	The move could not be buffered because the axis motion queue is full. 16 moves is the maximum which can be buffered.
4370	The move could not be started because motion is prohibited. The drive may not be enabled. MC_Power.Enable_Positive or MC_Power.Enable_Negative might be low. Check MC_Power.Status output. MC_Stop.Execute might be held high, preventing motion.
4378	The function block is not applicable for the external axis specified
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4641	Buffer mode does not correspond to a valid enumeration value.
4642	Direction does not correspond to a valid enumeration value.
4659	Acceleration is less than or equal to zero.
4660	Deceleration is less than or equal to zero.



4665	Velocity parameter is negative.
4667	Jerk is less than or equal to zero.
4893	The specified external axis may not be used. A physical axis is required.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.



PositionLimits



This function block enables or disables the position limit function. It also allows continuous streaming of new position limits. This block uses MC_WriteBoolParameter, MC_ReadBoolParameter, MC_WriteParameter, and MC_ReadParameter.

Parameters


*_	Parameter	Data Type	Description	
VAR_IN_OUT				
B	Axis	AXIS_REF	Logical axis reference. This value can be located on the Configuration tab in the Hardware Configuration (logical axis number).	
VAR_INPUT				
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
V	LimitPositionEnable	BOOL	Enables / Disables the position limit function in the motion engine.	FALSE
V	LimitPositionPositive	LREAL	The maximum commanded position allowed	LREAL#0.0
V	LimitPositionNegative	LREAL	The minimum commanded position allowed	LREAL#0.0



VAR_OUTPUT			
B	Valid	BOOL	Indicates that the outputs of the function are valid.
V	LimitPositionEnableEcho	BOOL	Status of the Position Limit function from the motion engine.
V	LimitPositionPositiveEcho	LREAL	Value used by the motion engine for the maximum allowed commanded position.
V	LimitPositionNegativeEcho	LREAL	Value used by the motion engine for the minimum allowed commanded position.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Notes

The function block uses MC_ReadBoolParameter, MC_WriteBoolParameter, MC_ReadParameter, and MC_WriteParameter.



- The software position limits are managed by the MP2000iec controller. The parameters are called LimitPositionPositive and LimitPositionNegative, with values of UINT#1201 and UINT#1200 respectively. Use the MC_WriteParameter function block for these and all controller side parameters. Position limit parameters are in user units.
- When a position limit is exceeded, a controller alarm will be generated, obtainable via the MC_ReadAxisError function block, or the web server.
- The controller alarm will be 16#3202 0001 if the positive position limit is exceeded and 16#3202 0002 if the negative position limit is exceeded.
- To disable the position limits, set LimitPositionEnable, parameter 1202 to zero.
- LimitPositionPositive must be greater than LimitPositionNegative.
- LimitPositionNegative must be lower than LimitPositionPositive.
- See the [PositionLimits eLearning Module](#) on Yaskawa's YouTube channel.

Error Description


ErrorID	Meaning
---------	---------



0	No error
4378	The function block is not applicable for the external axis specified
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4648	The parameter number does not exist for the specified axis
10026	Positive Position Limit must be greater than Negative Position Limit
10027	Negative Position Limit must be less than Positive Position Limit.
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.



ProductBuffer



This function block uses MC_TouchProbe and provides a circular buffer of recorded latch positions for the axis specified. It is tailored for use especially for axes that transfer incoming products to a process. The accompanying "RegistrationData" structure contains information pertaining to the circular buffer and other machine dimensions related to such operations.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
V	ProductAxis	AXIS_REF	Logical axis reference. This value can be located on the Configuration tab in the Hardware Configuration (logical axis number).	
V	RegistrationData	ProductBufferStruct	Structure containing all information for the circular buffer to operate.	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
V	TestMode	BOOL	If TRUE, then the internal MC_TouchProbe is aborted, and the function block can be used to "dry	FALSE



			cycle" the machine by simulating products using the TestTrigger input.	
V	TestTrigger	BOOL	If TestMode is TRUE, then on the rising edge of TestTrigger, the actual position of the ProductAxis will be stored into the RegistrationData STRUCT.	FALSE
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
V	BufferLevel	BOOL	Indicates the number of products in the buffer by subtracting UsePointer from StorePointer.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	

Notes

- The ProductBuffer function block manages only the "storing" activity and only updates the StorePointer. Another part of your application must update the UsePointer and PrevUsePointer as the products leave the machine. If these pointers are not updated, the function block will Error with code 10022, buffer overrun.
- The StorePointer and UsePointer are the "Head" and the "Tail" of the circular buffer. If more than one "Use" of the latch data is required, they can be inserted into the chain outside of the ProductBufferStruct.
- Both a cyclic (modularized) and unmodularized circular latch buffer are stored simultaneously.
- TestMode can be switched on the fly without re enabling the function block. TestMode was added in v201.
- See the [ProductBuffer eLearning Module](#) on Yaskawa's YouTube channel.

Error Description

ErrorID	Meaning
0	No error
4396	Axis latch function already in use.
4624	Axis latch function already in use.
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4630	Trigger reference is not valid
4894	The specified virtual axis may not be used with this function block.



10022	Product or circular buffer overrun / full
10023	Buffer size too small / cannot be zero
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.

Example

Initialization of the ProductBufferStruct in an initialize program:

```
Conveyor.Products.BufferSize:=INT#20;
```

```
Conveyor.Products.LockoutDistance:=LREAL#3.25; (* inches *)
```


```
Conveyor.Products.ManualOffset:=LREAL#0.0;
```

```
Conveyor.Products.ProductAwayDistance:=LREAL#23.75;
```

```
Conveyor.Products.Sensor.Bit:=UINT#1; (* Equates to input1 on 2600 I/O, see MC_TouchProbe help for details *)
```

```
Conveyor.Products.SensorDistance:=LREAL#23.25; (* If product leads slave, increase this value *)
```

```
Conveyor.Products.SensorOffset:=REM(Conveyor.Products.SensorDistance,  
Conveyor.MachineCycle);
```







Variable	Value	Default value	Type
[-] Conveyor			ConveyorStruct
[-] Ref			AXIS_REF
[-] Ptm			AxisParameterStruct
[-] Products			ProductBufferStruct
[-] BufferSize	20		INT
[-] BufferNonCyclic			LatchBufferArray
[-] BufferCyclic			LatchBufferArray
[-] Sensor			TRIGGER_REF
[-] Input			INPUT_REF
[-] Bit	1		UINT
[-] Pattern	0		INT
[-] ID	0		UINT
[-] SensorDistance	2.3250000E+001		LREAL
[-] SensorOffset	1.2588514E+000		LREAL
[-] ManualOffset	0.0000000E+000		LREAL
[-] FilterDistance	3.2500000E+000		LREAL
[-] ProductAwayDistance	2.3750000E+001		LREAL
[-] StorePointer	19		INT
[-] UsePointer	16		INT
[-] PrevUsePointer	15		INT

Variable	Value	Default value	Type
[-] BufferNonCyclic			LatchBufferArray
[-] [0]	7.0217149E+005		LREAL
[-] [1]	7.0217666E+005		LREAL
[-] [2]	7.0203970E+005		LREAL
[-] [3]	7.0204402E+005		LREAL
[-] [4]	7.0205855E+005		LREAL
[-] [5]	7.0206436E+005		LREAL
[-] [6]	7.0207238E+005		LREAL
[-] [7]	7.0207649E+005		LREAL
[-] [8]	7.0208167E+005		LREAL
[-] [9]	7.0209183E+005		LREAL
[-] [10]	7.0209664E+005		LREAL
[-] [11]	7.0210632E+005		LREAL
[-] [12]	7.0211436E+005		LREAL
[-] [13]	7.0211861E+005		LREAL
[-] [14]	7.0212569E+005		LREAL
[-] [15]	7.0212982E+005		LREAL
[-] [16]	7.0213470E+005		LREAL
[-] [17]	7.0215034E+005		LREAL
[-] [18]	7.0216219E+005		LREAL
[-] [19]	7.0216738E+005		LREAL
[-] [20]	0.0000000E+000		LREAL



ProductBuffer Operation


(Assume a 10" Machine Cycle)





ProductBufferStruct Definitions


(Assume a rotary knife application)



o



ReadAxisParameters



This function block reads all the commonly updated axis parameters that may be used within an application and copies them to an AxisParameterStruct. Firmware library Y_Motion should be inserted in the project that uses ReadAxisParameters.

Parameters

*	Parameter	Data Type	Description	
VAR_IN_OUT				
B	Axis	AXIS_REF	Logical axis reference. This value can be located on the Configuration tab in the Hardware Configuration (logical axis number).	
V	AxisParams	AxisParameterStruct	User Defined DataType declared in the PLCopen Toolbox.	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
V	AxisType	TB_AxisType	Indicates axis type: TB_AxisType#Servo TB_AxisType#VFD TB_AxisType#Stepper TB_AxisType#Virtual TB_AxisType#External	INT#0 (TB_AxisType#Servo)
V	ParamTypes	WORD	Used to include additional	WORD#0





			parameter sets, such as camming.
VAR_OUTPUT			
B	Valid	BOOL	Indicates that the outputs of the function are valid.
V	ErrorPrm	UINT	If there was an error while attempting to read one of the parameters listed in the ParamStruct, this output will contain the offending parameter number.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Notes

Only AxisType#Servo, AxisType#External, AxisType#Virtual are supported.

By default, the function will update all parameter types in the AxisParamStruct. For efficiency, parameters are grouped into types. Basic, Status, and Cam. For axes that are not cam slaves, there is no need to read the cam parameters. To cause the function to skip the update of a parameter group, set the corresponding bit high. For example, the following function block will not read the cam parameters:





Parameters categorized as BasicMotion are always read.

ParamType	ParameterName	Parameter #
BasicMotion	ActualPosition	1000
BasicMotion	ActualPositionCyclic	1005
BasicMotion	ActualPositionNonCyclic	1006
BasicMotion	ActualTorque	1004
BasicMotion	ActualVelocity	1001
BasicMotion	AtVelocity	1141
BasicMotion	CommandedPosition	1010
BasicMotion	CommandedPositionCyclic	1015
BasicMotion	CommandedPositionNonCyclic	1016
BasicMotion	CommandedTorque	1014
BasicMotion	CommandedVelocity	1011
BasicMotion	InPosition	1140



BasicMotion	LatchPositionNonCyclic	1031
BasicMotion	PositionError	1130
Cam	CamMasterCycle	1512
Cam	CamMasterPosition	1500
Cam	CamMasterScale	1510
Cam	CamMasterShift	1511
Cam	CamMasterShiftedCyclic	1502
Cam	CamMasterShiftedPosition	1501
Cam	CamOffset	1531
Cam	CamScale	1530
Cam	CamShiftRemaining	1513
Cam	CamState	1540
Cam	CamTableIDEngaged	1541
Cam	CamTableOutput	1520
Status	BufferedMotionBlocks	1600
Status	CommandedAcceleration	1012
Status	PositionWindow	1120

- See the [ReadAxisParameters eLearning Module](#) on Yaskawa's YouTube channel.







Error Description

ErrorID	Meaning
0	No error
4378	The function block is not applicable for the external axis specified
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POUs.



4648	The parameter number does not exist for the specified axis
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.

Example






Variable	Value	Type	Instance
Machine.Master.Prm		AxisParameterStruct	Configuration.Resource.Task.Monitor.Machine.Master.Prm
ActualPosition	1467.48	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.ActualPosition
ActualPositionCyclic	1467.48	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.ActualPositionCyclic
ActualPositionNonCyclic	1467.48	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.ActualPositionNonCyclic
ActualTorque	0.00	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.ActualTorque
ActualVelocity	60.00	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.ActualVelocity
AtVelocity	FALSE	BOOL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.AtVelocity
BufferedMotionBlocks	1.00	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.BufferedMotionBlocks
CamMasterCycle	1.00	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.CamMasterCycle
CamMasterPosition	0.00	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.CamMasterPosition
CamMasterShiftedCyclic	0.00	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.CamMasterShiftedCyclic
CamMasterShiftedPosition	0.00	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.CamMasterShiftedPosition
CamMasterScale	100.00	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.CamMasterScale
CamMasterShift	0.00	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.CamMasterShift
CamOffset	0.00	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.CamOffset
CamScale	100.00	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.CamScale
CamShiftRemaining	0.00	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.CamShiftRemaining
CamState	0.00	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.CamState
CamTableDEngaged	0.00	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.CamTableDEngaged
CamTableOutput	0.00	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.CamTableOutput
CommandedAcceleration	0.00	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.CommandedAcceleration
CommandedPosition	1467.60	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.CommandedPosition
CommandedPositionCyclic	1467.60	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.CommandedPositionCyc...
CommandedPositionNonCyclic	1467.60	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.CommandedPositionNo...
CommandedTorque	0.00	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.CommandedTorque
CommandedVelocity	60.00	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.CommandedVelocity
InPosition	FALSE	BOOL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.InPosition
LatchPositionNonCyclic	0.00	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.LatchPositionNonCyclic
PositionError	0.00	LREAL	Configuration.Resource.Task.Monitor.Machine.Master.Prm.PositionError

Watch 1 Watch 2 Watch 3 Watch 4

r



Reverse_MC_Direction



This function block was designed for use with the Home_LS_Pulse function block in the PLCopen Toolbox. It changes the enumerated type MC_Direction#positive_direction to MC_Direction#negative_direction or vice versa so that the function can move the motor one direction into a limit switch with MC_StepRefLimit, and the other direction when searching for the Index Pulse with MC_StepRefPulse.

Parameters

*_	Parameter	Data Type	Description	
VAR_INPUT				Default
B	EN	BOOL	Enables the function.	FALSE
V	LimitDirection	INT	ENum	
V	BackOffDistance	LREAL		INT#0
VAR_OUTPUT				
B	ENO	BOOL	High if the function executed normally	
V	PulseDirection	INT	MC_Direction#positive_direction or MC_Direction#negative_direction	
V	BackOffDirection	LREAL		


Error Description

No Errors will result, but if there is a problem with the ENum input for MC_Direction, then ENO will be FALSE.

Example




PLCopen Toolbox: Function Blocks





VelocityLimits



This function block enables or disables the velocity limit function. It also allows continuous streaming of new velocity limits. This block uses MC_WriteBoolParameter, MC_ReadBoolParameter, MC_WriteParameter, and MC_ReadParameter.

Parameters


* _	Parameter	Data Type	Description	
VAR_IN_OUT				
B	Axis	AXIS_REF	Logical axis reference. This value can be located on the Configuration tab in the Hardware Configuration (logical axis number).	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
V	LimitVelocityEnable	BOOL	Enables / Disables the velocity limit function in the motion engine.	FALSE
V	LimitVelocityPositive	LREAL	The maximum commanded velocity allowed	LREAL#0.0
V	LimitVelocityNegative	LREAL	The minimum commanded velocity allowed	LREAL#0.0
VAR_OUTPUT				



B	Valid	BOOL	Indicates that the outputs of the function are valid.
V	LimitPositionEnableEcho	BOOL	Status of the Velocity Limit function from the motion engine.
V	LimitPositionPositiveEcho	LREAL	Value used by the motion engine for the maximum allowed commanded velocity.
V	LimitPositionNegativeEcho	LREAL	Value used by the motion engine for the minimum allowed commanded velocity.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Notes

The function block uses MC_ReadBoolParameter, MC_WriteBoolParameter, MC_ReadParameter, and MC_WriteParameter.





PLCopen Toolbox: Function Blocks




- The software velocity limits are managed by the MP2000iec controller. The parameters are called LimitVelocityPositive and LimitVelocityNegative, with values of UINT#1211 and UINT#1210 respectively. Use the MC_WriteParameter function block for these and all controller side parameters. Velocity limit parameters are in user units / sec.
- When a velocity limit is exceeded, a controller alarm will be generated, obtainable via the MC_ReadAxisError function block, or the web server.
- The controller alarm will be 16#3202 0003 if the positive velocity limit is exceeded and 16#3202 0004 if the negative velocity limit is exceeded.
- To disable the velocity limits, set LimitVelocityEnable, parameter 1212 to zero.
- LimitVelocityPositive must be zero or greater.
- LimitVelocityNegative must be zero or lower.

Error Description

ErrorID	Meaning
0	No error
10028	Positive Velocity Limit must be LREAL#0.0 or greater.
10029	Negative Velocity Limit must be LREAL#0.0 or lower.



Y_DigitalCamSwitch



This function block commands a group of discrete output bits analogous to a set of mechanical cam controlled switches driven by a rotating shaft. Forward and backward movements are allowed. A maximum of 32 outputs and 256 switches are supported.

Parameters

*	Parameter	Data Type	Description
VAR_IN_OUT			
B	Axis	AXIS_REF	Logical axis reference. This value can be located on the Configuration tab in the Hardware Configuration (logical axis number).
B	Switches	CAMSWITCH_REF	Reference to the switching actions. 256 maximum switches.
E	TrackOptions	TRACK_REF	Reference to the track related properties. 32 maximum tracks.
VAR_INPUT			Default
B	Enable	BOOL	The function will continue to execute while



			enable is held high.	
E	EnableMask	DWORD	Individually enables the tracks [0..31] per the bit pattern. Value of 1 means Enabled, 0 means disabled. Least significant bit corresponds to Track [0]. Default if not connected is All Tracks Enabled.	FALSE
VAR_OUTPUT				
B	InOperation	BOOL	Function Block Enable is ON and at least 1 track is enabled (EnableMask is <> 0).	
E	Busy	BOOL	Function Block Enable is ON but no tracks are enabled (EnableMask = 0).	
E	Warning	BOOL	Signals that a non-critical error has occurred within the function block. In this case, the block will continue to function.	
E	SWErrorCode	SWERROR_STRUCT	Switch Error Code Structure that identifies particular warnings with switch settings. The user can monitor this ErrorCode if Warning output comes on.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
E	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	
E	Output	DWORD	Resulting CamSwitch output for each track per the bit pattern. Least significant bit corresponds to Track [0]. This Output will need to be tied to physical outputs outside of the DigitalCamSwitch FB.	

Notes

- This functionality is sometimes called PLS – Phase or Position or Programmable Limit Switch.
- Switches will be evaluated for both forward and reverse travel of the axis.
- OnCompensation and OffCompensation will only be applied when the axis is moving in the Positive Direction.
- Track Hysteresis is not supported.

Restrictions

If the output specified in the PLS is also controlled somewhere else in the project then the last instruction wins. This would also be the case when a single output is used in two PLS blocks.

The PLS block will support a maximum of 256 switches and 32 outputs. This means that the block will react to a maximum of 512 positions (two for each switch).



If the cam-like lobes of multiple switches intersect with each other for a single track the net effect would be an OR-ing of the switches.

Example1 SW1: on at 10, off at 50, SW2: on at 20, off at 30; net effect on at 10 off at 50.

Example2 SW1: on at 10, off at 50, SW2: on at 40, off at 60; net effect on at 10 off at 60.

Operation

On the rising edge of Enable, the input data will be checked against restrictions. The busy output will remain on until at least 1 track is enabled and the FB is controlling the outputs, then the InOperation bit will be set and the busy bit reset.

While the Enable is on, the EnableMask value will be read each scan and effect the output control.

On the falling edge of Enable, all outputs will be reset (turn off), and the InOperation, Busy, and Error bits will be reset. ErrorID output will be set to 0.

Input Data that is read only on rising edge of Enable

CAMSWITCH_STRUCT[].TrackNumber

CAMSWITCH_STRUCT[].AxisDirection

CAMSWITCH_STRUCT[].CamSwitchMode

AXIS_REF

CAMSWITCH_REF.MasterType

CAMSWITCH_REF.MachineCycle

CAMSWITCH_REF.LastSwitch

Input Data that is read continuously while Enabled

CAMSWITCH_STRUCT[].FirstOnPosition

CAMSWITCH_STRUCT[].LastOnPosition

CAMSWITCH_STRUCT[].Duration

CAMSWITCH_STRUCT[].FirstOnPosition

TRACK_STRUCT[].OnCompensationScaler

TRACK_STRUCT[].OffCompensationScaler

Enable

EnableMask



Output Bits: Boolean Outputs are exclusive

Data Validation

The data passed into the function block will be validated at run time.

All TrackNumbers must be in the range of 1 ~ 32 (corresponds to bit locations in EnableMask).

AxisDirection must be 0, any other number will default to 0. (values 1 and 2 not supported at this time)

CamSwitchMode must be 0 or 1, any other number will default to 0.

The total number of switches must be less than or equal to 256.

Error Description

ErrorID	Meaning
0	No error
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
10061	MasterType is something other than 0 or 1.
10062	MachineCycle must be a positive value if MasterType = 0
10063	LastSwitch is set outside the 0-255 range.
10064	Track Number outside the 0-31 range.
10065	FirstOnPosition is not equal to 0.
10066	LastOnPosition is not equal to 0.
10067	AxisDirection is not equal to 0.
10068	CamSwitchMode is not equal to 0.
10069	Duration is set to 0 or a negative value.
10070	OnCompensationScaler is set to an invalid value.
10071	OffCompensationScaler is set to an invalid value.
10072	ImproperOnPos_SetError
10073	OnOffPosition_Error

Example 1:

Consider the PLS requirement shown in the figure below. There are 4 tracks (0, 1, 2, 3) in the set up and a total of 5 switches (0, 1, 2, 3, 4).

Track 0 has 2 switches associated with it.

Switch 0: On Position : 2 degrees



PLCopen Toolbox: Function Blocks

Off Position : 10 degrees

Switch 1: On Position : 200 degrees

Off Position : 210 degrees

Track 1 has 1 switch associated with it

Switch 2: On Position : 20 degrees

Off Position : 30 degrees

Track 2 has 1 switch associated with it


Switch 3: On Position : 50 degrees

Off Position : 60 degrees

Track 3 has 1 switch associated with it

Switch 4: On Position : 100 degrees

Off Position : 200 degrees



The switches can be defined and initialized as follows:



```

(*PLS initialization*)
4      PLS_Switches.LastSwitch :=INT#4;
360.0000000 PLS_Switches.MachineCycle :=LREAL#360.0;
0      PLS_Switches.MasterType :=INT#0;

0      PLS_Switches.Switch[INT#0].TrackNumber := 0;
0      PLS_Switches.Switch[INT#0].AxisDirection := INT#0;
0      PLS_Switches.Switch[INT#0].CamSwitchMode := INT#0; (* 0: Position, 1: Time *)
0      PLS_Switches.Switch[INT#0].Duration := DINT#0;
2.00000000 PLS_Switches.Switch[0].FirstOnPosition := LREAL#2.0;
10.00000000 PLS_Switches.Switch[0].LastOnPosition := LREAL#10.0;


0      PLS_Switches.Switch[INT#1].TrackNumber := 0;
0      PLS_Switches.Switch[INT#1].AxisDirection := INT#0;
0      PLS_Switches.Switch[INT#1].CamSwitchMode := INT#0; (* 0: Position, 1: Time *)
0      PLS_Switches.Switch[INT#1].Duration := DINT#0;
200.0000000 PLS_Switches.Switch[1].FirstOnPosition := LREAL#200.0;
210.0000000 PLS_Switches.Switch[1].LastOnPosition := LREAL#210.0;

1      PLS_Switches.Switch[INT#2].TrackNumber := 1;
0      PLS_Switches.Switch[INT#2].AxisDirection := INT#0;
0      PLS_Switches.Switch[INT#2].CamSwitchMode := INT#0; (* 0: Position, 1: Time *)
0      PLS_Switches.Switch[INT#2].Duration := DINT#0;
20.00000000 PLS_Switches.Switch[2].FirstOnPosition := LREAL#20.0;
30.00000000 PLS_Switches.Switch[2].LastOnPosition := LREAL#30.0;


2      PLS_Switches.Switch[INT#3].TrackNumber := 2;
0      PLS_Switches.Switch[INT#3].AxisDirection := INT#0;
0      PLS_Switches.Switch[INT#3].CamSwitchMode := INT#0; (* 0: Position, 1: Time *)
0      PLS_Switches.Switch[INT#3].Duration := DINT#0;
50.00000000 PLS_Switches.Switch[3].FirstOnPosition := LREAL#50.0;
60.00000000 PLS_Switches.Switch[3].LastOnPosition := LREAL#60.0;

3      PLS_Switches.Switch[INT#4].TrackNumber := 3;
0      PLS_Switches.Switch[INT#4].AxisDirection := INT#0;
0      PLS_Switches.Switch[INT#4].CamSwitchMode := INT#0; (* 0: Position, 1: Time *)
0      PLS_Switches.Switch[INT#4].Duration := DINT#0;
100.0000000 PLS_Switches.Switch[4].FirstOnPosition := LREAL#100.0;
200.0000000 PLS_Switches.Switch[4].LastOnPosition := LREAL#200.0;

```




Once the Y_DigitalCamSwitch is enabled and is in operation, the track output states will be as shown in the logic analyzer plot given below. Note that the outputs will correspond to the position of the axis.



Example 2:

If speed compensation needs to be applied to individual tracks, it can be accomplished by specifying either OnCompensationScaler or OffCompensationScaler in the TRACK_REF data type (TrackOptions in Y_DigitalCamSwitch). An example of applying a -0.06 OffCompensation on track 1 and 0.05 OnCompensation on track 3 is shown below.

```
PLS TrackOptions .Track[3].OnCompensationScaler := LREAL#0.05;
```





```
(*PLS initialization*)
4      PLS_Switches.LastSwitch :=INT#4;
360.0000000 PLS_Switches.MachineCycle :=LREAL#360.0;
0      PLS_Switches.MasterType :=INT#0;

0      PLS_Switches.Switch[INT#0].TrackNumber := 0;
0      PLS_Switches.Switch[INT#0].AxisDirection := INT#0;
0      PLS_Switches.Switch[INT#0].CamSwitchMode := INT#0; (* 0: Position, 1: Time *)
0      PLS_Switches.Switch[INT#0].Duration := DINT#0;
2.00000000 PLS_Switches.Switch[0].FirstOnPosition := LREAL#2.0;
10.00000000 PLS_Switches.Switch[0].LastOnPosition := LREAL#10.0;

0      PLS_Switches.Switch[INT#1].TrackNumber := 0;
0      PLS_Switches.Switch[INT#1].AxisDirection := INT#0;
0      PLS_Switches.Switch[INT#1].CamSwitchMode := INT#0; (* 0: Position, 1: Time *)
0      PLS_Switches.Switch[INT#1].Duration := DINT#0;
200.00000000 PLS_Switches.Switch[1].FirstOnPosition := LREAL#200.0;
210.00000000 PLS_Switches.Switch[1].LastOnPosition := LREAL#210.0;


1      PLS_Switches.Switch[INT#2].TrackNumber := 1;
0      PLS_Switches.Switch[INT#2].AxisDirection := INT#0;
0      PLS_Switches.Switch[INT#2].CamSwitchMode := INT#0; (* 0: Position, 1: Time *)
0      PLS_Switches.Switch[INT#2].Duration := DINT#0;
20.00000000 PLS_Switches.Switch[2].FirstOnPosition := LREAL#20.0;
30.00000000 PLS_Switches.Switch[2].LastOnPosition := LREAL#30.0;

-0.06000000 PLS_TrackOptions.Track[1].OffCompensationScaler := LREAL#-0.06;

2      PLS_Switches.Switch[INT#3].TrackNumber := 2;
0      PLS_Switches.Switch[INT#3].AxisDirection := INT#0;
0      PLS_Switches.Switch[INT#3].CamSwitchMode := INT#0; (* 0: Position, 1: Time *)
0      PLS_Switches.Switch[INT#3].Duration := DINT#0;
50.00000000 PLS_Switches.Switch[3].FirstOnPosition := LREAL#50.0;
60.00000000 PLS_Switches.Switch[3].LastOnPosition := LREAL#60.0;

3      PLS_Switches.Switch[INT#4].TrackNumber := 3;
0      PLS_Switches.Switch[INT#4].AxisDirection := INT#0;
0      PLS_Switches.Switch[INT#4].CamSwitchMode := INT#0; (* 0: Position, 1: Time *)
0      PLS_Switches.Switch[INT#4].Duration := DINT#0;
100.00000000 PLS_Switches.Switch[4].FirstOnPosition := LREAL#100.0;
200.00000000 PLS_Switches.Switch[4].LastOnPosition := LREAL#200.0;

0.05000000 PLS_TrackOptions.Track[3].OnCompensationScaler := LREAL#0.05;
```



Yaskawa Toolbox

Yaskawa Toolbox

The Yaskawa Toolbox consists of the following:

Data Types:

Enumerated Type	Description
MovingAverageArray	For use with the MovingAverage function block.
PIDStruct	Used with the PIDControl function block.
RTCStruct	Used with the RealTimeClock , DateCompare , and the Y_SetRTC function blocks.
XYArray	Supporting structure for XYDataStruct . For use with the XYLookup function block
XYData	Supporting structure for XYArray . For use with the XYLookup function block
XYDataStruct	For use with the XYLookup function block

Function Blocks:

Function Block	Description
Action	
Blink	Toggles the Output at the frequency specified at the input.
CommWatchDog	Allows the application program to monitor data being transmitted from a master device.
DataRecord	Records data into the array.
DataSort	Sorts data from the lowest to highest value of X data.
DataCompare	Calculates the difference between two real time clock values and provides the difference as a real time clock value.
Enable_FB_Template	Template which can be used when developing functions which adhere to the PLCopen output behavior.
Enable_ST_Template	
Execute_FB_Template	
Execute_ST_Template	
MovingAverage	
PackByte	
PackWord	
PIDControl	Can be used as a generic control loop feedback mechanism.
RangeCheck	
RealTimeClock	



Scaler	
UnpackByte	
UnpackWord	
WindowCheck	
XYLookup	



Getting Started: Yaskawa

Requirements for v204

To use the Yaskawa Toolbox, your project must also contain the following:

Firmware libraries:

- YDeviceComm
- PROCONOS

User libraries:

- None

Current Version:

(***** 2013-09-01: v204 released. Requires firmware 2.1.0
 *****)

- 1) More string and byte array datatypes added to be used across the Toolbox family
- 2) LAU - new function block added. Creates a linear profile from current value to target value based on rate/scan input
- 3) SLAU - new function block added. Creates an s-curve (moving average profile) from a current value to target value.
- 4) PIcontrol - new function block added. Subset of PID block
- 5) Removed references to the Math Toolbox to simplify usage. NOTE: This change makes version 204 and higher incompatible with MP2600iec firmware versions 2.0, 2.1, and 2.2!
- 6) RateCalculator - new function block added.

Previous Versions:

(***** 2012-08-16: v203 released. Requires firmware 2.1.0
 *****)

- 1) CheckSumValidate_BYTE - Removed the Result output sad added the Method input to select a calculation method to use. There will now be a function block error if the checksum is not valid.
- 2) CheckSumCalculate_BYTE - Added the Method input.

(***** 2012-06-19: v202 released. Requires firmware 2.1.0
 *****)

- 1) Sweep function improved by adding Trigger and Stream inputs.
- 2) Explicit_Message - new function block added. Y_DeviceComm firmware library added
- 3) CheckSumCalculate_BYTE - new function block added.
- 4) CheckSumValidate_BYTE - new function block added.



- 4) Blink function - resolution improved.

(***** 2011-11-16: v201 released
 *****)

- 1) Reduced the size of the DataType definition for MovingAverageArray back down to 1000 as it was in v008. 30000 is too large, and causing "Data Area Exceeded" error for some users.

(***** 2011-07-29: v200 released
 *****)

- 1) Built from v010beta for MotionWorks IEC 2.0.
- 2) Upgraded to Math Toolbox v200
- 3) Changed Scaler FB to allow negative slope
- 4) Fixed bug in XY Lookup (Min and Max were not getting reset for each scan.)

(***** 2011-04-27: v010beta created
 *****)

- 1) Updated to Math_Toolbox_v004
- 2) Removed spaces in filename and replaced with underscores
- 3) Changed MovingAverage to always divide by the number of samples specified by the user. Old methods divided by the number of actual samples until the entire buffer had been filled.
- 4) Changed the Blink functions frequency input to REAL datatype and the value now accepts a frequency. (Before it was TIME datatype)
- 5) Added RTCString as output of RealTimeClock FB
- 6) Added error checking to WindowCheck FB to ensure Window value is greater than zero.



(***** 2011-03-25: v009 released
*****)

- 1) Added Error logic to PIDControl
- 2) Improved MovingAverage to not require a FOR LOOP to initialize the buffer at rising edge of ENABLE
- 3) Moved Math Functions to Math Toolbox
- 4) Included ProConOS firmware library to use the Real Time Clock function, provided FB to convert RTC from STRING TO STRUCT
- 5) Added DateCompare FB, STILL UNDER TEST in v009.
- 6) Moved REM function to the Math Toolbox v002.
- 7) Added XYLookup, which is equivalent to the FGN function in the standard MP series
- 8) Added DataSort, to arrange the data for use with XYLookup if it has been collected out of order.
- 9) Added DataRecord to capture XY data by either streaming or when the Trigger input goes high.
- 10) Fixed MovingAverage - it was not properly subtracting old and adding new values.

(***** 2010-02-03: v008 released
*****)

Added REM function to return the remainder of LREAL division.

Added Pack & Unpack of Byte and Word.

Added RangeCheck function block.

Added WindowCheck function.

Added Sweep function, useful for testing a range of values.

(***** 2009-10-29: v007 released
*****)

Added ErrorID and outputs to MovingAverage.

Removed ErrorWatchDog functions.



Improved templates with new, reduced logic that does not use SET or RESET coils.

Added template functions for Enable in ST and LD.

Changed functions for MP2600 compatibility by removing EN / ENO and adding MOVE_UINT.

Added Valid outout to PID function.

(***** 2009-04-03: v006 released
*****)

Added CommHeartbeat Funtion

(***** 2009-03-27: v005 released
*****)

Added MovingAverage Funtion

(***** 2009-02-06: v004 released
*****)

Added the Blink function for toggling an output at a TIME interval.

Added FB_Error_Capture, FB_Error_WatchDog, FB_Error_Clear for trapping function block errors

Corrected and improved PIDControl FB based on Eric Kelley's modifications

Under Construction! - FBError trapping functions blocks, Timestamp not implemented.

(***** 2008-10-17: v002 released
*****)

Added PIDControl Function Block and associated DataType structure

(***** 2008-09-26 v001 released
*****)

Execute_FB_Template:



Shell code with all logic to replicate the behavior of PLCopen FB with Execute, Busy, Done, Error, & ErrorID outputs

Behavior and variables match the ST version.

Execute_ST_Template:

Shell code with all logic to replicate the behavior of PLCopen FB with Execute, Busy, Done, Error, & ErrorID outputs

Behavior and variables match the FB version.

Action:

Dummy FB to show simulation of the template function blocks.



Explicit Data Types

ExplicitSendDataStruct

For use with the [Explicit_Message](#) function block

Data Type Declaration

ExplicitSendDataStruct : STRUCT (*Refer to 2-5.7.2 in Vol 2, Chapter 2 EtherNet/IP Adaptation of CIP*)

ED_Command1 : BYTE; (*ED:Encapsulation Data*)

ED_Command2 : BYTE;

ED_Length1 : BYTE;

ED_Length2 : BYTE;

ED_SessionHandle1 : BYTE;

ED_SessionHandle2 : BYTE;

ED_SessionHandle3 : BYTE;

ED_SessionHandle4 : BYTE;

ED_Status1 : BYTE;

ED_Status2 : BYTE;

ED_Status3 : BYTE;

ED_Status4 : BYTE;

ED_SenderContext : SenderContext;

ED_Options1 : BYTE;

ED_Options2 : BYTE;

ED_Options3 : BYTE;

ED_Options4 : BYTE;

ED_InterfaceHandle1 : BYTE;

ED_InterfaceHandle2 : BYTE;

ED_InterfaceHandle3 : BYTE;



Yaskawa Toolbox: DataTypes



ED_InterfaceHandle4 : BYTE;

ED_TimeOut1 : BYTE;

ED_TimeOut2 : BYTE;

ED_ItemCount1 : BYTE;

ED_ItemCount2 : BYTE;

ED_AddressItemID1 : BYTE;

ED_AddressItemID2 : BYTE;

ED_AddressItemLength1 : BYTE;

ED_AddressItemLength2 : BYTE;

ED_DataItemID1 : BYTE;

ED_DataItemID2 : BYTE;

ED_DataItemLength1 : BYTE;

ED_DataItemLength2 : BYTE;

ED_DataService : Service;

ED_Data : ExplicitData;

END_STRUCT;



ExplicitReceiveDataStruct

For use with the [Explicit_Message](#) function block

Data Type Declaration

ExplicitReceiveDataStruct : STRUCT (*Refer to 2-5.7.2 in Vol 2, Chapter 2 EtherNet/IP Adaptation of CIP*)

ED_Command1 : BYTE; (*ED:Encapsulation Data*)

ED_Command2 : BYTE;

ED_Length1 : BYTE;

ED_Length2 : BYTE;

ED_SessionHandle1 : BYTE;

ED_SessionHandle2 : BYTE;

ED_SessionHandle3 : BYTE;

ED_SessionHandle4 : BYTE;

ED_Status1 : BYTE;

ED_Status2 : BYTE;

ED_Status3 : BYTE;

ED_Status4 : BYTE;

ED_SenderContext : SenderContext;

ED_Options1 : BYTE;

ED_Options2 : BYTE;

ED_Options3 : BYTE;

ED_Options4 : BYTE;

ED_InterfaceHandle1 : BYTE;

ED_InterfaceHandle2 : BYTE;

ED_InterfaceHandle3 : BYTE;

ED_InterfaceHandle4 : BYTE;



Yaskawa Toolbox: DataTypes



ED_TimeOut1 : BYTE;

ED_TimeOut2 : BYTE;

ED_ItemCount1 : BYTE;

ED_ItemCount2 : BYTE;

ED_AddressItemID1 : BYTE;

ED_AddressItemID2 : BYTE;

ED_AddressItemLength1 : BYTE;

ED_AddressItemLength2 : BYTE;

ED_DataItemID1 : BYTE;

ED_DataItemID2 : BYTE;

ED_DataItemLength1 : BYTE;

ED_DataItemLength2 : BYTE;

ED_Response1 : BYTE;

ED_Response2 : BYTE;

ED_ResponseStatus1 : BYTE;

ED_ResponseStatus2 : BYTE;

ED_Data : ExplicitData;

END_STRUCT;



RegSessionRequestStruct

For use with the [Explicit Message](#) function block.

Data Type Declaration

RegSessionRequestStruct : STRUCT (*Refer to 2-5.4.2 in Vol 2, Chapter 2 EtherNet/IP Adaptation of CIP*)

RSR_Command1 : BYTE; (*RSR: Register Session Request*)

RSR_Command2 : BYTE;

RSR_Length1 : BYTE;

RSR_Length2 : BYTE;

RSR_SessionHandle1 : BYTE;

RSR_SessionHandle2 : BYTE;

RSR_SessionHandle3 : BYTE;

RSR_SessionHandle4 : BYTE;

RSR_Status1 : BYTE;

RSR_Status2 : BYTE;

RSR_Status3 : BYTE;

RSR_Status4 : BYTE;

RSR_SenderContext : SenderContext;

RSR_Options1 : BYTE;

RSR_Options2 : BYTE;

RSR_Options3 : BYTE;

RSR_Options4 : BYTE;

RSR_ProtocolVersion1 : BYTE;

RSR_ProtocolVersion2 : BYTE;

RSR_OptionFlags1 : BYTE;

RSR_OptionFlags2 : BYTE;



Yaskawa Toolbox: DataTypes
END_STRUCT;





UnRegSessionRequestStruct

For use with the [Explicit Message](#) function block.

Data Type Declaration

UnRegSessionRequestStruct : STRUCT (*Refer to 2-5.4.3 in Vol 2, Chapter 2 EtherNet/IP Adaptation of CIP*)

USR_Command1 : BYTE;

USR_Command2 : BYTE; (*USR: Unregister Session Request *)

USR_Length1 : BYTE;

USR_Length2 : BYTE;

USR_SessionHandle1 : BYTE;

USR_SessionHandle2 : BYTE;

USR_SessionHandle3 : BYTE;

USR_SessionHandle4 : BYTE;

USR_Status1 : BYTE;

USR_Status2 : BYTE;

USR_Status3 : BYTE;

USR_Status4 : BYTE;

USR_SenderContext : SenderContext;

USR_Options1 : BYTE;

USR_Options2 : BYTE;

USR_Options3 : BYTE;

USR_Options4 : BYTE;

END_STRUCT;



SenderContext

For use with the [Explicit Message](#) function block.

Data Type Declaration

TYPE

SenderContext : ARRAY[0..7] OF BYTE;

END_TYPE



Service

For use with the [Explicit Message](#) function block.

Data Type Declaration

TYPE

Service : ARRAY[0..7] OF BYTE;

END_TYPE



ExplicitData

For use with the [Explicit Message](#) function block.

Data Type Declaration

TYPE

ExplicitData : ARRAY[0..503] OF BYTE;

END_TYPE



Data Types

Data Types for Yaskawa Toolbox

The following is a complete list of all DataTypes included in the [Yaskawa Toolbox](#). The list is arranged to separate those that are used internally, and not useful outside of their particular function, and those that an application program must incorporate when the programmer wishes to use the associated Function Block.

Data Type	Usage
DataTypes for external use with Yaskawa Toolbox function blocks	
MovingAverageArray	For use with the MovingAverage function block.
PIDStruct	Used with the PIDControl function block.
RTCStruct	Used with the RealTimeClock , DateCompare , and the Y_SetRTC function blocks.
XYDataStruct	For use with the XYLookup function block
DataTypes that support other DataTypes (no need for direct use by the application programmer)	
XYArray	Supporting structure for XYDataStruct . For use with the XYLookup function block
XYData	Supporting structure for XYArray . For use with the XYLookup function block



Data Type: MovingAverageArray

For use with the [MovingAverage](#) function block.

Data Type Declaration

TYPE

MovingAverageArray: ARRAY[0..30000] OF LREAL; (* Adjust the array size if more data elements are desired.
*)

END_TYPE



Data Type: PIDStruct

Used with the [PIDControl](#) function block.

Data Type Declaration

TYPE

PIDStruct: STRUCT

Ts:LREAL; (* Sample time *)

Kp:LREAL; (* Proportional Gain *)

Ki:LREAL; (* Integral Gain *)

Kd:LREAL; (* Derivative Gain *)

Ti:LREAL; (* Integral Time (in Sec.) *)

Td1:LREAL; (* Derivative Time for Divergent Inputs *)

Td2:LREAL; (* Derivative Time for Convergent Inputs *)

ILL:LREAL; (* Integral Lower Limit *)

IUL:LREAL; (* Integral Upper Limit *)

LowerLimit:LREAL; (* Lower Limit for ControlOutput *)

UpperLimit:LREAL; (* Upper Limit for ControlOutput *)

DeadBand:LREAL; (* Dead band limit *)

END_STRUCT;

END_TYPE



Data Type: RTCStruct

Used with the [RealTimeClock](#), [DateCompare](#), and the Y_SetRTC function blocks.

Data Type Declaration

TYPE

RTC_Struct: STRUCT

Year:INT;

Month:INT;

Day:INT;

Hour:INT;

Minute:INT;

Second:INT;

mSec:INT;

END_STRUCT;

END_TYPE



Data Type: XYArray

Supporting structure for [XYDataStruct](#). For use with the [XYLookup](#) function block.

Data Type Declaration

TYPE

XYArray: ARRAY[0..4000] OF [XYData](#); (* NOTE! Had strange error message after

download when set to 5000 *)

END_TYPE



Data Type: XYData

Supporting structure for [XYArray](#). For use with the [XYLookup](#) function block

Data Type Declaration

```
TYPE
```

```
XYData: STRUCT
```

```
X:LREAL; (* Any data that will be used with the XY lookup function  
as input *)
```

```
Y:LREAL; (* Any data that will be used with the XY lookup function  
as output *)
```

```
END_STRUCT;
```

```
END_TYPE
```



Data Type: XYDataStruct

For use with the [XYLookup](#) function block

Data Type Declaration

TYPE

XYDataStruct: STRUCT

Pair: [XYArray](#); (* Adjust the XYArray size if more data elements are desired. *)

LastPair:INT; (* Set this value to indicate the last ACTUAL array element
that contains user data *)


END_STRUCT;

END_TYPE;



Function Blocks

Action



This function block is only for demonstration purposes. It is applied in the Enable_F_Template, Enable_ST_Template, Execute_FB_Template, and Execute_ST_Template function blocks to show how the inputs and outputs of nested functions can be interlocked to apply the PLCopen standards for I/O behavior.

Parameters

* _	Parameter	Data Type	Description	
VAR_INPUT				Default
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
VAR_OUTPUT				
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.	
B	CommandAborted	BOOL	Set high if motion is aborted by another motion command or MC_Stop. This output is cleared with the same behavior as the Done output.	
B	Error	BOOL	Set high if error has occurred during the execution of the	



			function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Error Description

This function provides no Errors.

Example

See the Enable_F_Template, Enable_ST_Template, Execute_FB_Template, and Execute_ST_Template function blocks.



Blink



This function block will toggle the Output at the frequency specified at the input. If Frequency is set to 1.0, then the output will be on for 500 msec and off for 500 msec. Note that the actual frequency may be affected by the application scan rate in which this function block is placed.

Parameters


Parameter		Data Type	Description	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
V	Frequency	LREAL	The cycle rate in Hertz.	LREAL#0.0
VAR_OUTPUT				
B	Valid	BOOL	Indicates if the function is operating	
V	Output	BOOL	Toggled at the specified frequency when the function is enabled.	

Error Description


The valid output will be high if the function is operating. If Enable is held high and the Frequency is not greater than zero, the valid output will be low.

Example

Blink_1 was placed in a 10ms task so the expected output is 50ms on and 50ms off which corresponds to 5 cycles on, 5 cycles off.



Logic Analyzer output:





ByteSwap



This function block swaps the upper and lower byte of a word.

Parameters

Parameter		Data Type	Description	
VAR_INPUT				Default
B	WordIn	WORD	Input word	WORD#0
VAR_OUTPUT				
B	WordOut	WORD	Output word	

Error Description

This block will not produce any errors.

Example:





CommWatchDog



This function block allows the application program to monitor data being transmitted from a master device. If the data does not change within the TimeOut period, then the OK output goes off to indicate that the communications is not being updated by the master.

Parameters


* _	Parameter	Data Type	Description	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
V	HeartBeat	DINT	Value that the master changes and sends to the MP2000iec controller.	DINT#0
V	WatchDog	DINT	The HeartBeat input must change value within the TimeOut period for the communications to be considered OK.	DINT#0
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
V	OK	BOOL	Indicates if the HeartBeat input has changed within the TimeOut period.	

Error Description

The Valid Output will be high when the function is executing. If the WatchDog value is not greater than zero, the function will not operate.



DataRecord



This function block will record Data into the array. Data can be stored continuously or intermittently. The default datatype for Data to be recorded can be customized by the user to satisfy other recording needs.

Parameters

Parameter		Data Type	Description	
VAR_IN_OUT				
V	Data	XYDataStruct	Structure where recorded data is stored	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
V	DataSize	INT	The maximum amount of data to be stored, which must be less than or equal to the datatype definition for Data.	INT#0
V	NewData	XYData	Structure containing a single pair of X and Y data to be added to the XYDataStruct.	n/a
V	Stream	BOOL	If TRUE, the function will store NewData every application scan.	FALSE
V	Trigger	BOOL	If Stream is FALSE, then the function will store new Data only upon the rising edge of Trigger.	FALSE
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	




V	Index	INT	Indicates the last array index recorded
V	DataFilled	BOOL	Indicates when the Data recording has reached the DataSize
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.

Error Description

ErrorID	Meaning
0	No error
10024	DataSize must be greater than zero



DataSort



This function block will sort data from the lowest to highest value of X data. It was designed to work with data that may be used with a cam function where the X or master data must continually increase, but this generic function can be customized for other sorting needs.

Parameters

*_	Parameter	Data Type	Description	
VAR_IN_OUT				
V	Data	XYDataStruct	Structure where recorded data is stored	
VAR_INPUT				Default
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
VAR_OUTPUT				
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	



B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.
---	---------	------	--

Notes


This function is designed to sort by the X data in ascending order only.

Error Description

The default version of this block produces no errors (customizing this block may add errors depending on what functions are used internally).



DateCompare



This function block will calculate the difference between two real time clock values and provide the difference as a real time clock value. The clock values may be obtained using the RealTimeClock function block.

Parameters


<u>*</u>	Parameter	Data Type	Description	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
V	Clock1	RTCStruct	The first (older) real time clock value	N/A
V	Clock2	RTCStruct	The second (newer) real time clock value	N/A
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
E	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	
V	ClockDiff	RTCStruct	Outputs the time difference between Clock1 and Clock2	

Error Description

There will be no Errors reported.



Enable_FB_Template



This function block is a template which can be used when developing functions which adhere to the PLCopen output behavior.

Parameters


*_	Parameter	Data Type	Description	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	

Error Description

This is an example function block template with no specific errors of its own.



Enable_ST_Template



This function block is a template which can be used when developing functions which adhere to the PLCopen output behavior.

Parameters


*_	Parameter	Data Type	Description	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	

Error Description

This is an example function block template with no specific errors of its own.



Execute_FB_Template



This function block is a template which can be used when developing functions which adhere to the PLCopen output behavior.

Parameters

*_	Parameter	Data Type	Description	Default
VAR_INPUT				
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
VAR_OUTPUT				
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.	
B	CommandAborted	BOOL	Set high if motion is aborted by another motion command or MC_Stop. This output is cleared with the same behavior as the Done output.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	



Notes


Depending on the exact usage, there may be outputs in the template that will not apply, such as CommandAborted. Please determine what outputs are necessary for your situation and make modifications accordingly.

Error Description

This is an example function block template with no specific errors of its own.



Execute_ST_Template



This function block is a template which can be used when developing functions which adhere to the PLCopen output behavior.

Parameters

<u>*</u>	Parameter	Data Type	Description	
VAR_INPUT				Default
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.	FALSE
VAR_OUTPUT				
B	Done	BOOL	Set high when the commanded action has been completed successfully. If another block takes control before the action is completed, the Done output will not be set. This output is reset when execute goes low.	
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.	
B	CommandAborted	BOOL	Set high if motion is aborted by another motion command or MC_Stop. This output is cleared with the same behavior as the Done output.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	



Notes

This template contains supporting code for:

- Initialization
- Main code body
- Output status updates


Depending on the exact usage, there may be outputs in the template that will not apply, such as CommandAborted. Please determine what outputs are necessary for your situation and make modifications accordingly.

Error Description

This is an example function block template with no specific errors of its own.



Explicit_Message



This function block will write/read a block of data to/from an Ethernet/IP Target (Adapter) device via Explicit Messaging. Unlike Implicit Messaging (a built in feature of the MPiec Series Controllers) which uses the UDP protocol, Explicit Messaging uses TCP/IP.

This function block emulates the MSG function block in the AB RSLogix platform. The Explicit_Message function block is best suited when an application requires unscheduled and less frequent updates like recipe transfer, cam table transfer, job transfer etc. Explicit Messaging makes use of a request/response format for communication.

Parameters

*	Parameter	Data Type	Description
VAR_IN_OUT			
B	SourceElement	ExplicitData	When writing a message to the Target (Adapter), SourceElement is the data (as an array of bytes) that the Scanner (MPiec Controller) will send to the Target.
B	Destination	ExplicitData	When reading a message from the Target (Adapter), the



			Destination Element is the data (as an array of bytes) where the Scanner (MPIec Controller) will copy the data from the Target.
VAR_INPUT			Default
B	Execute	BOOL	Upon the rising edge, all other function block inputs are read and the function is initiated. To modify an input, change the value and re-trigger the execute input.
B	AdapterIPAddress	STRING	IP Address of the Target device.
B	ServiceCode	BYTE	Code for the particular service type as defined for a CIP message. The value can be obtained from the Target's (Adapter's) documentation.
B	Class	BYTE	Class parameter of a CIP Generic message. The value can be obtained from the Target's (Adapter's) documentation.
B	Instance	BYTE	Instance parameter of a CIP Generic message. The value can be obtained from the Target's (Adapter's) documentation.
B	Attribute	BYTE	Attribute parameter of a CIP Generic message. The value can be obtained from the Target's (Adapter's) documentation.
B	SourceLength	INT	The number of bytes to be written to the Target. This is the actual data size required, not the full size of the SourceData DataType.
VAR_OUTPUT			
B	Done	BOOL	The done bit is set high when the last packet of the message is successfully transferred.
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.
B	Status	DWORD	Indicates if the Target was able to execute the requested command. A value of zero indicates successful execution of the command by the remote device.
B	Response	WORD	Response from the Target.
B	ResponseStatus	WORD	Status of the response from the Target.

Notes



Yaskawa Toolbox: Function Blocks



- The Explicit_Message function block uses the Y_DeviceComm firmware library. This firmware library must be added to your project. Y_DeviceComm was incorporated into firmware version 2.1.0 and has been included as a firmware library starting in MotionWorks IEC v2.1.0.
- Enter parameters as entered in Message Configuration for the MSG function block in AB RSLogix software.
- See Yaskawa's Youtube webinar - [EtherNet/IP Explicit Messaging](#) for more info.

The screenshot shows the 'Message Configuration - msgWrite' dialog box. The 'Communication' tab is active, showing 'WRITE to MP2300Siec'. The 'Message Type' is 'CIP Generic'. The 'Service Type' is 'Set Attribute Single'. The 'Source Element' is 'data_111' and 'Source Length' is '128 (Bytes)'. The 'Service Code' is '10 (Hex)', 'Class' is '4 (Hex)', and 'Instance' is '111'. The 'Attribute' is '3 (Hex)'. The 'Destination' field is empty. The 'Done' radio button is selected. The 'Error Code' is 'Extended Error Code' and 'Timed Out' is checked. The 'Error Path' and 'Error Text' fields are empty. The 'Explicit_Message' function block parameters are listed in a blue box on the right, with red dashed arrows pointing from the dialog box fields to the corresponding parameters: SourceElement, Destination, Execute, AdapterIPAddress, ServiceCode, Class, Instance, Attribute, SourceLength, Done, Busy, Error, ErrorID, Status, Response, and ResponseStatus.

Error Description

ErrorID	Meaning
0	No error
8705	The maximum number of concurrently open user IO devices (sockets/files) has been reached.
8706	The socket handle was invalid.
8707	The IP address string was not in a valid format.
8708	The socket could not be created.
8709	The specified address or port is already in use on the local network.
8710	The specified address or port is not available for use.
8711	Unable to accept new socket connection.
8712	Unable to bind to the specified address.
8713	The socket type argument was invalid.
8714	The local address or port was not valid.
8715	The socket could not be connected.
8716	There is no network routing path to the specified address.



8717	The socket is already connected to another endpoint.
8718	The socket connection attempt was actively refused by the remote peer.
8719	The socket was not connected to a remote endpoint. Call Y_ConnectSocket prior to Y_ReadDevice or Y_WriteDevice.
8720	An error occurred trying to get or set the device option.
8721	The communication device could not be read.
8722	The communication device could not be written.
8723	The Buffer argument to WriteDevice and ReadDevice is required.
8724	The device option ID was invalid.
8725	The device option value was not the right size or the data was out of range.
8726	The serial port ID was not a valid serial port.
8727	The serial port could not be opened.

Example 1

Set Single Attribute

Variable Properties (SrcEle):
 Name: SrcEle
 Data Type: ExplicitData
 Usage: VAR
 Initial value: []

Variable Properties (D1):
 Name: D1
 Data Type: ExplicitData
 Usage: VAR
 Initial value: []


Watch Window (SrcEle):

Variable	Value
SrcEle [0]	0
SrcEle [1]	0
SrcEle [2]	0
SrcEle [3]	0
SrcEle [4]	0
SrcEle [5]	0
SrcEle [6]	0
SrcEle [7]	0
SrcEle [8]	0
SrcEle [9]	0
SrcEle [10]	0
SrcEle [11]	0
SrcEle [12]	0
SrcEle [13]	0

Function Block: Explicit_Message_6
 Inputs: SrcEle, D1, Execute (1)
 Outputs: SrcEle, D1, SetAttributeDone (1), SetAttributeBusy (0), SetAttributeError (0), SetAttributeErrorID (0), Stat (0), Resp (144), RespStat (0)
 Annotations: (*Write instance 111 to MP2000iec slave*)


Example 2

Get Attribute single





MovingAverage



This function block will provide the MovingAverage of a series of samples. The NewValue can either be streamed continuously or updated only when the Trigger value goes high.

Parameters

<u>*</u>	Parameter	Data Type	Description	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
V	NewValue	LREAL	The new value to be added to the total	LREAL#0.0
V	SampleSize	UINT	The total number of values to total	UINT#0
V	Trigger	BOOL	To indicate when a NewValue should be added to the total	FALSE
V	Stream	BOOL	To indicate if the NewValues should be added to the total every scan.	FALSE
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
V	MovingAverage	LREAL	The moving average of all the samples.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	



Notes


- See Yaskawa's Youtube webinar - [MPiec Web Tension Control Applications](#) for more info on using this function block.

Error Description


ErrorID	Meaning
0	No error
10024	DataSize must be greater than zero

Example

The MovingAverage function acts as a smoothing filter. In this example, the Sweep function will increment by 5 each cycle. The Sweep function will continue to increment the OutputValue until it has reached 100.




The Moving average function has a sample size of 50 which means that if Sweep reaches its maximum value after 19 cycles, MovingAverage will output the maximum value after 69 cycles. By looking at the Logic Analyzer plot below, notice there is a 5 cycle pre-record that must be taken in to account: $74 - 5 = 69$ cycles.





PackByte



This function block converts 8 Boolean inputs to a single byte output.


Parameters

*_	Parameter	Data Type	Description	
VAR_INPUT				Default
V	Bit0	BOOL	Bit 0 of the BYTE to be output	FALSE
V	Bit1	BOOL	Bit 1 of the BYTE to be output	FALSE
V	Bit2	BOOL	Bit 2 of the BYTE to be output	FALSE
V	Bit3	BOOL	Bit 3 of the BYTE to be output	FALSE
V	Bit4	BOOL	Bit 4 of the BYTE to be output	FALSE
V	Bit5	BOOL	Bit 5 of the BYTE to be output	FALSE
V	Bit6	BOOL	Bit 6 of the BYTE to be output	FALSE
V	Bit7	BOOL	Bit 7 of the BYTE to be output	FALSE
VAR_OUTPUT				
V	OutputByte	BYTE	Resulting byte of the input bits	

Error Description




Example





PackWord



This function block converts 16 Boolean inputs to a single WORD output.

Parameters

*	Parameter	Data Type	Description	
VAR_INPUT				Default
V	Bit0	BOOL	Bit 0 of the WORD to be output	
V	Bit1	BOOL	Bit 1 of the WORD to be output	
V	Bit2	BOOL	Bit 2 of the WORD to be output	
V	Bit3	BOOL	Bit 3 of the WORD to be output	




V	Bit4	BOOL	Bit 4 of the WORD to be output	
V	Bit5	BOOL	Bit 5 of the WORD to be output	
V	Bit6	BOOL	Bit 6 of the WORD to be output	
V	Bit7	BOOL	Bit 7 of the WORD to be output	
V	Bit8	BOOL	Bit 8 of the WORD to be output	
V	Bit9	BOOL	Bit 9 of the WORD to be output	
V	Bit10	BOOL	Bit A of the WORD to be output	
V	Bit11	BOOL	Bit B of the WORD to be output	
V	Bit12	BOOL	Bit C of the WORD to be output	
V	Bit13	BOOL	Bit D of the WORD to be output	
V	Bit14	BOOL	Bit E of the WORD to be output	
V	Bit15	BOOL	Bit F of the WORD to be output	
VAR_OUTPUT				
V	OutputWord	WORD	The resulting WORD of the input bits	

Error Description


No errors will be generated

Example





PIDControl



This function block can be used as a generic control loop feedback mechanism. A PID controller calculates an "error" value as the difference between a measured process variable and a desired set point, or reference.

PIDParameters must be adjusted to allow the process to provide the proper ControlOutput for a given error situation.

Parameters

*	Parameter	Data Type	Description	Default
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
V	PIDParameters	PIDStruct	Structure containing all the information for PID control block to operate	N/A
V	Reference	LREAL	Setpoint for the PID control loop.	LREAL#0.0
V	ProcessValue	LREAL	Real world value to be compared with the Reference in the control loop	LREAL#0.0
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
V	ControlOutput	BOOL	Output value from the PID control block. The range of values will be governed by the PIDParameters, especially the upper and lower limit.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	



Notes

- All time parameters in the PIDStruct (Ts, Td1, and Td2) must be in the same units, i.e seconds or ms.
- See Yaskawa's Youtube webinar - [MPiec Web Tension Control Applications](#) for more info on using this function block.

Example

Initialization of the PIDStruct:

PIDPrm.Ts := LREAL#0.004; (* Set to the same value as the cyclic application task *)

PIDPrm.Kp := LREAL#40.0; (* Proportional gain *)

PIDPrm.Ki := LREAL#0.0; (* Integral gain *)

PIDPrm.Kd := LREAL#0.0; (* Derivative gain *)

PidPrm.Td1 := LREAL#4.0; (* Divergence differentiation time *)

PidPrm.Td2 := LREAL#4.0; (* Convergence differentiation time *)

PIDPrm.Ti := LREAL#4.0; (* Integration time *)

PIDPrm.ILL := LREAL#-10.0; (* The smallest integration value *)

PIDPrm.IUL := LREAL#10.0; (* The largest integration value *)

PIDPrm.LowerLimit:= LREAL#-2000.0; (* The smallest ControlOutput that will be output *)

PIDPrm.UpperLimit:= LREAL#2000.0; (* The largest ControlOutput that will be output *)

PIDPrm.DeadBand := LREAL#0.00001; (* Maximum absolute error value that will result in a

ControlOutput of zero *)

Symbol	Specification
Ts	Scan time set value
Kp	Proportional gain
Ki	Integral gain
Kd	Derivative gain
Td1	Divergence differentiation time
Td2	Convergence differentiation time
Ti	Integration time
IUL	Upper integration limit
ILL	Lower integration limit



LowerLimit	Lower PID Limit
UpperLimit	Upper PID limit
Deadband	Width of the deadband for the P+I+D correction value

Here, the PID operation is expressed as follows:

$$\frac{Y}{X} \cdot Kp + \frac{Ki}{Ti \cdot S} = Kd \cdot Td \cdot S$$


$$\frac{Y}{X} = Kp + Kd \cdot Td \cdot S$$

X: deviation input value; Y: output value


The following operation is performed within the PID instruction:

$$Y = Kp \cdot X + \left\{ \frac{Ki \cdot X + IREM}{\frac{Ti}{Ts}} + Yi' \right\} + Kd \cdot (X - X') \cdot \frac{Td}{Ts}$$

X': previous input value; Yi': previous I output value; Ts: scan time set value




1. An example controlling a servo in torque mode:




The following series of graphs show changes made to the PID gains to minimize error:

a. Proportional Control Only. Severe oscillation:




b. PID Control. Derivative helps to control oscillation:




Variable	Value
PwrEnable	???
MvDCExe	???
PIDPm	
Kp	1.000000E-001
Ki	1.000000E-002
Kd	5.000000E-001
Ti	4.000000E-003
Td1	4.000000E-003
Td2	4.000000E-003
IUL	1.000000E+001
ILL	-1.000000E+001
UpperLimit	1.000000E+002
LowerLimit	-1.000000E+002
DeadBand	0.000000E+000
Ts	4.000000E-003

c. PID Control – Increasing the derivative gain:



Variable	Value
PwrEnable	???
MvDCExe	???
PIDPm	
Kp	1.000000E-001
Ki	1.000000E-002
Kd	1.000000E+000 *
Ti	4.000000E-003
Td1	4.000000E-003
Td2	4.000000E-003
IUL	1.000000E+001
ILL	-1.000000E+001
UpperLimit	1.000000E+002
LowerLimit	-1.000000E+002
DeadBand	0.000000E+000
Ts	4.000000E-003


d. Further increase in the derivative gain:





Variable	Value	Default value	Type
PwrEnable	???		
MvDCExe	???		
PIDPrm			PIDStruct
Kp	1.000000E-001		LREAL
Ki	1.000000E-002		LREAL
Kd	8.000000E-001		LREAL
Ti	4.000000E-003		LREAL
Td1	4.000000E-003		LREAL
Td2	4.000000E-003		LREAL
IUL	1.000000E+001		LREAL
ILL	-1.000000E+001		LREAL
UpperLimit	1.000000E+002		LREAL
LowerLimit	-1.000000E+002		LREAL
DeadBand	0.000000E+000		LREAL
Ts	4.000000E-003		LREAL

e. PD Control – Integral gain is set to zero, which is best suited for this example.






Watch Window

Variable	Value	Default value	Type
PwrEnable	???		
MvDCExe	???		
PIDPrm			PIDStruct
Kp	1.0000000E-001		LREAL
Ki	0.0000000E+000		LREAL
Kd	8.0000000E-001		LREAL
Ti	4.0000000E-003		LREAL
Td1	4.0000000E-003		LREAL
Td2	4.0000000E-003		LREAL
IUL	1.0000000E+001		LREAL
ILL	-1.0000000E+001		LREAL
UpperLimit	1.0000000E+002		LREAL
LowerLimit	-1.0000000E+002		LREAL
DeadBand	0.0000000E+000		LREAL
Ts	4.0000000E-003		LREAL

Watch 1 Watch 2 Watch 3 Watch 4 Watch 5 Watch 6 Watch 7 Watch 8 Watch 9



RangeCheck



This function block will set the output 'InRange' if the Value input is between the Minimum and Maximum. The check is inclusive, meaning that if Value=Minimum or Value=Maximum, then the InRange output will be on.

Parameters

* _	Parameter	Data Type	Description	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
V	Minimum	LREAL	The smallest 'Value' that will set the InRange output high.	LREAL#0.0
V	Value	LREAL	The data to be tested against the Minimum and Maximum.	LREAL#0.0
V	Maximum	LREAL	The largest 'Value' that will set the InRange output high.	LREAL#0.0
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
V	InRange	BOOL	Indicates if the Value is between the Minimum and Maximum. (Inclusive)	


Error Description

No errors will be generated.

Example




ExeRange does not need to be toggled if Value is changed, as demonstrated below:





RateCalculator



This function block determines the frequency and number of occurrences of an event, such as determining the part output rate of a machine. RateCalculator counts the number of times an input 'Sensor' signal produces a rising edge and determines the frequency of that signal with respect to a chosen time period. It can account for real-time changes to the time period.

Parameters

* _	Parameter	Data Type	Description
VAR_INPUT			
B	Enable	BOOL	The function will continue to execute while enable is held high.
V	Sensor	BOOL	Periodic signal to be measured. Commonly a "part-complete" sensor.
V	TimePeriod_ms	DINT	Sensor is measured with respect to this time window (milliseconds) to determine the current real-time rate.
VAR_OUTPUT			
B	Valid	BOOL	Indicates that the outputs of the function are valid.
B	Busy	BOOL	Set high upon the rising edge of the 'Execute' or 'Enable' input, and reset if Done, CommandAborted, or Error is true.
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.
V	CounterValue	LREAL	Number of times 'Sensor' has measured a rising edge since the function block has been enabled.
V	CurrentRate	LREAL	The current frequency of the 'Sensor' input with respect to the



			chosen time period
--	--	--	--------------------

Notes


- Upon enabling or a change of the time period, the 'Busy' signal remains active until the specified time period elapses, whereupon 'Busy' will go low and 'Valid' will go high. This is to receive a complete initial measurement of the rate 'Sensor' / 'TimePeriod_ms'.

Error Description

No errors will be generated.



RealTimeClock



This function block provides the controllers real time clock as an [RTCStruct](#) containing year, month, day, hour, minute, second, and millisecond. This function uses the RTC_S function, provided in the ProConOS firmware library, which returns the real time clock as a string.

Parameters

*	Parameter	Data Type	Description	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	
V	Clock	RTCStruct	Structure containing year, month, day, hour, minute, second, and millisecond.	

Notes

The controllers clock can be set from the web server, or by using the Y_SetRTC function block, which requires firmware version 2.0.0 or greater.


Error Description



No errors will be generated.


Example

The output of this block is continually updated as long as Enable is TRUE.





Scaler



This function block performs the calculation $y := mx + b$.

m is determined by the slope of a line specified by Cal_X1, Cal_Y1, Cal_X2, Cal_Y2.

x is the 'Input'

b is determined by calculating the Y intercept of the line.

This function can be used with temperature sensors or any analog value that must be adjusted before further processing takes place.

Parameters

*	Parameter	Data Type	Description	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
V	Input	LREAL	The x variable of $y := mx + b$.	LREAL#0.0
V	CalX1	LREAL	Datapoint specifying a line along which data is to be scaled.	LREAL#0.0
V	CalY1	LREAL	Datapoint specifying a line along which data is to be scaled.	LREAL#0.0
V	CalX2	LREAL	Datapoint specifying a line along which data is to	LREAL#0.0




			be scaled.	
V	CalY2	LREAL	Datapoint specifying a line along which data is to be scaled.	LREAL#0.0
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
V	Output	LREAL	The result of the calculation $y:=mx + b$.	
V	m	LREAL	The calculated slope of the line.	
V	b	LREAL	The calculated intercept of the line.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	

Error Description


ErrorID	Meaning
<u>0</u>	No error
<u>10075</u>	Calibration Error: Cal_X2 must be greater than Cal_X1

Example





Sweep



This function block generates an output that rises and falls between the minimum and maximum outputs specified by the inputs. The OutputValue is the changed by the Increment input. This function block is useful for testing purposes by forcing other portions of application code to be tested with a full range of expected values.

Parameters



* _	Parameter	Data Type	Description	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
B	StartValue	LREAL	The OutputValue will start from this value	LREAL#0.0
B	Increment	LREAL	The amount by which the Outputvalue is changed each scan	LREAL#0.0
B	Minimum	LREAL	The minimum value output	LREAL#0.0
B	Maximum	LREAL	The maximum value output	LREAL#0.0
VAR_OUTPUT				
B	Valid	BOOL	Indicates if the function is operating normally	
B	OutputValue	LREAL	The output of the function	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	

Error Description

No errors will be generated.




Example:





UnpackByte



This function block converts a byte into discrete bits.

Parameters


*	Parameter	Data Type	Description	
VAR_INPUT				Default
B	InputByte	BYTE	The input data to be separated into bits.	BYTE#0
VAR_OUTPUT				
V	Bit0	BOOL	Bit 0 of the InputByte	
V	Bit1	BOOL	Bit 1 of the InputByte	
V	Bit2	BOOL	Bit 2 of the InputByte	
V	Bit3	BOOL	Bit 3 of the InputByte	
V	Bit4	BOOL	Bit 4 of the InputByte	
V	Bit5	BOOL	Bit 5 of the InputByte	
V	Bit6	BOOL	Bit 6 of the InputByte	
V	Bit7	BOOL	Bit 7 of the InputByte	

Error Description




No errors will be generated.

Example





UnpackWord



This function block separates a word into individual bits.

Parameters

*	Parameter	Data Type	Description	Default
VAR_INPUT				Default
B	InputWord	WORD	The input data to be separated into bits.	WORD#0




VAR_OUTPUT			
V	Bit0	BOOL	Bit 0 of the InputWord
V	Bit1	BOOL	Bit 1 of the InputWord
V	Bit2	BOOL	Bit 2 of the InputWord
V	Bit3	BOOL	Bit 3 of the InputWord
V	Bit4	BOOL	Bit 4 of the InputWord
V	Bit5	BOOL	Bit 5 of the InputWord
V	Bit6	BOOL	Bit 6 of the InputWord
V	Bit7	BOOL	Bit 7 of the InputWord
V	Bit8	BOOL	Bit 8 of the InputWord
V	Bit9	BOOL	Bit 9 of the InputWord
V	Bit10	BOOL	Bit 10 of the InputWord
V	Bit11	BOOL	Bit 11 of the InputWord
V	Bit12	BOOL	Bit 12 of the InputWord
V	Bit13	BOOL	Bit 13 of the InputWord
V	Bit14	BOOL	Bit 14 of the InputWord
V	Bit15	BOOL	Bit 15 of the InputWord

Error Description


No errors will be generated.

Example





WindowCheck



This function block sets the InWindow output high if the InputValue is within +/- (Window/2) of the TargetValue. This function is useful when making a comparison that only relies on the InputValue to be close to the Target, but an exact match is not required.

Parameters



* _	Parameter	Data Type	Description	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
V	InputValue	LREAL	The data to be tested against the TargetValue	LREAL#0.0
V	TargetValue	LREAL	The desired data to be compared against.	LREAL#0.0
V	Window	LREAL	This amount will be divided in two. The InputValue must fall within half the window distance of the TargetValue for the InWindow output to go high. Window must be greater than zero.	LREAL#0.0
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
V	InWindow	BOOL	Indicates that the InputValue is within the TargetValue +/- (Window/2) inclusive.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	

Error Description




ErrorID	Meaning
0	No error
10076	WindowSize must be greater than zero.

Example





XYLookup



This function block will do a binary search on the XYdata to find the X value, then output the corresponding Y value. This function will perform linear interpolation if the X value is between two data points in the XYData and calculate the appropriate Y value.

Parameters

*_	Parameter	Data Type	Description	
VAR_IN_OUT				
V	XYData	XYDataStruct	An array of X & Y data pairs	
VAR_INPUT				Default
B	Enable	BOOL	The function will continue to execute while enable is held high.	FALSE
V	X	LREAL	The input reference	
VAR_OUTPUT				
B	Valid	BOOL	Indicates that the outputs of the function are valid.	
V	Y	LREAL	The resulting output that relates the input.	
B	Error	BOOL	Set high if error has occurred during the execution of the function block. This output is cleared when 'Execute' or 'Enable' goes low.	
B	ErrorID	UINT	If Error is true, this output provides the Error ID. This output is reset when 'Execute' or 'Enable' goes low.	

Error Description



ErrorID	Meaning
0	No error
10038	CamData.LastSegment must be greater than 0 and less than 400, or whatever value has been declared as the ARRAY size in the CTB_Types file.


Example

The XY_Data structure was initialized as:

```

1      1.0000000 XY_Data.Pair[0].X := LREAL#1.0;
2      10.0000000 XY_Data.Pair[0].Y := LREAL#10.0;
3      2.0000000 XY_Data.Pair[1].X := LREAL#2.0;
4      20.0000000 XY_Data.Pair[1].Y := LREAL#20.0;
5      3.0000000 XY_Data.Pair[2].X := LREAL#3.0;
6      30.0000000 XY_Data.Pair[2].Y := LREAL#30.0;
7      2 XY_Data.LastPair := INT#2;

```





Function Block ErrorID List

ErrorID	Description
0	No error
1	Time limit exceeded
2	Distance limit exceeded
3	Torque limit exceeded
Motion State Error	
4369	The move could not be buffered because the axis motion queue is full. 16 moves is the maximum which can be buffered.
4370	The move could not be started because motion is prohibited. The drive may not be enabled. MC_Power.Enable_Positive or MC_Power.Enable_Negative might be low. Check MC_Power.Status output. MC_Stop.Execute might be held high, preventing motion.
4371	The servo drive failed to enable or disable. Check the amplifier wiring for L1 / L2 / L3
4375	CamOut called while not camming.
4376	The master slave relationship can not be modified because the master axis has not been set yet.
4377	File reading already in progress
4378	The function block is not applicable for the external axis specified
4379	A homing sequence is already in progress.
4380	MC_SetPosition can not be executed while the axis is moving.
4381	Motion aborted due to axis alarm. It is also possible that a software limit has been exceeded.
4382	When the axis is in rotary mode, and the MC_SetPosition tries to set a position that is equal to or greater than the MachineCycle, this error is generated, and the position is not set.
4383	Axis must be commanded at standstill when homing is attempted.
4390	Position cannot be defined while the axis is the cam master of other axes.
4391	The function block cannot be used with a virtual axis.
4394	More than 10 Y_CamIn, Y_CamOut, or MC_GearInPos function blocks for a given axis are active at the same time. Most likely the application program is not coded correctly, and the Execute input is being fired too frequently.
4395	Window parameters are outside of the cams Machine Cycle. (0 to Prm1502, the last master position in the active cam table.)
4396	Axis latch function already in use.
4397	Over travel limit still ON after attempting to move away from it.
4399	The L1 / L2 / L3 power inputs on the drive may not be supplied with power, possibly due to an E-Stop condition.
4400	The Safety input (HHB) is preventing the drive from enabling.
4401	Axis latch function already in use.
4402	The scan compensation delay parameter 1305 is only valid for external encoders.
4403	The High Speed Output functionality is only available on external encoders.
4404	Can not execute MC_GearOut because axis is not in gear.



4405	Y_CamOut was aborted.
4406	Continuous Latch Mode not supported on Sigma II, Sigma III, or external encoders
4407	Internal buffer overflow
4408	PatternSize is out of range (1-8) or PatternCount is out of range (0-255)
4409	Parameter write in progress.
4410	Parameter is read-only.
4411	Parameter read in progress.
4412	Parameter not supported for this axis.
4413	The Stepper axis does not support the mode of motion commanded
4414	MECHATROLINK Communications to the drive was disrupted. Execute MC_Reset to restore the connection.
Invalid Structure Value	
4624	Axis latch function already in use.
4625	Axis ID does not correspond to an axis configured on the system. Verify the value of AxisNum matches a logical axis number in the configuration. Tip: Make sure AXIS_REF is properly declared as a VAR or VAR_GLOBAL in all relevant POU's.
4626	The master slave relationship is defined. A slave cannot be a master to another axis.
4630	Trigger reference is not valid
4633	Table size results in misaligned data. Refer to the help section "Internally Created Cam Data." A cam table will have a multiple of 16 bytes if created correctly.
4634	Buffer size results in misaligned data
4635	Table type is not supported
4636	Invalid start index.
4637	Invalid end index
Invalid Enumeration Type	
4641	Buffer mode does not correspond to a valid enumeration value.
4642	Direction does not correspond to a valid enumeration value.
4643	Start mode does not correspond to a valid enumeration value.
4646	Mode does not correspond to a valid enumeration value.
4648	The parameter number does not exist for the specified axis
4649	Invalid adjust mode
4650	'RampIn' does not correspond to a valid enumeration value.
4651	'ControlMode' does not correspond to a valid enumeration value.
4652	'EndMode' does not correspond to a valid enumeration value.
Range Error	
4657	Distance parameter is less than or equal to zero.
4658	Velocity parameter is less than or equal to zero.
4659	Acceleration is less than or equal to zero.
4660	Deceleration is less than or equal to zero.
4663	Specified time was less than zero.
4665	Velocity parameter is negative.



4667	Jerk is less than or equal to zero.
4669	Engage position is outside the cam table domain.
4670	Engage window is less than zero.
4671	Disengage position is outside the cam table domain.
4672	Negative Disengage Window.
4673	StartPosition is outside of master's range.
4674	EndPosition is outside of master's range.
4677	Array size too large.
4678	Buffer array index out of range.
Invalid Input Data	
4881	The specified Pn does not exist.
4882	The mask does not correspond to valid tracks.
4883	The profile must start with relative time equal to zero, and the time must be increasing.
4884	The specified cam file does not exist.
4885	Invalid header for the cam file. Cam tables must have a header indicating the number of rows, number of columns and a feed forward velocity flag.
4887	CamTableID does not refer to a valid cam table.
4891	The slave axis can not be the same as the master axis.
4893	The specified external axis may not be used. A physical axis is required.
4894	The specified virtual axis may not be used with this function block.
4895	File extension is not recognized or missing.
4896	Could not find the axis parameter file.
4897	The drive's model number or type does not match the parameter file.
4898	No filter configured for axis.
4899	Axis position compensation file not found.
4900	Invalid axis position compensation file format.
4901	Cannot enable/disable axis position compensation while servo on.
4902	Invalid compensation table wrap range
Y_DeviceComm ErrorIDs	
8705	The maximum number of concurrently open user IO devices (sockets/files) has been reached.
8706	The socket handle was invalid.
8707	The IP address string was not in a valid format.
8708	The socket could not be created.
8709	The specified address or port is already in use on the local network.
8710	The specified address or port is not available for use.
8711	Unable to accept new socket connection.
8712	Unable to bind to the specified address.
8713	The socket type argument was invalid.
8714	The local address or port was not valid.



8715	The socket could not be connected.
8716	There is no network routing path to the specified address.
8717	The socket is already connected to another endpoint.
8718	The socket connection attempt was actively refused by the remote peer.
8719	The socket was not connected to a remote endpoint. Call Y_ConnectSocket prior to Y_ReadDevice or Y_WriteDevice.
8720	An error occurred trying to get or set the device option.
8721	The communication device could not be read.
8722	The communication device could not be written.
8723	The Buffer argument to WriteDevice and ReadDevice is required.
8724	The device option ID was invalid.
8725	The device option value was not the right size or the data was out of range.
8726	The serial port ID was not a valid serial port.
8727	The serial port could not be opened.
Toolbox ErrorIDs	
10020	ProductSize cannot be less than or equal to zero
10021	Maximum allowed consecutive missed registration marks reached
10022	Product or circular buffer overrun / full
10023	Buffer size too small / cannot be zero
10024	DataSize must be greater than zero
10025	Might be crossed or the same non-zero value
10026	Positive Position Limit must be greater than Negative Position Limit
10027	Negative Position Limit must be less than Positive Position Limit.
10028	Positive Velocity Limit must be LREAL#0.0 or greater.
10029	Negative Velocity Limit must be LREAL#0.0 or lower.
10030	Positive Acceleration Limit must be greater than 0.
10031	Negative Acceleration Limit must be less than 0.
10032	Positive Deceleration Limit must be greater than 0.
10033	Negative Deceleration Limit must be less than 0.
10034	Interpolation calculation error.
10035	Gripper Close Error (Timeout)
10036	Gripper Open Error (Timeout)
10037	Offset cannot be in the same direction as the original motion into the limit switch.
10038	CamData.LastSegment must be greater than 0 and less than 400, or whatever value has been declared as the ARRAY size in the CTB_Types file.
10039	Cam Segment 'Resolution' cannot be zero unless the CurveType is TB_CurveType#StraightLine..
10040	Curve Type selected in a segment is not valid.
10041	Total pairs required would exceed DataType definition for MS_Array_Type based on number of segments and resolution settings in CamData.
10042	Master must be always increasing from segment to segment.



10043	Tangent Match formula error, cannot have only one segment.
10044	Tangent Blend error, must have two segments, a straight line and a Tangent Blend, in either order.
10045	SlavePosition not found in Y_MS_CAM_STRUCT
10046	Both cam tables must have the same number of point to be added together.
10047	Both tables must have the same master cycle to be added together.
10048	The IndexSpeed is less than 20.
10049	Frequency cannot be less than 1 Hz.
10050	The dwell cannot be greater than the IndexTime.
10051	There must be a whole number of oscillations in an index at a given speed.
10052	There is a discrepancy between the master values in Profile1 and Profile 2. At the same pair somewhere in the table, the masters have values differing by more than 1 user unit.
10053	DataPoint Error
10054	One of the segments in the path has an invalid Segment Type. Path.Data[Segment].SegmentType must be coded as either being a line (INT#1) or an arc (INT#2).
10055	The absolute sum of the motion for all axes relative travel from the previous segment cannot be zero. One axis must always be in motion from segment to segment, otherwise the virtual master distance cannot be calculated.
10056	Arc Error
10057	Point Error
10058	The start angle must be a value from 0.0 to 360.0 degrees
10059	The axes got out of sync during the path motion. All Cam Slaves InSync output must be on or off at the same time, or this ErrorID is generated.
10060	The axis must be configured as a rotary type for this function block to be applicable.
10061	MasterType is something other than 0 or 1.
10062	MachineCycle must be a positive value if MasterType = 0
10063	LastSwitch is set outside the 0-255 range.
10064	Track Number outside the 0-31 range.
10065	FirstOnPosition is not equal to 0.
10066	LastOnPosition is not equal to 0.
10067	AxisDirection is not equal to 0.
10068	CamSwitchMode is not equal to 0.
10069	Duration is set to 0 or a negative value.
10070	OnCompensationScaler is set to an invalid value.
10071	OffCompensationScaler is set to an invalid value.
10072	ImproperOnPos_SetError
10073	OnOffPosition_Error
10074	Direction must be 0 for positive, or 2 for negative.
10075	Calibration Error: Cal_X2 must be greater than Cal_X1
10076	WindowSize must be greater than zero.



10077	Cubic Spline maximum number of consecutive segments exceeded. DataType definition for the Matrix could be increased if necessary.
10078	Formula 27 Error is reserved for errors with circle calculations.
10079	When using UserNoDwellModifiedConstant Velocity, there must be three contiguous segments with the same formula code applied, and the master percentages must be increasing.
10080	Formula 29 error.
10081	ControlData.DecisionPosition
10082	Mode Error. ControlData.Mode can only be 1 (one way cam) or 2 (two way cam).
10083	Unsupported Cubic Spline Sequence
10084	One of the Cam Tables has an invalid TableID
10086	MaxPosCorrection must be zero or positive, MaxNegCorrection must be or zero or negative.
10100	Both axes must be configured for the same axis type (Rotary / Linear) and if Rotary, they must have the same Machine Cycle
10110	Too many tabs specified.
10111	Pitch between labels would be negative, need more spacing between tabs
10112	Tab mode must be specified as 1 (Tabbing) or 2 (Stamp).
10114	Incorrect cam table size (check the CamTable.Header.Datasize)
10116	Problem converting string data to the output buffer
10117	String Conversion Error already exists on the controller. Clear the alarm and try again.
10118	STRING_TO_BUF Conversion Error
10119	In the Data Structure, rows must be set greater than zero and columns must be set greater than zero.
10120	File could not be opened.
10121	CSV file contains an unsupported version.
10123	Column Start Error. The data is corrupted.
10124	Unsupported Case condition.
10125	Conversion Error. Check the ErrorRow and ErrorCol outputs for details
10126	NoDataError - The End Of File was reached, but the record count is zero
10127	TooManyRecords - DataType is not large enough
10128	MaxNotDefined - User must set the maximum number of records that can be added to structure.
10129	No Carriage return found in CSV buffer. The function searched the file for twice the length of the specified buffer and was unable to find a carriage return indicating the end of a row. Either the buffer size is too small, or the data is invalid.
10130	The center to co-ordinate distance for the two input co-ordinates are not the same
10131	Zero radius is invalid
10132	Only modes 0 (center + 2 co-ordinates) and 1 (radius + 2 coordinates) are supported
10133	The coordinates of the two data points are the same
10140	Must be greater than zero and less than 20
10150	Theta1 Below Minimum.



Toolboxes Function Block ErrorID List



10151	Theta1 Above Maximum
10152	Theta2 Below Minimum
10153	Theta2 Above Maximum
10154	Imaginary ChordHeight (impossible for mechanism)
10155	Maximum Compression Reached (Mechanism squats too deeply)
10156	Locked Leg at Knee Joint B (Link2-Link3)
10157	Locked Leg at Knee Joint D (Link1-Link4)
10160	CommandString length is invalid
10161	Invalid CommandCode
10162	Parameter being searched for is out of range
10163	Mode input not valid
10164	Invalid character position input
12000	Read response timeout, no response was received within the supplied TimeOut
12010	Not a response (QR should be 1 but it was 0)
12011	Response was truncated because it extended beyond the 512byte UDP packet size
12012	Recursive is not available but was requested by the Query packet
12021	Format error, the name server was unable to interpret the query
12022	Server failure, the name server was unable to process the query due to an internal problem
12023	Name error, not valid for this block (only valid for Authoritative servers)
12030	Address length was less than 3 characters which is not possible
12031	Address format was incorrect as it does not contain a '.'
12100	Connect to SMTP server timeout, no connection was established within the supplied TimeOut
12101	DATA portion of e-mail was not successful and therefore the e-mail may not send/be malformed
12102	QUIT error, there was an error sending the 'QUIT' command to the server
12103	NumRcpt cannot equal 0.
12200	Connect to FTP server timeout, no connection was established within the supplied TimeOut
12201	Connect to FTP data socket timeout, no connection was established within the supplied TimeOut
12202	QUIT error, there was an error sending the 'QUIT' command to the server
12203	The credentials for the FTP server were incorrect (either one or both username and password)
12300	File Error, no error information available
12301	Invalid file handle
12302	Maximum number of files are already opened
12304	File is already opened
12305	File is write protected or access denied
12306	File name not defined
12310	End of data reached
12312	The number of characters to be read from file is greater than the data buffer



Toolboxes Function Block ErrorID List



12322	No data could be read from file
12421	Service not available, closing control connection. This may be a reply to any command if the service knows it must shut down.
12425	Can't open data connection.
12426	Connection closed; transfer aborted.
12430	Invalid username or password
12434	Requested host unavailable
12450	Requested file action not taken / Requested mail action not take (mailbox unavailable)
12451	Requested action aborted. Local error in processing
12452	Requested action not taken, insufficient storage space in system (FTP: File unavailable)
12500	Syntax error, command unrecognised
12501	Syntax error in parameters or arguments
12502	Command not implemented
12503	Bad sequence of commands
12504	Command not implemented for that parameter
12521	[domain] does not accept mail
12530	Not logged in / Access denied
12532	Need account for storing files
12550	Requested action not taken. File unavailable (e.g., file not found, no access) / Mailbox unavailable
12551	Requested action aborted. Page type unknown / User not local
12552	Requested file action aborted, exceeded storage allocation / Requested mail action aborted, exceeded storage allocation
12553	Requested action not taken, file name not allowed / mailbox name not allowed
12554	Transcation failed
12560	Invalid Equipment Module number
12561	Equipment Module not enable in the system
12562	Invalid number of enabled Control Modules in selected Equipment Module
12563	Time rollover warning
Axis Error	
40960	RESERVED
45332	Sending clear alarms command to servo drive failed.
45335	Failed to initialize absolute encoder.
Operating System Error	
57620	The DataType connected to a function block parameter specified as ANY type does not match the required data size. Right click on the function block and select "Object Properties" to determine which parameters are ANY type.
Kernel Error	
61713	An internal assertion in the motion kernel failed indicating the controller is not in a stable state. Please report this error to Yaskawa America Incorporated.

Please refer to the following manuals for details regarding servo amplifier errors:

MotionWorks IEC61131-3 Toolboxes: 2013-09-13



Toolboxes Function Block ErrorID List



- Sigma II with NS115: [SIEPC71080001](#), see section 9.3
- Sigma III: [YEA-SIA-S800-11](#), see section 10.1.4
- Sigma-5 with rotary motor: [SIEPS8000043](#), see Section 6.1
- Sigma-5 with linear motor: [SIEPS8000044](#), see Section 6.1