

MOTOMAN-MPL80 INSTRUCTIONS

**TYPE: YR-MPL0080-A00 (STANDARD SPECIFICATION)
YR-MPL0080-A01 (WITH LIMIT SWITCHES FOR S-, L-, U-AXES)**

Upon receipt of the product and prior to initial operation, read these instructions thoroughly, and retain for future reference.

MOTOMAN INSTRUCTIONS

- MOTOMAN-MPL80 INSTRUCTIONS
- DX 100 INSTRUCTIONS
- DX 100 OPERATOR'S MANUAL
- DX100 MAINTENANCE MANUAL

The DX 100 operator's manual above corresponds to specific usage.
Be sure to use the appropriate manual.

Part Number: 157283-1CD
Revision: 4

Copyright © 2015, Yaskawa America, Inc. All Rights Reserved.



MANDATORY

- This instruction manual is intended to explain mainly on the mechanical part of the MOTOMAN-MPL80 for the application to the actual operation and for proper maintenance and inspection. It describes on safety and handling, details on specifications, necessary items on maintenance and inspection, to explain operating instructions and maintenance procedures. Be sure to read and understand this instruction manual thoroughly before installing and operating the manipulator.
- General items related to safety are listed in the Chapter 1: Safety of the DX 100 instructions. To ensure correct and safe operation, carefully read the DX 100 instructions before reading this manual.



CAUTION

- Some drawings in this manual are shown with the protective covers or shields removed for clarity. Be sure all covers and shields are replaced before operating this product.
- The drawings and photos in this manual are representative examples and differences may exist between them and the delivered product.
- YASKAWA may modify this model without notice when necessary due to product improvements, modifications, or changes in specifications.
If such modification is made, the manual number will also be revised.
- If your copy of the manual is damaged or lost, contact a YASKAWA representative to order a new copy. The representatives are listed on the back cover. Be sure to tell the representative the manual number listed on the front cover.
- YASKAWA is not responsible for incidents arising from unauthorized modification of its products. Unauthorized modification voids your product's warranty.

Notes for Safe Operation

Read this manual carefully before installation, operation, maintenance, or inspection of the MOTOMAN-MPL80.

In this manual, the Notes for Safe Operation are classified as “DANGER”, “WARNING”, “CAUTION”, “MANDATORY”, or “PROHIBITED”.



DANGER

Indicates an imminent hazardous situation which, if not avoided, could result in death or serious injury to personnel.



WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury to personnel.



CAUTION

Indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury to personnel and damage to equipment. It may also be used to alert against unsafe practices.



MANDATORY

Always be sure to follow explicitly the items listed under this heading.



PROHIBITED

Must never be performed.

Even items described as “CAUTION” may result in a serious accident in some situations.

At any rate, be sure to follow these important items.



To ensure safe and efficient operation at all times, be sure to follow all instructions, even if not designated as “DANGER”, “WARNING” and “CAUTION”.



DANGER

- Maintenance and inspection must be performed by specified personnel.
- Failure to observe this caution may result in electric shock or injury.
- For disassembly or repair, contact your Yaskawa representative.
- Do not remove the motor, and do not release the brake.

Failure to observe these safety precautions may result in death or serious injury from unexpected turning of the manipulator's arm.



WARNING

- Before operating the manipulator, check that servo power is turned OFF pressing the emergency stop buttons on the front door of the DX100 and the programming pendant. When the servo power is turned OFF, the SERVO ON LED on the programming pendant is turned OFF.

Injury or damage to machinery may result if the emergency stop circuit cannot stop the manipulator during an emergency. The manipulator should not be used if the emergency stop buttons do not function.


Figure 1: Emergency Stop Button



- Once the emergency stop button is released, clear the cell of all items which could interfere with the operation of the manipulator. Then turn the servo power ON.

Injury may result from unintentional or unexpected manipulator motion.

Figure 2: Release of Emergency Stop



- Observe the following precautions when performing teaching operations within the P-point maximum envelope of the manipulator:
 - Be sure to lock out the safeguarding when going inside. Also, display the sign that the operation is being performed inside the safeguarding and make sure no one closes the safeguarding.
 - View the manipulator from the front whenever possible.
 - Always follow the predetermined operating procedure.
 - Keep in mind the emergency response measures against the manipulator's unexpected motion toward you.
 - Ensure that you have a safe place to retreat in case of emergency.

Improper or unintended manipulator operation may result in injury.

- Confirm that no person is present in the P-point maximum envelope of the manipulator and that you are in a safe location before:
 - Turning ON the power for the DX100.
 - Moving the manipulator with the programming pendant.
 - Running the system in the check mode.
 - Performing automatic operations.

Injury may result if anyone enters the P-point maximum envelope of the manipulator during operation. Always press an emergency stop button immediately if there is a problem.

The emergency stop buttons are located on the right of front door of the DX100 and the programming pendant.



CAUTION

- Perform the following inspection procedures prior to conducting manipulator teaching. If problems are found, repair them immediately, and be sure that all other necessary processing has been performed.
 - Check for problems in manipulator movement.
 - Check for damage to insulation and sheathing of external wires.
- Always return the programming pendant to the hook on the cabinet of the DX100 after use.

The programming pendant can be damaged if it is left in the manipulator's work area, on the floor, or near fixtures.

- Read and understand the Explanation of Warning Labels in the DX100 Instructions before operating the manipulator:

Definition of Terms Used Often in This Manual

The MOTOMAN is the YASKAWA industrial robot product.

The MOTOMAN usually consists of the manipulator, the controller, the programming pendant, and supply cables.

In this manual, the equipment is designated as follows:

Equipment	Manual Designation
DX100 controller	DX100
DX100 programming pendant	Programming pendant
Cable between the manipulator and the controller	Manipulator cable

Registered Trademark

In this manual, names of companies, corporations, or products are trademarks, registered trademarks, or brand names for each company or corporation. The indications of (R) and TM are omitted.


Explanation of Warning Labels

The following warning labels are attached to the manipulator.

Always follow the warnings on the labels.

Also, an identification label with important information is placed on the body of the manipulator. Prior to operating the manipulator, confirm the contents.

Figure 3: Warning Label Locations



Nameplate:

MOTOMAN	
TYPE	
□□□□□□	
PAYLOAD	MASS
□□ kg	□□□ kg
ORDER NO.	DATE
□□□□□□	□□
SERIAL NO.	
□□□□□□	
YASKAWA ELECTRIC CORPORATION JAPAN	

WARNING Label A:



WARNING Label B:



Table of Contents

1	Product Confirmation	1-1
1.1	Contents Confirmation	1-1
1.2	Order Number Confirmation.....	1-2
2	Transport.....	2-1
2.1	Transport Method.....	2-1
2.1.1	Using a Crane.....	2-2
2.1.2	Using a Forklift.....	2-3
2.2	Shipping Bolts and Brackets.....	2-3
3	Installation.....	3-1
3.1	Installation of the Safeguarding	3-2
3.2	Mounting Procedures for Manipulator Base.....	3-2
3.2.1	Mounting Example	3-3
3.2.2	When the Manipulator is Mounted Directly on the Floor.....	3-4
3.3	Protection Class.....	3-5
3.4	Location	3-5
4	Wiring.....	4-1
4.1	Grounding.....	4-1
4.2	Cable Connection	4-2
4.2.1	Connection to the Manipulator.....	4-2
4.2.2	Connection to the DX100.....	4-3
5	Basic Specifications	5-1
5.1	Basic Specifications.....	5-1
5.2	Part Names and Working Axes.....	5-2
5.3	Baseplate Dimensions	5-2
5.4	Dimensions and P-Point Maximum Envelope.....	5-3
5.5	B-Axis Operating Range	5-4
5.6	Alterable Operating Range	5-5
6	Allowable Load for Wrist Axis and Wrist Flange	6-1
6.1	Allowable Wrist Load	6-1
6.2	Wrist Flange.....	6-2

7	System Application	7-1
7.1	Peripheral Equipment Mounts	7-1
7.2	Internal User I/O Wiring Harness and Air Line.....	7-2
8	Electrical Equipment Specification.....	8-1
8.1	Location of Limit Switch	8-1
8.2	Internal Connections.....	8-2
9	Maintenance and Inspection.....	9-1
9.1	Inspection Schedule	9-1
9.2	Notes on Maintenance Procedures	9-6
9.2.1	Battery Pack Replacement.....	9-6
9.3	Notes on Grease Replenishment/Exchange Procedures	9-8
9.3.1	Grease Replenishment/Exchange for S-Axis Speed Reducer	9-8
9.3.1.1	Grease Replenishment.....	9-9
9.3.1.2	Grease Exchange	9-10
9.3.2	Grease Replenishment/Exchange for L-Axis Speed Reducer.....	9-11
9.3.2.1	Grease Replenishment.....	9-11
9.3.2.2	Grease Exchange	9-12
9.3.3	Grease Replenishment/Exchange for U-Axis Speed Reducer.....	9-13
9.3.3.1	Grease Replenishment.....	9-13
9.3.3.2	Grease Exchange	9-14
9.3.4	Grease Replenishment for B- and T-Axis Gears	9-15
9.3.4.1	Grease Replenishment.....	9-15
9.3.4.2	Grease Exchange	9-16
9.3.5	Grease Replenishment for B- and T-Axis Speed Reducers and Gears	9-17
9.3.5.1	Grease Replenishment.....	9-17
9.3.5.2	Grease Exchange	9-18
9.3.6	Notes for Maintenance	9-19
9.3.6.1	Battery Pack Connection.....	9-19
10	Recommended Spare Parts.....	10-1
11	Parts List.....	11-1
11.1	S-Axis Unit.....	11-1
11.2	L-Axis Unit	11-3
11.3	U-Axis Unit.....	11-5
11.4	B-,T-Axes Unit	11-7
11.5	Wrist Unit	11-9

1 Product Confirmation



CAUTION

- Confirm that the manipulator and the DX100 have the same order number. Special care must be taken when more than one manipulator is to be installed.

If the numbers do not match, manipulators may not perform as expected and cause injury or damage.

1.1 Contents Confirmation

Confirm the contents of the delivery when the product arrives.


Standard delivery includes the following four items (Information for the content of optional goods is given separately):

- Manipulator
- DX100
- Programing Pendant
- Manipulator Cable (between the DX100 and the Manipulator)

1.2 Order Number Confirmation

Check that the order number of the manipulator corresponds to the DX100. The order number is located on a label as shown below.

Fig. 1-1: Location of Order Number Labels



2 Transport



CAUTION

- Sling applications and crane or forklift operations must be performed by authorized personnel only.

Failure to observe this caution may result in injury or damage.

- Avoid excessive vibration or shock during transport.

The system consists of precision components. Failure to observe this caution may adversely affect performance.

2.1 Transport Method




- Check that the eyebolts are securely fastened.
- The weight of the manipulator is approximately 580 kg including the shipping bolts and brackets. Use a wire rope strong enough to withstand the weight.
- Attached eyebolts are designed to support the manipulator weight. Do not use them for anything other than transporting the manipulator.
- Mount the shipping bolts and brackets for transporting the manipulator.
- Avoid putting external force on the arm or motor unit when transporting by a crane, forklift, or other equipment. Failure to observe this instruction may result in injury.

2.1.1 Using a Crane

As a rule, the manipulator should be lifted by a crane with four wire ropes when removing it from the package and moving it. Be sure that the manipulator is fixed with the shipping bolts and brackets before transport, and lift it in the posture as shown in Fig. 2-1 "Transporting Position".


Fig. 2-1: Transporting Position



2.1.2 Using a Forklift

When using a forklift, the manipulator should be fixed on a pallet with bolts as shown in *Fig. 2-2 "Using a Forklift"*. Insert claws under the pallet and lift it. The pallet must be strong enough to support the manipulator. Transport the manipulator slowly with due caution in order to avoid overturning or slippage.

Fig. 2-2: Using a Forklift



2.2 Shipping Bolts and Brackets

The manipulator is provided with shipping bolts and a shipping brackets.

(See *Fig. 2-1 "Transporting Position" on page 2-2.*)

- The shipping bolts and bracket are painted yellow.



Before turning ON the power, make sure that the shipping bolts and brackets are removed. The shipping bolts and brackets then must be stored for future use, in the event that the manipulator must be moved again.

3 Installation



WARNING

- Install the safeguarding.

Failure to observe this warning may result in injury or damage.

- Install the manipulator in a location where the tool or the workpiece held by its fully extended arm will not reach the wall, safeguarding, or controller.

Failure to observe this warning may result in injury or damage.

- Do not start the manipulator or even turn ON the power before it is firmly anchored.

The manipulator may overturn and cause injury or damage.



CAUTION

- Do not install or operate a manipulator that is damaged or lacks parts.

Failure to observe this caution may cause injury or damage.

- Before turning ON the power, check to be sure that the shipping bolts and brackets are removed.

Failure to observe this caution may result in damage to the driving parts.

3.1 Installation of the Safeguarding

To insure safety, be sure to install safeguarding. It prevents unforeseen accidents with personnel and damage to equipment. Refer to the quoted clause for your information and guidance.

Responsibility for Safeguarding (ISO10218)

The user of a manipulator or robot system shall ensure that safeguarding is provided and used in accordance with Sections 6, 7, and 8 of this standard. The means and degree of safeguarding, including any redundancies, shall correspond directly to the type and level of hazard presented by the robot system consistent with the robot application. Safeguarding may include but not be limited to safeguarding devices, barriers, interlock barriers, perimeter guarding, awareness barriers, and awareness signals.

3.2 Mounting Procedures for Manipulator Base

The manipulator should be firmly mounted on a baseplate or foundation strong enough to support the manipulator and withstand repulsion forces during acceleration and deceleration.

Construct a solid foundation with the appropriate thickness to withstand maximum repulsion forces of the manipulator referring to *Table 3-1 "Maximum Repulsion Forces of the Manipulator at Emergency Stop"* and *Table 3-2 "Endurance Torque in Operation"*.

A baseplate flatness must be kept at 0.5 mm or less: insufficient flatness of installation surface may deform the manipulator shape and affect its functional abilities.

Mount the manipulator base as instructed in *section 3.2.1 "Mounting Example" on page 3-3* or *section 3.2.2 "When the Manipulator is Mounted Directly on the Floor" on page 3-4*.

Table 3-1: Maximum Repulsion Forces of the Manipulator at Emergency Stop

Maximum torque in horizontal rotation (S-axis moving direction)	24500 N•m (2500 kgf•m)
Maximum torque in vertical rotation (L-, U-axes moving direction)	45080 N•m (4600 kgf•m)

Table 3-2: Endurance Torque in Operation

Endurance torque in horizontal operation (S-axis moving direction)	6125 N•m (625 kgf•m)
Endurance torque in vertical operation (L-, U-axes moving direction)	11270 N•m (1150 kgf•m)

3.2.1 Mounting Example


For the first process, anchor the baseplate firmly to the ground. The baseplate should be rugged and durable to prevent shifting of the manipulator or the mounting fixture. It is recommended to prepare a baseplate of 50 mm or more thick, and anchor bolts of M20 or larger size.

Next, fix the manipulator base to the baseplate. The manipulator base is tapped for eight mounting holes; securely fix the manipulator base to the baseplate with hexagon head screws M20 (70 mm long is recommended).

Tighten the hexagon head screws and anchor bolts firmly so that they will not work loose during the operation.

Refer to Fig. 3-1 "Mounting the Manipulator Baseplate".


Fig. 3-1: Mounting the Manipulator Baseplate



3.2.2 When the Manipulator is Mounted Directly on the Floor

The floor should be strong enough to support the manipulator. Construct a solid foundation with the appropriate thickness to withstand maximum repulsion forces of the manipulator. As a rough standard, when there is a concrete thickness (floor) is 200 mm or more, the manipulator base can be fixed directly to the floor with M 20 anchor bolts. Before mounting the manipulator, however, check that the floor is level and that all cracks, etc. are repaired. Any thickness less than 200 mm is insufficient for mounting, even if the floor is concrete.

Fig. 3-2: Direct Mounting on the Floor



Bolt A: Bolt M20 X 70 mm (8 bolts), Spring Washer, Flat Washer
 Bolt B: Bolt M24 X 70 mm (4 bolts), Spring Washer, Flat Washer
 Tightening bolts or bases are prepared by the customer.

Units: mm

3.3 Protection Class

The protection class at the main part conforms to IP54 and that of wrist part is IP67.

3.4 Location

When installing a manipulator, it is necessary to satisfy the following environmental conditions:

- Ambient Temperature: 0° to +45°C
- Humidity: 20 to 80%RH (non-condensing)
- Free from dust, soot, oil, or water
- Free from corrosive gas or liquid, or explosive gas or liquid.
- Free from excessive vibration (4.9 m/s² [0.5G] or less)
- Free from large electrical noise (plasma)
- The flatness for installation is 0.5 mm or less

4 Wiring



WARNING

- Ground resistance must be 100 Ω or less.
Failure to observe this warning may result in fire or electric shock.
- Before wiring, make sure to turn the primary power supply off, and put up a warning sign. (ex. DO NOT TURN THE POWER ON.)
Failure to observe this warning may result in fire or electric shock.



CAUTION

- Wiring must be performed by authorized or certified personnel.
Failure to observe this caution may result in fire or electric shock

4.1 Grounding


Follow the local regulations and electrical installation standards for grounding. A wire of 5.5 mm² or more is recommended.

Refer to Fig. 4-1 "Grounding Method" to connect the ground line directly to the manipulator.



- Never use this wire sharing with other ground lines or grounding electrodes for other electric power, motor power, welding devices, etc.
- Where metal ducts, metallic conduits, or distributing racks are used for cable laying, ground in accordance with electrical installation standards.

Fig. 4-1: Grounding Method



4.2 Cable Connection

Two manipulator cables are delivered with the manipulator; an encoder cable (1BC) and a power cable (2BC). (Refer to *Fig. 4-2 "Manipulator Cables" on page 4-3.*)

Connect these cables to the manipulator base connectors and to the DX100. Refer to *Fig. 4-3(a) "Manipulator Cable Connectors (Manipulator Side)" on page 4-4* and *Fig. 4-3(b) "Manipulator Cable Connectors (DX100 Side)" on page 4-4.*

4.2.1 Connection to the Manipulator

Before connecting cables to the manipulator, verify the numbers on both manipulator cables and the connectors on the connector base of the manipulator. When connecting, adjust the cable connector positions to the main key positions of the manipulator, and insert cables in the order of 2BC, then 1BC. After inserting the cables, depress the lever until it clicks.

4.2.2 Connection to the DX100

Before connecting cables to the DX100, verify the numbers on both manipulator cables and the connectors on the DX100. When connecting, insert the cables in the order of X21, then X11, and depress each lever low until it clicks.

Fig. 4-2: Manipulator Cables





Fig. 4-3(a): Manipulator Cable Connectors (Manipulator Side)





Fig. 4-3(b): Manipulator Cable Connectors (DX100 Side)



5 Basic Specifications

5.1 Basic Specifications

Table 5-1: Basic Specifications¹⁾

Item	Model	MOTOMAN-MPL80
Structure		Vertically Articulated
Degree of Freedom		5
Payload		80 kg
Repeatability ^{*2)}		±0.07 mm
Range of Motion ³⁾	S-Axis (turning)	±180°
	L-Axis (lower arm)	+135°, -90°
	U-Axis (upper arm)	+251°, -170°
	B-Axis (wrist pitch/yaw)	±15° ⁴⁾
	T-Axis (wrist twist)	±360°
Maximum Speed	S-Axis	2.97rad/s, 170°/s
	L-Axis	2.97rad/s, 170°/s
	U-Axis	2.97rad/s, 170°/s
	B-Axis	2.97rad/s, 170°/s
	T-Axis	6.11 rad/s, 350°/s
Allowable Moment ⁵⁾	B-Axis	78.4 N•m (8 kgf•m)
	T-Axis	20.5N•m (2.1 kgf•m)
Allowable Inertia (GD ² /4)	B-Axis	16 kg•m ²
	T-Axis	6.1 kg•m ²
Approx. Mass		550 kg
Ambient Conditions	Temperature	0° to 45°C
	Humidity	20 to 80% RH at constant temperature
	Vibration Acceleration	Less than 4.9 m/s ² (0.5G)
	Others	Free from corrosive gas or liquid, or explosive gas or liquid. Free from water, oil, or dust. Free from excessive electrical noise (plasma).
Power Capacity		4.0 kVA

1 SI units are used in this table. However, gravitational unit is used in ().

2 Conformed to ISO9283


3 The range of motion of type:MPL0080-A01 is limited with the limit switch before shipment.

4 The range of motion of the B-axis indicates the angle to the ground. With certain postures, however, motion may be limited by the relative angle between the B-axis and the upper arm. Refer to *section 5.5 "B-Axis Operating Range"* on page 5-4.

5 Refer to *section 6.1 "Allowable Wrist Load"* on page 6-1 for details on the allowable inertia.


5.2 Part Names and Working Axes

Fig. 5-1: Part Names and Working Axes




5.3 Baseplate Dimensions

Fig. 5-2: Baseplate Dimensions



5.4 Dimensions and P-Point Maximum Envelope

Fig. 5-3: Dimensions and P-Point Maximum Envelope



5.5 B-Axis Operating Range


The operating range of the B-axis maintaining a constant angle to the center of U-axis is shown in *Fig. 5-4 "B-Axis Operating Range"*.

By "B-axis adjustable motion function", the B-axis maintains the same posture to the ground regardless of the L- or U-axis angle.

The operating range is $\pm 15^\circ$ (0 degree is defined as the angle when the wrist flange is horizontal and facing to the ground.) When the B-axis position exceeds this limit, "Special Soft Limit" occurs.

Note: In relation with interference with the upper arm, the range of motion can be limited.

Fig. 5-4: B-Axis Operating Range



5.6 Alterable Operating Range

The operating range of the S-axis can be altered in accordance with the operating conditions as shown in *Table 5-2 "S-Axis Operating Range"*. If alteration is necessary, contact your Yaskawa representative in advance.

Table 5-2: S-Axis Operating Range

Item	Specifications
S-Axis Operating Range	±180°(standard) ±165° ±150° ±135° ±120° ± 105° ± 90° ± 75° ± 60° ± 45° ± 30° ± 15°

6 Allowable Load for Wrist Axis and Wrist Flange

6.1 Allowable Wrist Load

The allowable wrist load is 80 kg. If force is applied to the wrist instead of the load, force on R-, B-, and T-axes should be within the value shown in *Table 6-1 "Allowable Wrist Load"*. Contact your Yaskawa representative for further information or assistance.

Table 6-1: Allowable Wrist Load


Axis	Moment N·m (kgf·m) ¹⁾	GD ² /4 Total Moment of Inertia kg·m ²
B-Axis	78.4 (8)	16
T-Axis	20.5 (2.1)	6

1 (): Gravitational unit

When the volume load is small, refer to the moment arm rating shown in *Fig. 6-1 "Moment Arm Rating"*.

The allowable total moment of inertia is calculated when the moment is at the maximum. Contact your Yaskawa representative beforehand when only the moment of inertia is created, or when the load moment is small while the moment of inertia is large. Also, when the load mass is combined with an outside force, contact your Yaskawa representative beforehand.


Fig. 6-1: Moment Arm Rating



6.2 Wrist Flange

The wrist flange dimensions are shown in *Fig. 6-2 "Wrist Flange"*. In order to see the alignment marks, it is recommended that the attachment be mounted inside the fitting. Fitting depth of inside and outside fittings must be 5 mm or less.

Fig. 6-2: Wrist Flange



NOTE Wash off anti-corrosive paint (yellow) on the wrist flange surface with thinner or light oil before mounting the tools.

7 System Application

7.1 Peripheral Equipment Mounts

The peripheral equipment mounts are provided on the U-axis (upper arm) and S-axis (rotary head) as shown in Fig. 7-1 "Installing Peripheral Equipment" for easier installation of the users' system applications. The following conditions should be observed to attach or install peripheral equipment.

Fig. 7-1: Installing Peripheral Equipment




Table 7-1: Conditions for Installation

Section	Application	Note
A	Cable processing	80 kg max. for attaching load mass including wrist load.
B	Cable processing and valve load	10 kg max. 49 N•m (5 kgf•m) max. for increased moment amount of upper arm
C	Others	30 kg max.



7.2 Internal User I/O Wiring Harness and Air Line

Internal user I/O wiring harness (0.5 mm² x 23 wires), and an air line are incorporated in the manipulator for the drive of peripheral device mounted on the upper arm as shown in Fig. 7-2 "Connectors for Internal User I/O Wiring Harness and Air Line" on page 7-2.

The connector pins 1 to 23 are assigned as shown in Fig. 7-2. Wiring must be performed by users.

The allowable current for internal user I/O wiring harness	5.1A or less for each wire (The total current value for pins 1 to 23 must be 34.5A or less.)
The maximum pressure for the air line	490 kPa (5 kgf/cm ²) or less (The air line inside diameter: 8.0 mm.)

Fig. 7-2: Connectors for Internal User I/O Wiring Harness and Air Line




The same numbered pins (1 to 23) of the two connectors are connected with a single lead wire of 0.5 mm².

8 Electrical Equipment Specification

8.1 Location of Limit Switch

The limit switches are optional. See *Fig. 8-1 "Location of Limit Switches"*. The overrun limit switches (the S- and L-axis overrun limit switches and the LU-axes interference limit switch) are mounted only if the manipulator type is : YR-MPL0080-A01.

Fig. 8-1: Location of Limit Switches



8.2 Internal Connections

Highly reliable connectors are equipped on each connection part of the manipulator to enable easy removal and installation for maintenance and inspection. For the number and location of connectors, see Fig. 8-2 "Location and Numbers of Connectors" and Table 8-1 "List of Connector Types".

Diagrams for internal connections of the manipulator are shown in Fig. 8-3(a) "Internal Connection Diagram" on page 8-3 and Fig. 8-3(b) "Internal Connection Diagram" on page 8-4 .

Fig. 8-2: Location and Numbers of Connectors




Table 8-1: List of Connector Types

Name	Type of Connector
Connector for the internal user I/O wiring harness on the connector base	JL05-2A24-28PC (JL05-6A24-28S: Optional)
Connector for the internal user I/O wiring harness on the U-arm	JL05-2A24-28SC (JL05-6A24-28P: Optional)

Fig. 8-3(a): Internal Connection Diagram





Fig. 8-3(b): Internal Connection Diagram



9 Maintenance and Inspection



DANGER

- Maintenance and inspection must be performed by specified personnel.

Failure to observe this caution may result in electric shock or injury.

- For disassembly or repair, contact your Yaskawa representative.
- Do not remove the motor, and do not release the brake.

Failure to observe these safety precautions may result in death or serious injury from unexpected turning of the manipulator's arm.



WARNING

- Before maintenance or inspection, be sure to turn the main power supply OFF, and put up a warning sign. (ex. DO NOT TURN THE POWER ON.)

Failure to observe this warning may result in electric shock or injury.



CAUTION

- The battery pack must be connected before removing detection connector when maintenance and inspection.

Failure to observe this caution may result in the loss of home position data.

9.1 Inspection Schedule

Proper inspections are essential not only to assure that the mechanism will be able to function for a long period, but also to prevent malfunctions and assure safe operation. Inspection intervals are classified into six levels as shown in *Table 9-1 "Inspection Items" on page 9-2*.

In *Table 9-1 "Inspection Items" on page 9-2*, the inspection items are classified into three types of operation: operations which can be performed by personnel authorized by the user, operations to be performed by trained personnel, and operations to be performed by service company personnel. Only specified personnel shall perform the inspection work.000



- The inspection interval depends on the total servo operation time.
- The inspection may be conducted at shorter intervals if the manipulator is used very frequently for the application such as handling; in this case, contact your Yaskawa representative.

Table 9-1: Inspection Items (Sheet 1 of 2)

Items ¹⁾	Schedule					Method	Operation	Inspection Charge			
	Daily	1000HCycle	6000HCycle	12000HCycle	24000HCycle			36000HCycle	Specified Personnel	Licensee	Service Company
1	Alignment mark	●					Visual	Check alignment mark accordance at the home position. Check for damage.	●	●	●
2	External lead	●					Visual	Check for damage and deterioration of leads.	●	●	●
3	Working area and manipulator	●					Visual	Clean the work area if dust or spatter is present. Check for damage and outside cracks.	●	●	●
4	S, L, U, B, T-axes motor	●					Visual	Check for grease leakage. ²⁾	●	●	●
5	Baseplate mounting bolts		●				Spanner Wrench	Tighten loose bolts. Replace if necessary.	●	●	●
6	Cover mounting screws		●				Screwdriver, Wrench	Tighten loose bolts. Replace if necessary.	●	●	●
7	S, L, U, B, T-axes motor connector		●				Manual	Tighten loose bolts.	●	●	●
8	Connector base		●				Manual	Check for loose connectors.	●	●	●
9	Wire harness in manipulator				●		Visual Multimeter	Check for conduction between the main connector of base and intermediate connector with manually shaking the wire. Check for wear of protective spring ³⁾		●	●
						●		Replace it 24000H intervals.			●
01	Limit switches and dogs (S,L,U-axes)			●			Screwdriver, Wrench, Multimeter	Tighten loose bolts. Replace if necessary.		●	●
11	Battery pack in manipulator					●		Replace the battery pack when the battery alarm occurs or the manipulator drove for 36000H.		●	●
21	S-axis speed reducer			●	●		Grease Gun	Check for malfunction. (Replace if necessary.) ⁴⁾ Supply grease (6000H cycle) ⁵⁾ Replace grease. (12000H cycle) ⁵⁾ See section 9.3.1 on page 9-8.		●	●

Table 9-1: Inspection Items (Sheet 2 of 2)

Items ¹⁾	Schedule						Method	Operation	Inspection Charge		
	Daily	1000HCycle	6000HCycle	12000HCycle	24000HCycle	36000HCycle			Specified Personnel	Licensee	Service Company
3) LU-axes speed reducers			●	●			Grease Gun	Check for malfunction. (Replace if necessary.) ⁴⁾ Supply grease (6000H cycle) ⁵⁾ . Replace grease (12000H cycle) ⁵⁾ . See <i>section 9.3.2 on page 9-11, section 9.3.3 on page 9-13.</i>		●	●
4) B,T-axes speed reducers B,T-axes gears			●	●			Grease Gun	Check for malfunction. (Replace if necessary.) ⁴⁾ Supply grease(6000H cycle) ⁵⁾ . Replace grease(12000H cycle) ⁵⁾ . See <i>section 9.3.5 on page 9-17.</i>		●	●
5) Overhaul						●					●

1) Inspection No. correspond to the numbers in *Fig. 9-1 "Inspection Items" on page 9-4.*


2) The occurrence of a grease leakage indicates the possibility that grease has seeped into the motor. This can cause a motor breakdown. Contact your Yaskawa representative.

3) When checking for conduction with multimeter, connect the battery to "BAT" and "OBT" of connectors on the motor side for each axis, and then remove connectors on detector side for each axis from the motor. Otherwise, the home position may be lost. (Refer to *section 9.3.6 on page 9-19.*)

4) The grease might leak out from the air breather or the internal pressure might rise in case the manipulator is used very frequently for the application such as handling.

5) For the grease, refer to *Table 9-2 "Inspection Parts and Grease Used" on page 9-5.*

Fig. 9-1: Inspection Items



9-4

HW0485739

Table 9-2: Inspection Parts and Grease Used

No.	Grease Used	Inspected Parts
13,14,15,16	Molywhite RE No.00	Speed reducers for all axes B,T-axes gears

The numbers in the above table correspond to the numbers in *Table 9-1 "Inspection Items"* on page 9-2.

9.2 Notes on Maintenance Procedures

9.2.1 Battery Pack Replacement

The battery packs are installed in the position shown in *Fig. 9-2 "Battery Location"*.

- Battery Type: HW0470360-A

Fig. 9-2: Battery Location





Fig. 9-3: Battery Connection



1. Turn OFF the DX100 main power supply.
2. Remove the plate fixing screws and the plate on the connector base, then pull the battery pack out to replace it with the new one.
3. Remove the battery pack from the battery holder.
4. Connect the new battery pack to the unoccupied connectors on the circuit board.
5. Remove the old battery pack from the circuit board.



Remove the old battery pack after connecting the new one so that the encoder absolute data does not disappear.

6. Mount the new battery pack on the battery holder.
7. Reinstall the plate.



Do not allow plate to pinch the cables when reinstalling the plate.

9.3 Notes on Grease Replenishment/Exchange Procedures


Make sure to follow the instructions listed below at grease replenishment/exchange. Failure to observe the following notes may result in damage to a motor and a speed reducer.



- If grease is added without removing the plug/air breather from the grease exhaust port, grease will leak inside a motor or an oil seal of a speed reducer will come off, which may result in damage to the motor. Make sure to remove the plug/air breather.
- Do not install a joint, a hose, etc. to the grease exhaust port. Failure to observe this instruction may result in damage to the motor due to coming off of an oil seal.
- Make sure to use a grease pump to inject grease. Set air supply pressure to the grease pump at 0.3 MPa or less, and the grease injection rate at 8 g/s or less.
- Make sure to fill hoses, which are joined to the grease inlet, with grease beforehand to prevent air from intruding into the speed reducer.

9.3.1 Grease Replenishment/Exchange for S-Axis Speed Reducer

Fig. 9-4: S-Axis Speed Reducer Diagram



9.3.1.1 Grease Replenishment

(Refer to Fig. 9-4 "S-Axis Speed Reducer Diagram" on page 9-8.)

1. Remove the hexagon socket head plug PT1/4 from the grease inlet and the hexagon socket head air breather from the grease exhaust port.



- If grease is injected with the air breather on, grease will leak inside the motor and may cause a damage. Make sure to remove the air breather before the grease injection.
- Do not install a joint, a hose, etc. to the grease exhaust port. Failure to observe this instruction may result in damage to the motor due to coming off of an oil seal.

2. Install the grease zerk PT1/4 to the grease inlet. (The grease zerk is delivered with the manipulator.)
3. Inject the grease through the inlet using a grease gun.
 - Grease type: Molywhite RE No. 00
 - Amount of grease: 520 cc
(1040 cc for 1st supply)
 - Air supply pressure of grease pump: 0.3 MPa or less
 - Grease injection rate: 8 g/s or less
4. Move the S-axis for a few minutes to discharge the excess grease.
5. Wipe the discharged grease with a cloth and reinstall the air breather upward.
Before installing the air breather, apply Three Bond 1206C on the thread part of each plug.
6. Remove the grease zerk from the grease inlet and reinstall the hexagon socket head plug PT1/4.
Before installing the plug, apply Three Bond 1206C on the thread part of each plug, then tighten the plug with a tightening torque of 12 N•m (1.2 kgf•m).

9.3.1.2 Grease Exchange

(Refer to *Fig. 9-4 "S-Axis Speed Reducer Diagram" on page 9-8.*)

1. Remove the hexagon socket head plug PT1/4 from the grease inlet and the hexagon socket head air breather from the grease exhaust port.

NOTE

- If grease is injected with the air breather, the grease will leak inside the motor and may cause a damage. Make sure to remove the air breather before the grease injection.
- Do not install a joint, a hose, etc. to a grease exhaust port. Failure to observe this instruction may result in damage to the motor due to coming off of an oil seal.

2. Install the grease zerk PT1/4 to the grease inlet.
(The grease zerk is delivered with the manipulator.)
3. Inject the grease through the grease inlet using a grease gun.
 - Grease type: Molywhite RE No. 00
 - Amount of grease: approx. 2600 cc
 - Air supply pressure of grease pump: 0.3 MPa or less
 - Grease injection rate: 8 g/s or less
4. The grease exchange is complete when new grease appears from the exhaust port. (The new grease can be distinguished from the old grease by color.)
5. Move the S-axis for a few minutes to discharge the excess grease.
6. Wipe the discharged grease with a cloth and reinstall the air breather upward.
Before installing the air breather, apply Three Bond 1206C on the thread part of each plug.


NOTE

If grease is injected with the air breather on, grease will leak inside the motor and may cause a damage. Make sure to remove the air breather before the grease injection.

7. Remove the grease zerk from the grease inlet and reinstall the hexagon socket head plug PT1/4.
Before installing the plug, apply Three Bond 1206C on the thread part of each plug, then tighten the plug with a tightening torque of 12 N•m (1.2 kgf•m).

9.3.2 Grease Replenishment/Exchange for L-Axis Speed Reducer

Fig. 9-5: L-Axis Speed Reducer Diagram



9.3.2.1 Grease Replenishment

(Refer to Fig. 9-5 “L-Axis Speed Reducer Diagram”.)

1. Make the L-arm vertical to the ground.
2. Remove the hexagon socket head plug PT3/8 from the grease exhaust port.
3. Remove the hexagon socket head plug PT1/8 from the grease inlet.

NOTE

- If grease is injected with the exhaust plug on, grease will leak inside the motor and may cause a damage. Make sure to remove the plug before the grease injection.
- Do not install a joint, a hose, etc. to the grease exhaust port. Failure to observe this instruction may result in damage to the motor due to coming off of an oil seal.

4. Install the grease zerk PT1/8 to the grease inlet. (The grease zerk is delivered with the manipulator.)
5. Inject grease through the grease inlet using a grease gun.

– Grease type:	Molywhite RE No. 00
– Amount of grease:	250 cc (500 cc for 1st supply)
– Air supply pressure of grease pump:	0.3 MPa or less
– Grease injection rate:	8 g/s or less
6. Move the L-axis for a few minutes to discharge the excess grease.
7. Wipe the discharged grease with a cloth and reinstall the hexagon socket head plug PT3/8 to the exhaust port.
Before installing the plugs, apply Three Bond 1206C on the thread part of each plug, then tighten the plug with a tightening torque of 23 N•m (2.3 kgf•m).
8. Remove the grease zerk from the grease inlet and reinstall the hexagon socket head plug PT1/8 to the grease inlet.
Before installing the plug, apply Three Bond 1206C on the thread part of each plug, then tighten the plug with a tightening torque of 4.9 N•m (0.5 kgf•m).

9.3.2.2 Grease Exchange

(Refer to *Fig. 9-5 "L-Axis Speed Reducer Diagram" on page 9-11.*)

1. Make the L-arm vertical to the ground.
2. Remove the hexagon socket head plug PT3/8 from the grease exhaust port.
3. Remove the hexagon socket head plug PT1/8 from the grease inlet.



- If grease is injected with the exhaust plug on, grease will leak inside the motor and may cause a damage. Make sure to remove the plug before the grease injection.
- Do not install a joint, a hose, etc. to the grease exhaust port. Failure to observe this instruction may result in damage to the motor due to coming off of an oil seal.

4. Install the grease zerk PT1/8 to the grease inlet.
(The grease zerk is delivered with the manipulator.)
5. Inject grease through the grease inlet using a grease gun.
 - Grease type: Molywhite RE No. 00
 - Amount of grease: approx. 1650 cc
 - Air supply pressure of grease pump: 0.3 MPa or less
 - Grease injection rate: 8 g/s or less
6. The grease discharge is complete when new grease appears from the exhaust port. The new grease can be distinguished from the old grease by color.
7. Move the L-axis for a few minutes to discharge the excess grease.
8. Wipe the discharged grease with a cloth and reinstall the hexagon socket head plug PT3/8 to the exhaust port.
Before installing the plugs, apply Three Bond 1206C on the thread part of each plug, then tighten the plug with a tightening torque of 23 N•m (2.3 kgf•m).



- If grease is injected with the plug on, grease will leak inside the motor and may cause a damage. Make sure to remove the plug before the grease injection.

9. Remove the grease zerk from the grease inlet and reinstall the hexagon socket head plug PT1/8 to the grease inlet.
Before installing the plug, apply Three Bond 1206C on the thread part of each plug, then tighten the plug with a tightening torque of 4.9 N•m (0.5 kgf•m).

9.3.3 Grease Replenishment/Exchange for U-Axis Speed Reducer

Fig. 9-6: U-Arm Posture





Fig. 9-7: U-Axis Speed Reducer Diagram



9.3.3.1 Grease Replenishment

(Refer to Fig. 9-7 "U-Axis Speed Reducer Diagram".)

1. Make the U-arm horizontal to the ground.
2. Remove the hexagon socket head plug PT3/8 from the grease exhaust port.
3. Remove the hexagon socket head plug PT1/8 from the grease inlet.



- If grease is injected with the bolt on, grease will leak inside the motor and may cause a damage. Make sure to remove the bolt before the grease injection.
- Do not install a joint, a hose, etc. to the grease exhaust port. Failure to observe this instruction may result in damage to the motor due to coming off of an oil seal.

4. Install the grease zerk PT1/8 to the grease inlet. (The grease zerk is delivered with the manipulator.)
5. Inject grease through the grease inlet using a grease gun.

– Grease type:	Molywhite RE No. 00
– Amount of grease:	140 cc (280 cc for 1st supply)
– Air supply pressure of grease pump:	0.3 MPa or less
– Grease injection rate:	8 g/s or less

9 Maintenance and Inspection

9.3 Notes on Grease Replenishment/Exchange Procedures

6. Move the U-axis for a few minutes to discharge the excess grease.
7. Wipe the discharged grease with a cloth and reinstall the hexagon socket head plug PT3/8 to the exhaust port.
Three Bond 1206C on the thread part of each plug, then tighten the plug with a tightening torque of 23 N•m (2.3 kgf•m)
8. Remove the grease zerk from the grease inlet and reinstall the hexagon socket head plug PT1/8.
Before installing the plug, apply Three Bond 1206C on the thread part of each plug, then tighten the plug with a tightening torque of 4.9 N•m (0.5 kgf•m)

9.3.3.2 Grease Exchange

(Refer to Fig. 9-7 "U-Axis Speed Reducer Diagram" on page 9-13.)

1. Make the U-arm horizontal to the ground.
2. Remove the hexagon socket head plug PT3/8 from the grease exhaust port.
3. Remove the hexagon socket head plug PT1/8 from the grease inlet.



- If grease is injected with the bolt on, grease will leak inside the motor and may cause a damage. Make sure to remove the bolt before the grease injection.
- Do not install a joint, a hose, etc. to the grease exhaust port. Failure to observe this instruction may result in damage to the motor due to coming off of an oil seal.

4. Install the grease zerk PT1/8 to the grease inlet. (The grease zerk is delivered with the manipulator.)
5. Inject grease through the grease inlet using a grease gun.
 - Grease type: Molywhite RE No. 00
 - Amount of grease: approx.700 cc
 - Air supply pressure of grease pump: 0.3 MPa or less
 - Grease injection rate: 8 g/s or less
6. The grease discharge is complete when new grease appears from the exhaust port. The new grease can be distinguished from the old grease by color.
7. Move the U-axis for a few minutes to discharge the excess grease.
8. Wipe the discharged grease with a cloth and reinstall the hexagon socket head plug PT3/8 to the exhaust port.
Before installing the plug, apply Three Bond 1206C on the thread part of each plug, then tighten the plug with a tightening torque of 23 N•m (2.3 kgf•m).




- If grease is injected with the plug on, grease will leak inside the motor and may cause a damage. Make sure to remove the plug before the grease injection.

9. Remove the grease zerk from the grease inlet and reinstall the hexagon socket head plug PT1/8.
Before installing the plug, apply Three Bond 1206C on the thread part of each plug, then tighten the plug with a tightening torque of 4.9 N•m (0.5 kgf•m).

9.3.4 Grease Replenishment for B- and T-Axis Gears

Fig. 9-8: B- and T-Axis Gears Diagram



9.3.4.1 Grease Replenishment

(Refer to Fig. 9-8 "B- and T-Axis Gears Diagram".)

1. Remove the hexagon socket head plug PT3/8 from the exhaust port.

NOTE

- If grease is injected with the bolt on, grease will leak inside the motor and may cause a damage. Make sure to remove the bolt before the grease injection.
- Do not install a joint, a hose, etc. to the grease exhaust port. Failure to observe this instruction may result in damage to the motor due to coming off of an oil seal.

2. Remove the hexagon socket head plug PT1/8.
3. Inject grease through the grease inlet using a grease gun.

– Grease type:	Molywhite RE No. 00
– Amount of grease:	approx.700 cc (1400 cc for 1st supply)
– Air supply pressure of grease pump:	0.3 MPa or less
– Grease injection rate:	8 g/s or less
4. The grease discharge is complete when new grease appears from the exhaust port. The new grease can be distinguished from the old grease by color.
5. Move the B-axis for a few minutes to discharge the excess grease.
6. Wipe the discharged grease with a cloth and reinstall the hexagon socket head plug PT3/8 to the exhaust port.
 Before installing the plug, apply Three Bond 1206C on the thread part of each plug, then tighten the plug with a tightening torque of 23 N•m (2.3 kgf•m).
7. Remove the grease zerk from the grease inlet and reinstall the hexagon socket head plug PT1/8.
 Before installing the plug, apply Three Bond 1206C on the thread part of each plug, then tighten the plug with a tightening torque of 4.9 N•m (0.5 kgf•m).

9.3.4.2 Grease Exchange

(Refer to *Fig. 9-8 "B- and T-Axis Gears Diagram"* on page 9-15.)

1. Remove the hexagon socket head plug PT3/8 from the grease exhaust port.
2. Remove the hexagon socket head plug PT1/8 from the grease inlet.



- If grease is injected with the bolt on, grease will leak inside the motor and may cause a damage. Make sure to remove the bolt before the grease injection.
- Do not install a joint, a hose, etc. to the grease exhaust port. Failure to observe this instruction may result in damage to the motor due to coming off of an oil seal.

3. Install the grease zerk PT1/8 to the grease inlet. (The grease zerk is delivered with the manipulator.)
4. Inject grease through the grease inlet using a grease gun.
 - Grease type: Molywhite RE No. 00
 - Amount of grease: approx.3500 cc
 - Air supply pressure of grease pump: 0.3 MPa or less
 - Grease injection rate: 8 g/s or less
5. The grease discharge is complete when new grease appears from the exhaust port. The new grease can be distinguished from the old grease by color.
6. Move the B-axis for a few minutes to discharge the excess grease.
7. Wipe the discharged grease with a cloth and reinstall the hexagon socket head plug PT3/8 to the exhaust port.
 Before installing the plug, apply Three Bond 1206C on the thread part of each plug, then tighten the plug with a tightening torque of 23 N•m (2.3 kgf•m).




- If grease is injected with the plug on, grease will leak inside the motor and may cause a damage. Make sure to remove the plug before the grease injection.

8. Remove the grease zerk from the grease inlet and reinstall the hexagon socket head plug PT1/8.
 Before installing the plug, apply Three Bond 1206C on the thread part of each plug, then tighten the plug with a tightening torque of 4.9 N•m (0.5 kgf•m).

9.3.5 Grease Replenishment for B- and T-Axis Speed Reducers and Gears

Fig. 9-9: B- and T-Axis Speed Reducers and Gears Diagram



9.3.5.1 Grease Replenishment

(Refer to Fig. 9-9 “B- and T-Axis Speed Reducers and Gears Diagram”.)

1. Remove the hexagon socket head plug PT1/8 from the exhaust port.



- If grease is injected with the bolt on, grease will leak inside the motor and may cause a damage. Make sure to remove the bolt before the grease injection.
- Do not install a joint, a hose, etc. to the grease exhaust port. Failure to observe this instruction may result in damage to the motor due to coming off of an oil seal.

2. Remove the hexagon socket head plug PT1/8.
3. Inject grease through the grease inlet using a grease gun.

– Grease type:	Molywhite RE No. 00
– Amount of grease:	approx.300 cc (600 cc for 1st supply)
– Air supply pressure of grease pump:	0.3 MPa or less
– Grease injection rate:	8 g/s or less
4. The grease discharge is complete when new grease appears from the exhaust port. The new grease can be distinguished from the old grease by color.
5. Move the B-axes for a few minutes to discharge the excess grease.
6. Wipe the discharged grease with a cloth and reinstall the hexagon socket head plug PT1/8 to the exhaust port.
Before installing the plug, apply Three Bond 1206C on the thread part of each plug, then tighten the plug with a tightening torque of 4.9 N•m (0.5 kgf•m).
7. Remove the grease zerk from the grease inlet and reinstall the hexagon socket head plug PT1/8.
Before installing the plug, apply Three Bond 1206C on the thread part of each plug, then tighten the plug with a tightening torque of 4.9 N•m (0.5 kgf•m).

9.3.5.2 Grease Exchange

(Refer to Fig. 9-9 "B- and T-Axis Speed Reducers and Gears Diagram" on page 9-17.)

1. Remove the hexagon socket head plug PT1/8 from the grease exhaust port.
2. Remove the hexagon socket head plug PT1/8 from the grease inlet.

NOTE

- If grease is injected with the bolt on, grease will leak inside the motor and may cause a damage. Make sure to remove the bolt before the grease injection.
- Do not install a joint, a hose, etc. to the grease exhaust port. Failure to observe this instruction may result in damage to the motor due to coming off of an oil seal.

3. Install the grease zerk PT1/8 to the grease inlet. (The grease zerk is delivered with the manipulator.)
4. Inject grease through the grease inlet using a grease gun.
 - Grease type: Molywhite RE No. 00
 - Amount of grease: approx.1500 cc
 - Air supply pressure of grease pump: 0.3 MPa or less
 - Grease injection rate: 8 g/s or less
5. The grease discharge is complete when new grease appears from the exhaust port. The new grease can be distinguished from the old grease by color.
6. Move the B-axes for a few minutes to discharge the excess grease.
7. Wipe the discharged grease with a cloth and reinstall the hexagon socket head plug PT1/8 to the exhaust port.
 Before installing the plug, apply Three Bond 1206C on the thread part of each plug, then tighten the plug with a tightening torque of 4.9 N•m (0.5 kgf•m).

NOTE

- If grease is injected with the plug on, grease will leak inside the motor and may cause a damage. Make sure to remove the plug before the grease injection.

8. Remove the grease zerk from the grease inlet and reinstall the hexagon socket head plug PT1/8.
 Before installing the plug, apply Three Bond 1206C on the thread part of each plug, then tighten the plug with a tightening torque of 4.9 N•m (0.5 kgf•m).

9.3.6 Notes for Maintenance

When performing maintenance such as replacement of a wire harness in the manipulator, the encoder connector may be necessary to be removed. In this case, be sure to connect the battery pack to the battery backup connector before removing the encoder connector.

Removing the encoder connector without connecting the battery pack leads to disappearance of the encoder absolute data.

For the battery pack connection, refer to *Fig. 9-10 "Battery Pack Connection"*.

9.3.6.1 Battery Pack Connection


The connectors (crimped contact-pin) for the battery backup are installed at the end point of the motors (BAT and OBT are marked). Connect the battery packs according to the following procedure.

1. Remove the cap attached to the battery backup connector of the motors.
2. Connect the battery packs (HW9470932-A) with the battery backup connectors (BAT and OBT are marked) located at the end point of the cables for the encoder. (Under this condition, remove the encoder connector and carry out the maintenance checks.)
3. Confirm all connectors connected after the maintenance check, and remove the battery packs. Install the caps attached to the battery backup connectors of the motors.



Do not remove the battery pack in the connector base.

Fig. 9-10: Battery Pack Connection



10 Recommended Spare Parts

It is recommended to keep the parts and components in the following table in stock as spare parts for the MOTOMAN-MPL80. Product performance cannot be guaranteed when using spare parts from any company other than Yaskawa. The spare parts are ranked as follows:

- Rank A: Expendable and frequently replaced parts
- Rank B: Parts for which replacement may be necessary as a result of frequent operation
- Rank C: Drive unit



For replacing parts in Rank B or Rank C, contact your Yaskawa representative.

Table 10-1: Spare Parts for YR-MPL0080-A00, -A01 (Sheet 1 of 2)

Rank	Parts No.	Name	Type	Manufacturer	Qty	Qty per Unit	Remarks
A	1	Grease	Molywhite RE No. 00	Yaskawa	16 kg	-	For speed reducers in each axis
A	2	Liquid Gasket	Three Bond 1206C	Three Bond Co., Ltd.	-	-	
A	3	Battery Pack	HW9470932-A	Yaskawa	1	1	For internal wire harness replacement
A	4	Battery Pack	HW0470360-A	Yaskawa	1	1	
B	5	S-Axis Speed Reducer	HW0387752-A	Yaskawa	1	1	For the manipulator assembled after Apr.2, 2014
			HW1382898-A	Yaskawa	1	1	
B	6	S-Axis Input Gear	HW0313741-1	Yaskawa	1	1	
B	7	L-Axis Speed Reducer	HW09381465-B	Yaskawa	1	1	
B	8	L-Axis Input Gear	HW9482771-A	Yaskawa	1	1	
B	9	U-Axis Speed Reducer	HW0387753-A	Yaskawa	1	1	
B	10	U-Axis Input Gear	HW0313740-1	Yaskawa	1	1	
B	11	B-Axis Speed Reducer	HW0387737-B	Yaskawa	1	1	
B	12	T-Axis Speed Reducer	HW0389043-A	Yaskawa	1	1	
C	13	S-Axis AC Servomotor	SGMRV-30ANA-YR11 HW0388669-A	Yaskawa	1	1	
C	14	L-Axis AC Servomotor	SGMRV-37ANA-YR11 HW0388670-A	Yaskawa	1	1	
C	15	U-Axis AC Servomotor	SGMRV-13ANA-YR11 HW0388666-A	Yaskawa	1	1	
C	16	B-, T-Axes AC Servomotor	SGMRV-09ANA-YR11 HW0388665-A	Yaskawa	1	2	

Table 10-1: Spare Parts for YR-MPL0080-A00, -A01 (Sheet 2 of 2)

Rank	Parts No.	Name	Type	Manufacturer	Qty	Qty per Unit	Remarks
C	17	Internal Wire Harness	HW0175247-A	Yaskawa	1	1	
C	18	Connector Base	HW0374528-B	Yaskawa	1	1	
C	19	Circuit Board	SGDR-EFBA02A	Yaskawa	1	1	

11 Parts List**11.1 S-Axis Unit**

Fig. 11-1: S-Axis Unit




Table 11-1: S-Axis Unit

No.	DWG No.	Name	Pcs
1001	HW0387752-A	Speed reducer	1
	HW1382898-A (For the manipulator assembled after Apr.2, 2014)	Speed reducer	1
1002	SGMRV-30ANA-YR1*	Motor	1
1003	HW9404486-1	Shaft	1
1004	HW0400405-1	Stopper	1
1005	6310	Bearing	1
1007	M8X45	Socket screw	1
1008	2H-8	Spring washer	1
1009	HW0102237-2	S-head	1
1010	M12X45	Socket screw	15
	M12X45 (For the manipulator assembled after Apr.2, 2014)	Socket screw	16
1011	2H-12	Spring washer	15
	2H-12 (For the manipulator assembled after Apr.2, 2014)	Spring washer	16
1012	C-30-SG-22A	Grommet	1
1013	M12X55	Socket screw	3
1014	2H-12	Spring washer	3
1016	STW-50	Retaining Ring-C type	1
1017	M8X100	Socket screw	1
1018	2H-8	Spring washer	1
1019	PT3/8(STAINLESS)	Plug	1
1020	MSTH10-25	Dowel pin	1
1021	M12X55	Socket screw	12
1022	2H-12	Spring washer	12
1023	HW9405875-1	Collar	1
1024	M20X40	Socket screw	1
1025	HW0102236-1	Base	1
1026	KQ2L10-01S	Elbow	1
1028	NB-1075-0.43	Tube	1
1029	HW0314010-1	M-base	1
1030	Y507212.5	Oil seal	1
1031	M6X20	Socket screw	2
1032	2H-6	Spring washer	2
1033	HW0313741-1	Gear	1
1034	PT1/8(STAINLESS)	Plug	1
1035	M12X35 (For the manipulator assembled after Apr.2, 2014)	GT-SA bolt	2

11.2 L-Axis Unit

Fig. 11-2: L-Axis Unit




Table 11-2: L-Axis Unit

No.	DWG No.	Name	Pcs
2001	SGMRV-37ANA-YR1*	Motor	1
2002	HW0102425-1	L-arm	1
2003	M12X55	Socket screw	16
2004	SW-2H-12	Spring washer	16
2005	HW9381465-B	Speed reducer	1
2006	M10X40	Socket screw	18
2007	2H-10	Spring washer	18
2008	M16X45	Socket screw	6
2009	2H-16	Spring washer	6
2010	HW9481343-A	Shaft	1
2011	HW9482771-A	Gear	1
2012	HW9405902-1	Pipe	1
2013	M8X130	Socket screw	1
2014	2H-8	Spring washer	1
2015	M8	Washer	1
2016	G270	O-ring	1
2017	EZ0094-A0	Air breather	1
2018	HW0314011-1	M-base	1
2019	HW0312815-2	Gear	1
2020	HW9482447-A	Oil seal	1
2021	M12X65	Socket screw	4
2022	2H-12	Spring washer	4
2023	M6X30	Socket screw	2
2024	2H-6	Spring washer	2
2025	EZ5002A0	Cap	3
2026	PT3/8(STAINLESS)	Plug	2
2027	PT1/8(STAINLESS)	Plug	4
1009	HW0102237-4	S-head	1

11.3 U-Axis Unit

Fig. 11-3: U-Axis Unit




Table 11-3: U-Axis Unit

No.	DWG No.	Name	Pcs
3001	SGMRV-13ANA-YR1*	Motor	1
3002	HW0413914-1	Stopper	1
3003	M6X55	Socket screw	1
3004	2H-6	Spring washer	1
3005	M8X55	Socket screw	4
3006	2H-8	Spring washer	4
3007	HW0387753-A	Speed reducer	1
3008	HW0313740-1	Gear	1
3009	HW8411125-3	Washer	1
3010	M6X115	Socket screw	1
3011	2H-6	Spring washer	1
3012	M12X30	Socket screw	12
3013	2H-12	Spring washer	12
3014	M10X30	Socket screw	6
3015	2H-10	Spring washer	6
3016	HW9405257-1	Collar	1
3017	HW0102239-2	Casing	1
3018	Y426012.5	Oil seal	1
3019	M6X30	Socket screw	2
3020	2H-6	Spring washer	2
3021	HW0314012-1	M-base	1
3022	G195	O-ring	1
3023	M10X40	Socket screw	16
3024	2H-10	Spring washer	16
3025	TSH6-01M	Union	2
3026	UB-0640-0.1C	Tube	2
3027	PT1/8(STAINLESS)	Plug	1
3028	PT3/8(STAINLESS)	Plug	1
2002	HW0102425-1	L-arm	1

11.4 B-,T-Axes Unit

Fig. 11-4: B-,T-Axes Unit




Table 11-4: B-,T-Axes Unit

No.	型式	Name	Pcs.
4001	HW0387754-A	Speed reducer	1
4002	SGMRV-09ANA-YR1*	Motor	2
4003	AC1306-G00X6	Oil seal	1
4004	TC20367*FKM*	Oil seal	1
4005	HW0415265-1	Spacer	1
4006	HW0415352-1	Cover	1
4007	HR32005XJ	Bearing	2
4008	HR32909J	Bearing	1
4010	HW0313628-1	Gear	1
4012	HW0313629-1	Gear	1
4013	HW0312826-1	Gear	1
4014	HW0404196-8	Washer	1
4016	MSTH8-20	Dowel pin	1
4017	HW0312834-1	Shaft	1
4019	HW0312831-1	Gear	1
4020	HW0312833-1	Shaft	1
4021	HW0312835-1	Shaft	1
4022	HW0312838-1	Flange	1
4023	MSTH6-15	Dowel pin	1
4024	HW0200768-1	Shaft	1
4025	HW0312837-1	Housing	1
4026	HW9405662-1	Washer	1
4027	HW0312825-1	Gear	1
4028	HW0412720-1	B nut	1
4029	PT1/8 (STAINLESS)	Plug	2
4030	PT3/8 (STAINLESS)	Plug	1
4031	M5X16	GT-SA bolt	14
4033	M4X6	H set screw	1
4034	M6X25	Socket screw	1
4035	2H-6	Spring washer	1
4036	M8X25	Socket screw	18
4037	2H-8	Spring washer	19
4038	M6X20	Socket screw	1
4039	2H-6	Spring washer	1
4040	M6X25	Socket screw	6
4041	2H-6	Spring washer	6
4042	M8X18	Socket screw	3
4043	2H-8	Spring washer	3
4044	M6X35	GT-SA bolt	16
4045	M8X30	GT-SA bolt	8
4046	M8X25	Socket screw	7
4047	2H-8	Spring washer	7
4048	M8X20	Socket screw	1
4049	M4X6	Socket screw	1
4050	2H-4	Spring washer	1
3017	HW0102239-2	Casing	1

11.5 Wrist Unit

Fig. 11-5: Wrist Unit




Table 11-5: Wrist Unit

No.	DWG No.	Name	Pcs
5001	HW0387737-B	Speed reducer	1
5002	HW0389043-A	Speed reducer	1
5003	HW9405880-1	B-cover	1
5004	HW9405445-1	B nut	1
5005	HW9405881-1	B nut	2
5006	HW9405882-1	B nut	1
5007	S34	O ring	1
5008	AE3092E2	Oil seal	1
5009	SC15247F585	Oil seal	1
5010	SC39528F585	Oil seal	1
5011	HW9405883-1	Collar	1
5012	HW9381667-A	Gear	1
5013	HW9381668-A	Gear	1
5014	HW9381669-A	Gear	1
5015	HW9381672-A	Gear	1
5016	WR60	Circlip	1
5017	HW9405888-*	Shim	*
5022	HW9405885-*	Shim	*
5027	HW9482772-A	Gear	1
5028	HW9482765-A	Shaft	1
5029	HW9381675-A	Shaft	1
5030	RTW42	Retaining Ring	1
5031	STW-25	Retaining Ring-C type	1
5032	ISTW40	Retaining Ring	1
5033	HW9405891-1	Housing	1
5034	PT3/8	Plug	2
5035	PT1/8 (STAINLESS)	Plug	3
5036	HW9405892-1	Flange	1
5037	HW9481234-A	Bearing	1
5038	6004LBD2PX24V1	Bearing	1
5039	HW9480086-A	Bearing	4
5040	6912DU	Bearing	1
5041	6808LLU	Bearing	2
5042	6905	Bearing	1
5043	HW9405901-1	Washer	1
5044	BG3000-15X19	Ring	1
5045	HW0312827-1	Gear	1
5046	HW0312828-1	Gear	1
5047	HW0313631-1	Gear	1
5048	HW0313631-1	Gear	1
5049	HW0201297-A	Shaft	1
5053	HW1300244-1	Flange	1
5054	HW0314705-1	Flange	1

Table 11-5: Wrist Unit

No.	DWG No.	Name	Pcs
5055	HW9302630-3	Housing	1
5056	HW0102233-1	U-arm	1
5057	HW0102491-1	Wrist	1
5058	HW0201226-1	Cover	1
5059	HW0414884-1	Cover	1
5060	HW0412694-*	Shim	*
5068	HW0412683-*	Shim	*
5075	HW0412695-*	Shim	*
5082	HW0412696-*	Shim	*
5089	HW9404651-1	Washer	1
5090	M8X85	Socket screw	12
5091	2H-8	Spring washer	12
5092	M4X12	GT-SA bolt	17
5093	M5X16	Socket screw	10
5094	2H-5	Spring washer	10
5095	M5X35	Socket screw	6
5096	2H-5	Spring washer	6
5097	M4X25	Socket screw	6
5098	2H-4	Spring washer	6
5099	M4X6	H set screw	1
5100	M8X18	GT-SA bolt	8
5102	M6X30	GT-SA bolt	10
5103	M6X20	Socket screw	1
5104	2H-6	Spring washer	1
5105	M6X25	Socket screw	16
5106	2H-6	Spring washer	16
5107	M8X25	Socket screw	12
5108	2H-8	Spring washer	12
5109	M6X16	Socket screw	1
5110	2H-6	Spring washer	1
5111	M8X20	Socket screw	16
5112	2H-8	Spring washer	16
5113	M4X14	Socket screw	4
5114	2H-4	Spring washer	4
5115	M5X7	Magic screw	6
3017	HW0102239-2	Casing	1

MOTOMAN-MPL80 INSTRUCTIONS

HEAD OFFICE

2-1 Kurosakishiroishi, Yahatanishi-ku, Kitakyushu 806-0004, Japan
Phone +81-93-645-7703 Fax +81-93-645-7802

YASKAWA America Inc. (Motoman Robotics Division)
100 Automation Way, Miamisburg, OH 45342, U.S.A.
Phone +1-937-847-6200 Fax +1-937-847-6277

YASKAWA Europe GmbH (Robotics Division)
Yaskawastrasse 1, 85391 Allershausen, Germany
Phone +49-8166-90-100 Fax +49-8166-90-103

YASKAWA Nordic AB
Bredbandet 1 vån. 3 varvsholmen 392 30 Kalmar, Sweden
Phone +46-480-417-800 Fax +46-480-417-999

YASKAWA Electric (China) Co., Ltd.
22/F One Corporate Avenue No.222, Hubin Road, Huangpu District, Shanghai 200021, China
Phone +86-21-5385-2200 Fax +86-21-5385-3299

YASKAWA SHOUGANG ROBOT Co. Ltd.
No7 Yongchang North Road, Beijing E&T Development Area, China 100176
Phone +86-10-6788-2858 Fax +86-10-6788-2878

YASKAWA India Private Ltd. (Robotics Division)
#426, Udyog Vihar, Phase- IV, Gurgaon, Haryana, India
Phone +91-124-475-8500 Fax +91-124-475-8542

YASKAWA Electric Korea Co., Ltd
9F, Kyobo Securities Bldg., 26-4, Yeouido-dong, Yeongdeungpo-gu, Seoul 150-737, Korea
Phone +82-2-784-7844 Fax +82-2-784-8495

YASKAWA Electric Taiwan Corporation
12F, No.207, Sec. 3, Beishin Rd., Shindian District, New Taipei City 23143, Taiwan
Phone +886-2-8913-1333 Fax +886-2-8913-1513

YASKAWA Electric (Singapore) PTE Ltd.
151 Lorong Chuan, #04-02A, New Tech Park, Singapore 556741
Phone +65-6282-3003 Fax +65-6289-3003

YASKAWA Electric (Thailand) Co., Ltd.
252/125-126 27th Floor, Tower B Muang Thai-Phatra Complex Building,
Rachadaphisek Road, Huaykwang, Bangkok 10320, Thailand
Phone +66-2693-2200 Fax +66-2693-4200

PT. YASKAWA Electric Indonesia
Secure Building-Gedung B Lantai Dasar & Lantai 1 Jl. Raya Protokol Halim Perdanakusuma,
Jakarta 13610, Indonesia
Phone +62-21-2982-6470 Fax +62-21-2982-6741

Specifications are subject to change without notice
for ongoing product modifications and improvements.